



TS255 Series Instrument and PC25X PC Software Utility Program



Amendment Record

TS255 Series Instrument PC25X Utility Software Document 51369

Manufactured by **Thurman Scales Inc.**
4025 Lakeview Crossing
Groveport, OH 43125

Created	02/2016	
Revision 1	02/2016	Released Manual
Revision 2	02/2016	Updated AutoTare and Manual Tare information
Revision 3	03/2016	Updated Weight Accumulation
Revision 4	04/2016	Added TM-U220 Tape Printer

Disclaimer

Every effort has been made to provide complete and accurate information in this manual. However, although this manual may include a specifically identified warranty notice for the product, Thurman Scales makes no representations or warranties with respect to the contents of this manual, and reserves the right to make changes to this manual without notice when and as improvements are made.

It is the responsibility of the requesting party to develop, maintain, install, and connect networking devices and general network connectivity as it applies to the originating party's network. No warranty or guarantee, expressed or implied, concerning the network, its design, its installation, or operational characteristics has been offered by Thurman Scales. Thurman Scales shall not be liable for any loss, damage, cost of repairs, incidental or consequential damages of any kind, whether or not based on express or implied warranty, contract, negligence, or strict liability arising in connection with the design, development, installation, or use of an intended network.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Thurman Scales is under license. Other trademarks and trade names are those of their respective owners.

© Copyright 2016

This document contains proprietary information protected by copyright. All rights are reserved; no part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without prior written permission of the manufacturer.

Table of Contents

SECTION 1: GENERAL INFORMATION	7
1.1. Model Descriptions.....	7
1.2. Main Product Features.....	7
1.3. Specifications.....	8
1.3.1. INSTRUMENT APPROVALS	8
1.3.2. BASIC SPECIFICATIONS	8
1.3.3. STANDARD SETTINGS	9
1.3.4. WEIGHT ACCUMULATOR.....	9
1.3.5. OUTPUTS.....	9
1.3.6. PC25X.....	9
1.3.7. POWER REQUIREMENTS	9
1.3.8. DC MODELS	10
1.3.9. OUT OF RANGE WARNINGS.....	10
1.3.10. EXTERNAL PRINTERS.....	10
1.3.11. ENVIRONMENT	10
1.4. Accessories	11
1.5. AC Operation.....	12
1.6. Powering up the TS255.....	12
SECTION 2: USER OPERATIONS	13
2.1. Front Panel Key Functions.....	13
2.2. Front Panel Programming Parameters.....	14
2.2.1. SETTING AND PROGRAMMING THE TIME.....	14
2.2.2. PROGRAMMING THE DATE.....	14
2.2.3. CHECKING POWER SUPPLY / BATTERY VOLTAGE	15
2.2.4. PROGRAMMING THE SLEEP FUNCTION	15
2.3. Operating Procedures	15
2.3.1. PROGRAMMING PORT 1.....	16
2.3.2. PROGRAMMING THE PORT 1 OUTPUT TYPE	16
2.3.3. PROGRAMMING PORT 1 BAUD RATE	17
2.3.4. PROGRAMMING PORT 1 DATA BITS	17
2.3.5. PROGRAMMING PORT 1 PARITY SETTING	17
2.3.6. PROGRAMMING PORT 1 STOP BITS.....	17
2.3.7. PROGRAMMING PORT 2.....	18
2.3.8. PROGRAMMING THE PORT 2 OUTPUT TYPE	18
2.3.9. PROGRAMMING PORT 2 BAUD RATE	19
2.3.10. PROGRAMMING PORT 2 DATA BITS	19
2.3.11. PROGRAMMING PORT 2 PARITY SETTING	19
2.3.12. PROGRAMMING PORT 2 STOP BITS.....	20
2.3.13. PROGRAMMING THE BACK LIGHT OPTIONS.....	20
2.3.14. PROGRAMMING THE BACK LIGHT TIMING	20
2.4. Gross, Tare and Net Weight	21
2.5. Basic Weighing.....	22
2.6. Gross Weighing.....	22
2.7. Net Weighing with AutoTare	22
2.8. Net Weighing with Manual Tare Entry	23
2.9. Weight Accumulation	23
2.9.1 GROSS WEIGHT ACCUMULATION	23
2.9.2 NET WEIGHT ACCUMULATION	24
2.9.3. GROSS AND NET WEIGHT ACCUMULATION.....	25

2.10. Number of Accumulations.....	26
2.11. Clearing the Accumulators.....	27
2.12. Piece Counting.....	27
2.13. Piece Count and Total.....	28
2.14. Peak Weight.....	29
SECTION 3: SERIAL COMMUNICATION WIRING	30
3.1. JP3 Jumper Configuration)	30
3.2. TB4 Wiring connections, COM1 (A), COM2 (B), and COM2 (C).....	31
3.3. TB5 Remote Switch Inputs	31
3.4. Remote Display Active Keys.....	32
SECTION 4: INPUT / OUTPUT.....	33
4.1. 3550 Tape Printer.....	33
4.2. TM-U220 Tape Printer	33
4.3. Okidata 186 T Form Printer.....	34
4.4. Okidata 420 Form Printer.....	38
4.5. TM-U295 Ticket Printer	41
4.6. TM-U590 Ticket Printer	41
4.7. Remote Display.....	42
4.8. 4-20mA Analog Output Setup.....	43
4.8.1. PROGRAMMING THE 4MA WEIGHT VALUE.....	44
4.8.2. PROGRAMMING THE 20MA WEIGHT VALUE.....	44
SECTION 5: FIELDBUS/BLUETOOTH.....	45
5.1. Fieldbus Installation.....	45
5.2. Fieldbus Connections.....	46
5.2.1. OVERVIEW OF TERMS.....	46
5.2.2. DEVICENET™ (29578)	47
5.2.3. CONTROLNET™ (31979).....	50
5.2.4. PROFIBUS®-DP (29576).....	52
5.2.5. MODBUS TCP (34032)	54
5.2.6. ETHERNET/IP DIAGNOSTIC LEDS.....	56
5.3. Bluetooth® Technology Device	57
SECTION 6: PC25X UTILITY SOFTWARE.....	60
6.1. Introduction	60
6.2. Communication Settings.....	60
6.3. Communication Files.....	62
6.4. Menu Bar.....	62
6.4. Menu Bar, Continued	63
6.5. Configuration	64
6.6. Calibration.....	65
6.7. First time connection using PC25X PC Utility and TS25X Ethernet TCP/IP option.....	65
6.8. Fieldbus	70
6.9. 4-20 mA.....	73
6.10. Custom Output – Settings.....	74
6.11. Custom Output – Load.....	75
6.12. Custom Output – Build	75
6.13. Custom Output – Tokens.....	76
6.14. Custom Output – Weights.....	78

6.15. Formatting Tickets	79
6.16. Printed Examples	80
SECTION 7: SERVICE AND MAINTENANCE	83
7.1. Troubleshooting the Instrument	83
7.2. Battery Installation	83
APPENDIX I: DATA OUTPUT FORMATS	84
A. General Notes	84
B. Thurman/ Toledo Continuous Output	84
C. Cardinal 738 Continuous Scoreboard Output	87
D. Weightronics WI-120 Continuous Output	87
E. Condec Continuous Output.....	88
F. Demand Output - DEFAULT	88
G. Continuous Output - DEFAULT	89
H. PLC (DO NOT USE)	90
<i>GENERAL INFORMATION</i>	90
I. UPS	91
J. P Ship	92
APPENDIX II: REMOTE PC COMMANDS	94
APPENDIX III: TS255 REMOTE DISPLAY WIRING	96
APPENDIX IV: TS255 REMOTE DISPLAY ACTIVE KEYS.....	97

Section 1: General Information

1.1. Model Descriptions

The TS255 is a general purpose weighing instrument that can be used with a wide variety of platforms and load receivers, and is available in eight (8) different configurations.

MODEL	PART NO.
• TS255 Series ABS, AC Power	34662
• TS255 Series ABS, AC/Battery Power	34666
• TS255-Series SS, AC Power	34663
• TS255 Series SS, AC/Battery Power	34667

1.2. Main Product Features

Major features of the Instrument include the following.

- Push-button programming and calibration.
- Program data is stored in battery supported RAM and backed up in flash memory.
 - The battery should be replaced every twelve (12) months.
- The TS255 series instrument features a large one inch (1”) green backlit LCD weight display, which can be tilted up or down to accommodate different lighting conditions.
 - Microprocessor controlled design allows the instrument to be rapidly programmed at installation to meet the specific requirements of the application.
- The obtainable accuracy meets Handbook 44 requirements, and the instrument is approved for **commercial application up to 10,000 divisions**.
 - A **maximum of 100,000 displayed divisions** can be programmed for non-commercial applications.
- A computer utility software program PC25X is available, downloaded from Thurman Intranet for programming using the computer, and is required for certain features such as custom ticket formatting.

1.2. Main Product Features, Continued

- The TS255 software utility program can also upload and modify the instruments set-up, configuration, and calibration.
 - Saved information can be downloaded from a computer to the TS255 Series in the event of a catastrophic failure.
- The instrument provides two (2) serial communication ports to provide communication to various types of peripheral devices for RS232, RS422, RS485, and 20mA data outputs.
- Optional accessories include a 4-20 mA analog output, Bluetooth® serial adapter, and five different fieldbus devices; Profibus®, DeviceNet™, ControlNet™, Modbus® and Ethernet/IP.

1.3. Specifications

1.3.1. INSTRUMENT APPROVALS

• CC	15-099
• MC	AM-6002
• ETL	ETL Listed
•	Conforms to ANSI/UL STD 60950-1
•	Certified to CAN/CSA C22.2 STD NO. 60950-1-03

1.3.2. BASIC SPECIFICATIONS

• ENCLOSURE	ABS, Black NEMA 1, Stainless Steel NEMA 4X Desk and Wall Mount
• DISPLAY	6-digits, One inch (1") LCD, Green Backlight
• FRONT PANEL KEYS	On/Off, Units, Zero, B/G, Net, Tare and Print
• UNITS	lbs., oz, kg, g and lbs/oz, or custom
• GRADUATION SIZE	0.0001 to 50
• AD CONVERSION	66 per second
• LOAD CELL EXCITATION	5 Volts DC
• SENSITIVITY	1µv/d (microvolt/division)
• LOAD CELLS	Eight (8) 350 ohm or Sixteen (16) 1000 ohm
• DISPLAYED DIVISIONS	10,000d Commercial and 100,000d Non-Commercial
• CAPACITIES	Programmable to 999999

1.3. Specifications, Continued

1.3.3. STANDARD SETTINGS

• Zero Range	Off, 2 % or 100%
• Auto Zero Tracking	OFF, 0.5, 1 or 3 divisions
• Balance	OFF, 0.5, 1 or 3 divisions
• Filter	Slow, Animal, Standard, and Fast
• Display Update Rate	0.2, 0.4, and 0.8 seconds

1.3.4. WEIGHT ACCUMULATOR

• Capacity	999,999 Weight Units – Printed or viewed.
------------	--

1.3.5. OUTPUTS

• PORT 1	Bidirectional Serial Port. Settings include OFF , RS232 , RS422, and RS485 . RS232 has 30+ updates a second
• PORT 2	Port 2 is used to interface to the PC25X program, OR, Provide 20 mA passive , RS232 , RS422 , or RS485 .

1.3.6. PC25X

• Computer software utility program is available for your local Thurman Representative. • PC25X is required for setting certain aspects of programming, such as custom Units and custom ticket formatting.

1.3.7. POWER REQUIREMENTS

• 117 volts AC +/- 10 % • 220 volts AC +/- 10 % • $\leq 0/2$ volts AC between Neutral and Ground
• 1.5 watts maximum • The TS255 is designed to operate from 80 to 260 volts AC, 50 to 60 Hertz

1.3. Specifications, Continued

1.3.8. DC MODELS

Batteries	Five (5) Size "D" Alkaline batteries @ 1.5 Volts DC each.
Battery Life	Battery usage time can be adversely affected by battery storage, battery capacity and battery brand. To maximize battery life, serial Ports 1 and 2 should be switched OFF, if not used. (1) 350Ω load cell, Back Light = OFF, RS232 ports = OFF.....55 hours (4) 350Ω load cell, Back Light = ON, RS232 ports = OFF.....16 hours (4) 350Ω load cell, Back Light = OFF, RS232 ports = OFF.....33 hours
Internal Battery	Should be replaced every 12 months using Panasonic CR 1220 3V or equivalent.

1.3.9. OUT OF RANGE WARNINGS

HiCAP	Scale input is over capacity
-----	Displayed weight exceeds 6 digits
Sleep Mode	Settings include OFF, 1, 2, 5, 10, 20, and 30 minutes
Time and Date	Battery Maintained

1.3.10. EXTERNAL PRINTERS

Tape Printers – Citizens IDP 3550 and Epson Model TM-U220 Tape Printers
Serial Form Printers – Okidata 184 & 186 Serial Form Printer
Okidata 420 Serial Form Printer
Ticket Printers – Epson Models TM-U295, TM-U590 Ticket Printers

1.3.11. ENVIRONMENT

Temperature	-10°C to + 40°C (+14°F to + 104°F)
Storage Temp.	-40°C to + 60°C (-40°F to + 140°F)

1.4. Accessories

Optional accessories include the following.

FIELD BUS DEVICES				
• DeviceNet™	• ControlNet™	• PROFIBUS®-DP	• Modbus®	• Ethernet/IP

4-20 MA ANALOG CURRENT LOOP OUTPUT	
• 16 bit Resolution and Monotonicity	• 0.01% Non-Linearity
• Isolated 4mA to 20mA	• Front Panel Programmable or via PC25X utility software program

BLUETOOTH® TECHNOLOGY INTERFACE
- Utilizes either Port 1 or Port 2 Serial Output. RS232 serial Interface to Bluetooth Interface. Range 100 meters (328 feet). - The Bluetooth option will operate either as a Client or Server depending on which device the TS255 is connected. - If connected to a printer, the TS255 will be a Server. - If connected to a PC, the Instrument will be a Client.

W A R N I N G !

Absolutely no physical, electrical or program modifications other than selection of standard options and accessories can be made by customers to this equipment

Repairs are performed by Thurman Scale Service Technicians and Authorized Distributor Personnel ONLY!

Failure to comply with this policy voids all implied and/or written warranties


1.5. AC Operation

The TS255 is designed to operate from **80 to 260 volts AC, 50 to 60 Hertz** with **Auto Switching** capability.

- 110 Volt AC Operation
 - The TS255 is factory wired for 110 VAC and requires a three prong grounded outlet.

TS25X TB3	TS25X Power Cord	Connection
1	Brown/Black	AC (HOT) 117 VAC
2	Blue/White	ACC (Neutral)
3	Green/Green-Yellow	Ground

- 220 Volt AC Operation
 - Rewire the power cord according to the following diagram:



1.6. Powering up the TS255

1. Press and hold the **ON / OFF Key** for one to two (1 – 2) seconds.
 - The Instrument will display “888888”, then a “1234567890” character display moving from right to left, followed by the revision of software.
 - Upon completing the warm-up, the TS25X will display the actual weight on the scale.
2. Press and hold the **ON/OFF Key** for one to two (1 – 2) seconds to turn off the TS255.

Section 2: User Operations

2.1. Front Panel Key Functions


ON/OFF	Turns the Instrument on or off.
UNITS	Switches between pre-programmed selectable weight units.
ZERO	Sets the display to zero, programmable: 2% or 100% of capacity.
B/G – NET	Toggles between Gross and Net weights This applies only if a Tare Value has been entered greater than ZERO.
TARE	Automatically tares off displayed weight when key is pressed.
PRINT	Simple RS232 output when key is pressed.
0-9	Used for Programming and inputting manual tares.
MENU	Gains access to the sub-menus in the Configuration Mode .
ARROW KEYS	Used for scrolling through the menu selections.

Depending on programmed selection, **Tare Weight** amount will do one of the following.

- Be retained for reuse until changed, or if power is removed.

OR...

- Automatically clear when **Gross Weight** returns to **ZERO**.



2.2. Front Panel Programming Parameters

Follow these steps to program the Instrument.

2.2.1. SETTING AND PROGRAMMING THE TIME

1. At **SEtUP**, press the **RIGHT ARROW** key; **Set-ti** displays, followed by the current time setting in **HHMMSS** format.
2. Press the **MENU** key to edit or **RIGHT ARROW KEY** to skip.
 - The first digit will blink.
 - Key the new time setting with the **0-9** keys.
3. When complete, the program will advance to the current display format setting.
 - **12hr A** – 12 hour clock, currently AM.
 - **12hr P** – 12 hour clock, currently PM.
 - **24 hour** – Military time (1:00 PM = 1300 hours).
4. Press the **MENU** key to edit, or **RIGHT ARROW KEY** to skip.
 - Use the **ARROW KEYS** to toggle through the options.
 - Press **ENTER** to save the setting.
5. When complete, the program will advance to Programming the Date.

2.2.2. PROGRAMMING THE DATE

1. **Set-dA** displays, followed by the current date setting in **MM-DD-YY** format.
2. Press the **MENU** key to edit or **RIGHT ARROW KEY** to skip.
 - The first digit will blink.
 - Key the new date setting with the **0-9** keys.
3. When complete, the program will advance to Port 1.

NOTE: See Section 3.2: TB4 Wiring connections and Section 4: INPUT/OUTPUT for information on configuring Port 1 and Port 2 parameters.

2.2.3. CHECKING POWER SUPPLY / BATTERY VOLTAGE

- Press the **TARE** key for **three (3) seconds**.
 - The battery current or power supply voltage displays
 - **8.3 VDC nominal**.

2.2.4. PROGRAMMING THE SLEEP FUNCTION

1. Press and hold the **BG/Net** key for three (3) seconds.
 - The display will indicate **SLEEP**, and then display the current setting.
 - This function serves to prolong battery life by turning off the Instrument.
 - When there is no activity, the **Sleep Mode** activates according to the programmed time frame.
 - Activity is when weight is applied to the scale exceeding the balance setting, pressing a key, and receiving a polling request on a communication port.
2. Press **MENU**.
3. Use the **Arrow Keys** to toggle between the available options.
 - Selections in **minutes** include **OFF, 1, 2, 5, 10, 20, 30**.
4. Press **ENTER** to save the setting.

2.3. Operating Procedures

1. Press and hold the **ON / OFF** Key for two (2) seconds.
 - The Instrument will display “**888888**”, followed by “**1234567890**” character display moving from right-to-left, then the revision of software.
 - Once the warm-up is complete, the TS25X displays the actual weight on the scale.
2. To turn the **TS255** off, press the **ON / OFF** key for two (2) seconds
 - The **Zero. Tare** and the **AZT** functions require the displayed weight to be stable before these functions will operate.
 - The weight reading is stable if the variation in weight is less than the programmed **BAL RANGE**.

2.3.1. PROGRAMMING PORT 1

1. **Port 1** displays, followed by the current protocol setting.
 - OFF – com port is not active.
 - rS232 – using RS232 protocol
 - rS485 – using RS485 or RS422 protocol
2. Press **MENU** key to edit, or **RIGHT ARROW KEY** to skip.
 - Press the **RIGHT ARROW** key to scroll through available settings.
 - Press **ENTER** to select an option.
3. When complete, the program will advance to output.

2.3.2. PROGRAMMING THE PORT 1 OUTPUT TYPE

1. Output displays, followed by the current output type setting.

OPTION	DESCRIPTION
Button	Using the Print key.
Auto	Activated by stable weight above 10d, reset by return to half of printed weight.
Contin	Continuous Output. Once every display update rate.
Poll	Demand Output by receipt of CR or programmed poll character
Rd2200	Remote Display for FAIRBANKS 2200
Rd2250	Remote Display for TS250/55
Rd2300	Remote Display for FAIRBANKS 2300 or IT-2000
Rd2500	Remote Display for FAIRBANKS 2500 or IS-3000
Rd2800	Remote Display for FAIRBANKS 2800
Rd5200	Remote Display for FAIRBANKS 5200
P Ship	Used for Fed Ex Shipping Software
UPS	Used for UPS Shipping Software
OFF	Output is not active

2. Press **MENU** key to edit, or **RIGHT ARROW KEY** to skip.
 - Press the **RIGHT ARROW KEY** to scroll through available settings.
 - Press **ENTER** to select an option.
3. When complete, the program will advance to Port 1 Baud Rate.

2.3.3. PROGRAMMING PORT 1 BAUD RATE

1. **Baud 1** displays, followed by the current baud rate setting.
 - 2400
 - 4800
 - 9600
 - 19200
 - 38400
 - 57600
 - 115200
2. Press **MENU** key to edit, or **RIGHT ARROW KEY** to skip.
 - Press the **RIGHT ARROW KEY** to scroll through available settings.
 - Press **ENTER** to select an option.
3. When complete, the program will advance to Port 1 Data Bits.

2.3.4. PROGRAMMING PORT 1 DATA BITS

1. **d-bitS** displays, followed by the current data bits setting:
 - 8
 - 7
2. Press **MENU** key to edit, or **RIGHT ARROW KEY** to skip.
 - Press the **RIGHT ARROW KEY** to scroll through available settings.
 - Press **ENTER** to select an option.
3. When complete, the program will advance to Port 1 Parity Setting..

2.3.5. PROGRAMMING PORT 1 PARITY SETTING

1. **Parity** displays, followed by the current parity bit setting:
 - **P None** – no parity bit
 - **P Odd** - odd parity bit
 - **P Even** – even parity bit
2. Press **MENU** key to edit, or **RIGHT ARROW KEY** to skip.
 - Press the **RIGHT ARROW KEY** to scroll through available settings.
 - Press **ENTER** to select an option.
3. When complete, the program will advance to Port 1 stop bits.

2.3.6. PROGRAMMING PORT 1 STOP BITS

1. **Stop** displays, followed by the current stop bits setting:
 - 1
 - 2

2. Press **MENU** key to edit, or **RIGHT ARROW KEY** to skip.
 - Press the **RIGHT ARROW KEY** to scroll through available settings.
 - Press **ENTER** to select an option.
3. When complete, the program will advance to Port 2.

2.3.7. PROGRAMMING PORT 2

1. **Port 2** displays, followed by the current protocol setting.
 - **OFF** – COM port is not active
 - **rS232** – Using RS232 protocol
 - **rS485** – Using RS485 or RS422 protocol
 - **Cloop** – Using 20 mA Current Loop (passive)
2. Press **MENU** key to edit, or **RIGHT ARROW KEY** to skip.
 - Press the **RIGHT ARROW KEY** to scroll through available settings.
 - Press **ENTER** to select an option.
3. When complete, the program will advance to Port 2 Output.

2.3.8. PROGRAMMING THE PORT 2 OUTPUT TYPE

1. **Output** displays, followed by the current output type setting:
 - **Auto** - Activated by stable weight above 10d, reset by return to half of printed weight.
 - **Contin** - Continuous Output. Once every display update rate.
 - **Poll** - Demand Output by receipt of CR from external source.
 - **r Disp** – 1600 Series Remote Display output format
 - **P Ship** - Used for FedEx Shipping Software
 - **UPS** - Used for UPS Shipping Software
 - **OFF** - output is not active.
2. Press **MENU** key to edit, or **RIGHT ARROW KEY** to skip.
 - Press the **RIGHT ARROW KEY** to scroll through available settings.
 - Press **ENTER** to select an option.
3. When complete, the program will advance to Port 2 baud rate.

2.3.9. PROGRAMMING PORT 2 BAUD RATE

1. **Baud 2** displays, followed by the current baud rate setting.
 - 2400
 - 4800
 - 9600
 - 19200
 - 38400
 - 57600
 - 115200
2. Press **MENU** key to edit, or **RIGHT ARROW KEY** to skip.
 - Press the **RIGHT ARROW KEY** to scroll through available settings.
 - Press **ENTER** to select an option.
3. When complete, the program will advance to Port 2 Data Bits.

2.3.10. PROGRAMMING PORT 2 DATA BITS

1. **d-bits** displays, followed by the current data bits setting:
 - 8
 - 7
2. Press **MENU** key to edit, or **RIGHT ARROW KEY** to skip.
 - Press the **RIGHT ARROW KEY** to scroll through available settings.
 - Press **ENTER** to select an option.
3. When complete, the program will advance to Port 2 Parity Setting.

2.3.11. PROGRAMMING PORT 2 PARITY SETTING

1. **Parity** displays, followed by the current parity bit setting:
 - **P None** – no parity bit
 - **P Odd** - odd parity bit
 - **P Even** – even parity bit
2. Press **MENU** key to edit, or **RIGHT ARROW KEY** to skip.
 - Press the **RIGHT ARROW KEY** to scroll through available settings.
 - Press **ENTER** to select an option.
3. When complete, the program will advance to Port 2 stop bits.

2.3.12. PROGRAMMING PORT 2 STOP BITS

1. **Stop** displays, followed by the current stop bits setting:
 - 1
 - 2
2. Press **MENU** key to edit, or **RIGHT ARROW KEY** to skip.
 - Press the **RIGHT ARROW KEY** to scroll through available settings.
 - Press **ENTER** to select an option.
3. When complete, the program will advance to Back light options.

2.3.13. PROGRAMMING THE BACK LIGHT OPTIONS

1. The current setting displays:
 - **bL On** - Back light always **ON**.
 - **bL POS** - Back light only on with a positive weight on the scale, otherwise off.
 - **bL tr1** - Back light **ON** with a positive weight on the scale until weight has been stable for the amount of time selected at the following program step.
 - **bL tr2** - Back light **ON** with a positive weight until returned to zero and stable for the amount of time selected at the following program step.
 - **bL OFF** - Back light always **OFF**.
2. Press **MENU** key to edit, or **RIGHT ARROW KEY** to skip.
 - Press the **RIGHT ARROW KEY** to scroll through available settings.
 - Press **ENTER** to select an option.
3. When complete, the program will advance to Back light timing.

2.3.14. PROGRAMMING THE BACK LIGHT TIMING


1. The current setting displays:
 - **bLt 15** - back light remains illuminated 15 seconds
 - **bLt 30** - back light remains illuminated 30 seconds
 - **bLt 60** - back light remains illuminated 60 seconds
 - **bLt 300** - back light remains illuminated 300 seconds
2. Press **MENU** key to edit, or **RIGHT ARROW KEY** to skip.
 - Press the **RIGHT ARROW KEY** to scroll through available settings.
 - Press **ENTER** to select an option.
3. When complete, the program will advance to Configuration Menu.

2.4. Gross, Tare and Net Weight

There are three terms used when weighing an object's or load's amount.

The **NET WEIGHT** (*product only*) is the **GROSS WEIGHT** (total amount) minus the **TARE WEIGHT** (*container only*).

$$\text{NET WEIGHT} = \text{Gross Weight} - \text{Tare Weight}$$



WORKING EXAMPLE

A full can of house paint is an object to be weighed. The empty can is the **TARE** weight. The paint is the **NET** weight. Together they equal the **GROSS** weight.

2.5. Basic Weighing

*Follow these steps for **Basic Weighing**.*

1. Empty the platform.
2. Turn the scale **ON**.
3. Press **ZERO**.
 - When the display indicates “0”, it is ready for use.

2.6. Gross Weighing

*Follow these steps for **Gross Weighing**.*

1. Unload the Scale.
2. Press the **ZERO** key, if required, to set scale to “0”.
3. Place container/object on scale.
4. Read the **Gross Weight** on the display.

2.7. Net Weighing with AutoTare

*Follow these steps for **Net Weighing**.*

1. Unload the Scale.
2. Press the **ZERO** key, if required, to set scale to “0”.
3. Place container/object on scale (Tare weight).
4. Press the **TARE** key.
5. Place material in container or add objects (Net weight).
6. Read the **Net Weight** on the display. The caret (v) above the printed NET legend of the display will be seen.

2.8. Net Weighing with Manual Tare Entry

1. Place container/object on scale.
2. From the Gross Weighing Mode, key in the desired tare weight using 0-9 keys.
3. Press the **ENTER** key.
4. The instrument changes to the Net Weighing Mode (Note: the caret (v) above the printed NET legend of the display will be seen.)
The net weight displays
5. Press the **GROSS/NET** key to toggle back and forth between **Gross** and **Net** weight.

2.9. Weight Accumulation

NOTE: For the following operations to function:
The Accumulator parameter “ACC” must be configured during initial installation.
When using PC25X utility program, Operating Mode must be set to “*Accumulation*”
(See Section 6.5). Place a weight on the Scale Platform.

2.9.1 GROSS WEIGHT ACCUMULATION

1. Unload the Scale.
2. Press the **ZERO** key, if required, to set scale to “0”.
3. Place a weight on the Scale Platform.
4. After the weight is stable, press the **B/G NET** key. The display alternates between the number of Accumulations “n” and the total Gross weight Accumulated.
 - The caret (v) above the printed *Total Weight Accumulated* legend of the display will be seen.
5. Press the **UNITS** key to accept the weight, display will momentarily indicate “**ACCEPT**”, and return to the weigh screen.


OR

Press the **B/G NET** key to skip and return to the weigh screen.

At this point pressing the Print key will output the following, assuming you have CNT GR, CNT NT, GR Acc and NT ACC enabled to print: (See Section [6.7: First time connection using the PC225X PC Utility and FB225X Ethernet TCP/IP option](#) for further instructions).

6. The scale must return to “0” **Gross Mode** before another accumulation can occur.
7. Repeat steps 3 through 6 for additional accumulations.

Here you see a sample ticket with 4 gross accumulations stored.



2.9.2 NET WEIGHT ACCUMULATION

1. Unload the Scale.
2. Press the **ZERO** key, if required, to set scale to “0”.
3. Place container/object on scale.
4. Press the **TARE** key.
5. Place material in container or add objects.
6. After the weight is stable, press the **B/G NET** key. The display alternates between the number of Accumulations “n” and the total Net weight Accumulated.
 - The caret (v) above the printed *Total Weight Accumulated* and *NET* legends of the display will be seen.
7. Press the **UNITS** key to accept the weight, display will momentarily indicate “ACCEPT”, and return to the weigh screen.

OR,

Press the **B/G NET** key to skip and return to the weigh screen.

At this point pressing the Print key will output the following, assuming you have CNT GR, CNT NT, GR Acc and NT ACC enabled to print: (See [Section 6.7: First time connection using the PC225X PC Utility and FB225X Ethernet TCP/IP option](#) for further instructions)

```

0 Items GR
  0.0 lb  GR Total

1 Items NT
  833.3 lb  NT Total
  
```

8. The scale must return to “0” **Gross Mode** before another accumulation can occur.
9. Repeat steps 3 through 8 for additional accumulations.

Here you see a sample ticket with 5 NET accumulations stored. Note that the Tare weight is not shown.

```

0 Items GR
  0.0 lb  GR Total

5 Items NT
  8333.5 lb  NT Total
  
```

2.9.3. GROSS AND NET WEIGHT ACCUMULATION

Gross weight and NET weight can be accumulated simultaneously in the TS255. Each Gross weight stored will be in its own register and each NET weight stored will be in its own register, completely independent from each other.

```

2 Items GR
  4166.7 lb  GR Total

6 Items NT
  9166.8 lb  NT Total
  
```

2.10. Number of Accumulations

1. Press and hold the **ZERO** key for three (3) seconds.
 - The display will alternate between the number of Gross weight Accumulations "**n**" and the total Gross weight Accumulated for thirty (30) seconds, then return to the **Weigh Mode**.
 - The caret (v) above the printed Total Weight Accumulated legend of the display will be seen.
2. Press the **B/G NET** key
 - The display will alternate between the number of Net weight Accumulations "**n**" and the total Net weight Accumulated for thirty (30) seconds, then return to the **Weigh Mode**.
 - The caret (v) above the printed Total Weight Accumulated and NET legends of the display will be seen.
3. Press the **B/G NET** key to alternate between Gross and Net accumulations or press the **UNITS** key at any time to exit immediately to the **Weigh Mode**.

2.11. Clearing the Accumulators

The Accumulator(s) to be cleared depend on whether the **Operating Mode** is programmed to **Accumulation**, **Peak Weight**, or **Piece Count and Total**.

- Press and hold the **BG/NET** key for three (3) seconds.
- **SLP.OFF** is displayed, press the right arrow key.
- **CLr.Acc** is displayed, press the MENU key,
- **CLr.YES** is displayed, press the left or right arrow keys to toggle between **Yes** or **No**.
 - **CLr.YES** (Clear the Accumulator)
 - **CLr.NO** (Do NOT Clear the Accumulator)
- Press the ENTER key to enter the selection.
- When complete, the FB2255 will return to the weight mode.

2.12. Piece Counting

NOTE: For the following operation to function:

- The Piece Count parameter "PCt", the Accumulator parameter "ACC", and the Peak Hold parameter "P-Hold" must be configured during initial installation.
- When using PC25X utility program, Operating Mode must be set to "*Piece Count*" (See Section 6.5).

1. Unload the Scale.
2. Press the **ZERO** key, if required, to set scale to "**0**".
3. Place the empty weighing container on the Scale Platform.
4. Press the **TARE** key.
 - This stores the container weight only, placing the scale in the **Net Mode**.
 - "**0**" should display on the instrument and the caret (v) above the printed NET legend of the display will be seen.
5. Press the **B/G NET** key.
 - The Display prompts to "**Add 1**" number of sample parts to the container.
6. Pressing the **B/G NET** key repeatedly will prompt the user to;
 - "**Add 1**", "**Add 5**", "**Add 10**", "**Add 25**", "**Add 50**", or "**Add 100**" sample pieces.
7. Add the required sample pieces to the container, then press the **UNITS** key.
 - The Display will alternate between indicating the net weight and the number of sample pieces.

8. Continue to add the remaining pieces to the container.
 - The display will update and continue to alternate between the net **Weight** and **Number of Pieces**, including the original sample.
9. To Exit to the NET Weigh Mode, press the **B/G NET** key.
 - When in the NET Weigh Mode, if the **ZERO** key is held for 3 seconds, the number of pieces on the scale (with container) at the time the key is pressed will be displayed for 30 seconds, or until the **UNITS** key is pressed.

2.13. Piece Count and Total

NOTE: For the following operation to function:

- The Piece Count parameter “PCt”, the Accumulator parameter “ACC”, and the Peak Hold parameter “P-Hold” must be configured during initial installation.
- When using PC25X utility program, Operating Mode must be set to “*Piece Count and Total*” (See Section 6.5).

This feature enables the TS25X to display the Count and **Net Weight** of the counted items, and to display the Total Count of accumulated items.

1. Unload the Scale.
2. Press the **ZERO** key, if required, to set scale to “0”.
3. Place the empty weighing container on the Scale Platform.
4. Press the **TARE** key.
 - This stores the container weight only, placing the scale in the **Net Mode**.
 - “0” should display on the instrument and the caret (v) above the printed NET legend of the display will be seen.
5. Press the **B/G NET** key.
 - The Display prompts to “**Add 1**” number of sample parts to the container.
6. Pressing the **B/G NET** key repeatedly will prompt the user to;
 - “**Add 1**”, “**Add 5**”, “**Add 10**”, “**Add 25**”, “**Add 50**”, or “**Add 100**” sample pieces.
7. Add the required sample to the container, then press the **UNITS** key.
 - The Display alternates between indicating the net weight and the number of sample pieces.
8. Continue to add the remaining pieces to the container.
 - The display will update and continue to alternate between the net **Weight** and **Number of Pieces**, including the original sample.
9. Press the **B/G NET** key.
 - The Display will alternate between the “**Total**” legend and the total **Number of Pieces Accumulated** plus the current **number of pieces**.

- Press the **B/G NET** key to return to step 6.
10. Press the **UNITS** key to save the new Total in the accumulator and return to the **NET Weigh Mode**.
- To continue adding to the Total, repeat steps 1-10.
 - To reset the Total see “Clearing the Accumulators” (Section 2.11)
 - When in the NET Weigh Mode, if the **ZERO** key is held for 3 seconds, the number of pieces on the scale (with container) at the time the key is pressed will be displayed for 30 seconds, or until the **UNITS** key is pressed.

2.14. Peak Weight


NOTE: For the following operation to function:

- Peak Hold parameter “P-Hold”, the Piece Count parameter “PCt”, and the Accumulator parameter “ACC” must be configured during initial installation.
 - When using PC25X utility program, Operating Mode must be set to “*PEAK HOLD STABLE*” or “*PEAK HOLD UNSTABLE*.” (See Section 6.5).
-

The **Peak Weight** feature records the heaviest stable or unstable load placed on the scale, and the time and date it occurred. To display the current Peak Weight perform the following:

1. Press and hold the **ZERO** key for three (3) seconds.
 - The display will show the **time** and then alternate between the **date** and **Peak Weight Value**, for thirty (30) seconds, then return to the **Weigh Mode**.
2. Press the **UNITS** key to end the process and immediately exit to the **Weigh Mode**.
 - To reset the Peak Weight value see “Clearing the Accumulators” (Section 2.11)

Section 3: Serial Communication Wiring



3.1. JP3 Jumper Configuration)

JP3	RS232	RS485	RS422*	PORT
1-2	Out	120 Ohm Resistor	120 Ohm Resistor	COM1
3-4	Out	In	Out	COM1
5-6	Out	In	Out	COM1
7-8	Out	In	Out	COM2
9-10	Out	In	Out	COM2
11-12	Out	120 Ohm Resistor	120 Ohm Resistor	COM2

*Port should be set to RS485.

NOTE: 120 ohm Termination Resistors are required if the receiver is the last node on the network.

3.2. TB4 Wiring connections, COM1 (A), COM2 (B), and COM2 (C)

TB4 (A)	RS232		RS485	RS422*	PORT
1	Rx – Receive Data		(–) RS485	RS422 (–) Rx	COM1
2	Tx – Transmit Data		(–) RS485	RS422 (–) Tx	COM1
3	CTS – Clear-to-Send		(+) RS485	RS422 (+) RX	COM1
4	GND -- Ground		GND	GND	COM1
5	RTS – Ready-to-Send		(+) RS485	RS422 (+) Tx	COM1
TB4 (B)	RS232	DB9 ABS ONLY	RS485	RS422*	PORT
1	Rx – Receive Data	2	(–) RS485	RS422 (–) Rx	COM2
2	TX – Transmit Data	3	(–) RS485	RS422 (–) Tx	COM2
3	CTS – Clear-to-Send	8	(+) RS485	RS422 (+) Rx	COM2
4	GND – Ground	5	GND	GND	COM2
5	RTS – Ready-to-Send	7	RS485	RS422 (+) Tx	COM2
TB4 (C)	20 MA		RS485	RS422	PORT
1	(+) TX – Remote Display Passive, 20 mA Output				COM2
2	(–) TX – Remote Display Passive, 20 mA Output				COM2
3		(+) 7.5V Bluetooth® Technology Supply			

*Port should be set to RS485.

3.3. TB5 Remote Switch Inputs

1	Ground	
2	Ground	
3	Ground	
4	Print	Connect to ground to perform programmed Print function
5	Tare	Connect to ground to Tare off Gross weight
6	B/G Net	Connect to ground to Select Gross/Tare displays
7	Zero	Connect to ground to Zero Platform Weight
8	Units	Connect to ground to change to alternate weight units

3.4. Remote Display Active Keys



INSTRUMENT	TS255 ACTIVE FRONT PANEL KEYS
TS255	Units, Zero, Gross Net, Auto Tare, Print *
IT-2000	No Active Keys
IS-3000	No Active Keys

* The “master” **TS255** must have the printer on COM 1 and COM 1 must be configured for **Button**. COM 2 of the “master **TS25X** must be configured for **Poll** and the **TS25X** acting as the remote display must be connected to COM 2 of the “master”.

Section 4: Input / Output

4.1. 3550 Tape Printer


Transmission	RS232
Baud Rate	9600
Data Bits	8
Stop Bit	1
OUTPUT	"BUTTON" for Print Key




4.2. TM-U220 Tape Printer

This is the TM-U220 Tape Printer (non-DAT, white case).

Transmission	RS232
Baud Rate	9600
Data Bits	8
Stop Bit	1
OUTPUT	"BUTTON" for Print Key



Bottom of TM-U220 Tape Printer




DS1	ON/OFF
1	OFF
2	OFF
3	OFF
4	OFF
5	OFF
6	OFF
7	OFF
8	OFF

DS2	ON/OFF
1	OFF
2	OFF
3	OFF
4	OFF
5	OFF
6	OFF
7	OFF
8	OFF

4.3. Okidata 186 T Form Printer

Transmission	RS232
Baud Rate	9600
Data Bits	8
Stop Bit	1
OUTPUT	"BUTTON" for Print Key

Switch 7 (SW2)	DTR Signal
** Space after power on	ON
Space when printer is selected	OFF
Switch 8 (SW2)	Not Used



Follow these steps to change **Menu Settings**.

- To enter MENU MODE, press and hold **SELECT** while turning on the printer.
 - The "12" and "UTILITY" LEDs will blink.
- With the printer in the **Menu Mode**, press **SELECT** to print the complete menu.
 - The current default settings print out.
 - It is recommended to use tractor fed paper.

NOTE: The Printed Menu selections are different for each **Emulation Mode**.

- Press **LINE FEED** to select the relevant group to be changed.
 - The group is the left-hand column on the **Menu Printout**.
- Press **FORM FEED** to select the relevant item within the selected group.
 - The Item is the center column on the **Menu Printout**.
- Press **TOF SET** to cycle through the settings available for the item to change.
 - The settings are the right-hand column on the **Menu Printout**.

4.3. Okidata 186 Form Printer, Continued

6. To continue making changes: press **LINE FEED** for the next group or press **FORM FEED** for the next item.
 - Repeat as needed until finished changing settings.
7. Press **PITCH** and **MODE** together to save the changes and exit the **Menu Mode**.

NOTE: Exiting the **Menu Mode** by turning off the printer will cancel any changed settings.

- Printed menu's changes according to the **Printer Emulation Mode**.
- If printer emulation mode is not set to **ML**, set this first, then reprint the menu.

GROUP (Press LINE FEED to change)	ITEM (Press FORM FEED to change)	SET (Press TOF SET to change)
Printer Control	Emulation Mode	ML
Font	Print Mode	Utility
Font	DRAFT Mode	SSD
Font	Pitch	10 CPI
Font	Proportional Spacing	No
Font	Style	Normal
Font	Size	Single
Symbol Sets	Character Set	Standard
Symbol Sets	Language Set	American
Symbol Sets	Zero Character	Slashed
Symbol Sets	Code Page	USA
Vertical Control	Line Spacing	6 LPI
Vertical Control	Skip Over Perforation	No
Vertical Control	Page Length	11"
Set-Up	Graphics	Bi-directional
Set-Up	7 or 8 Bits Graphics	7
Set-Up	Receive Buffer Size	128K
Set-Up	Paper Out Override	No
Set-Up	Paper Registration	0
Set-Up	7 or 8 Bits Data Word	8
Set-Up	Operator Panel Function	Full Operation
Set-Up	Reset Inhibit	No
Set-Up	Print Suppress Effective	Yes

4.3. Okidata 186 Form Printer, Continued

Set-Up	Auto LF	No
Set-Up	Print DEL Code	Yes
Set-Up	Time Out Print	Invalid
Set-Up	Auto Select	No
Set-Up	Impact Mode	Normal

GROUP	ITEM	SET
Parallel I/F	I-Prime	Buffer Print
Parallel I/F	Pin 18	+5v
Parallel I/F	Bi-Direction	Enable

Serial PCB Assy Switch Settings: (SW1) (** indicates typical Thurman setting)

Parity Type **Switch 1 (SW1)**

** Odd parity	ON
Even parity	OFF

Parity **Switch 2 (SW1)**

** No parity	ON
With parity	OFF
Data Bits	Switch 3 (SW1)
** 8 Bits	ON
7 Bits	OFF

Protocol **Switch 4 (SW1)**

Ready/Busy	ON
** X-ON, X-OFF	OFF

Test Select **Switch 5 (SW1)**

** Circuit	ON
Monitor	OFF
Mode Select	Switch 6 (SW1)
** Print mode	ON
Test mode	OFF

Busy Line Selection **Switch 7, 8 (SW1)**

SSD- Pin 11	OFF, ON
-------------	---------

4.3. Okidata 186 Form Printer, Continued

SSD+ Pin 11	OFF, OFF
** DTR- Pin 20	ON, ON
RTS- Pin 4	ON, OFF

(SW2) (** indicates typical Thurman setting)

<u>Transmission Speed</u>	<u>Switches 1, 2, 3 (SW2)</u>
19,200 bps	ON, ON, ON
** 9,600 bps	OFF, ON, ON
4,800 bps	ON, OFF, ON
2,400 bps	OFF, OFF, ON
1,200 bps	ON, ON, OFF
600 bps	OFF, ON, OFF
300 bps	ON, OFF, OFF
110 bps	OFF, OFF, OFF


<u>DSR Input Signal</u>	<u>Switch 4 (SW2)</u>
Active	ON
** Inactive	OFF
Buffer Threshold	Switch 5 (SW2)
32 bytes	ON
** 256 bytes	OFF

<u>Busy Signal Timing</u>	<u>Switch 6 (SW2)</u>
** 200 ms minimum	ON
1 second minimum	OFF

4.4. Okidata 420 Form Printer

Program the TS255 the following settings.

Transmission	RS232
Baud Rate	9600
Data Bits	8
Stop Bit	1
OUTPUT	"BUTTON" for Print Key



NOTE: Always *restart the printer* after making any switch changes.

SEL						
SEL		LF	FF/LOAD	TEAR	PARK	QUIET
MENU	SHIFT	Micro Feed Down	Micro Feed Up			TOF
EXIT		GROUP	ITEM	SET	PRINT	
POWER	ALARM		MENU			

- To enter **MENU MODE**, press and hold the **SHIFT** key while pressing the **SELECT** key.
 - The **MENU** legend will be illuminated while in the Menu Mode.
- With the printer in the **Menu Mode**, press **PRINT** to print the complete menu.
 - The current default settings print out.
 - It is recommended to use tractor fed paper.

NOTE: The **Printed Menu selections** are different for each **Emulation Mode**.

- Press **GROUP** to select the relevant group that needs to be changed.
 - Found on the left-hand column on the **Menu Printout**.
- Press **ITEM** to select the relevant item within the selected group.
 - Found on the Item is the center column on the **Menu Printout**.
- Press **SET** to cycle through the settings available for the item to change.
 - The settings are the right-hand column on the **Menu Printout**.
- Press and hold the **SHIFT** key while pressing the **SELECT** key to exit the **Menu Mode**.

4.4. Okidata 420 Form Printer, Continued

NOTE: If the printer is turned off before exiting the **MENU MODE**, all changes will be lost.

GROUP	ITEM	SET
(Press LINE FEED to change)	(Press FORM FEED to change)	(Press TOF SET to change)
Printer Control	Emulation Mode	IBM PPR
Font	Print Mode	Utility
Font	DRAFT Mode	HSD
Font	Pitch	10 CPI
Font	Proportional Spacing	No
Font	Style	Normal
Font	Size	Single
Symbol Sets	Character Set	Set 1
Symbol Sets	Language Set	American
Symbol Sets	Zero Character	Slashed
Symbol Sets	Code Page	USA
Rear Feed	Line Spacing	6 LPI
Rear Feed	Form Tear-off	Off
Rear Feed	Skip Over Perforation	No
Rear Feed	Page Length	11"
Bottom Feed	Line Spacing	6 LPI
Bottom Feed	Form Tear-off	Off
Bottom Feed	Skip Over Perforation	No
Bottom Feed	Page Length	11"
Top Feed	Line Spacing	6 LPI
Top Feed	Form Tear-off	Off
Top Feed	Skip Over Perforation	No
Top Feed	Page Length	11"

4.4. Okidata 420 Form Printer, Continued

GROUP	ITEM	SET
Set-Up	Graphics	Uni-directional
Set-Up	Receive Buffer Size	64K
Set-Up	Paper Out Override	No
Set-Up	Print Registration	0
Set-Up	Operator Panel Function	Full Operation
Set-Up	Reset Inhibit	No
Set-Up	Print Suppress Effective	Yes
Set-Up	Auto LF	No
Set-Up	Auto Select	No
Set-Up	SI Select Pitch (10CP)	17.1 CPI
Set-Up	SI Select Pitch (12CPI)	12 CPI
Set-Up	Time Out Print	valid
Set-Up	Auto Select	No
Set-Up	Centering Position	DEFAULT
Set-Up	ESC SI Pitch	17.1 CPI
Set-Up	Power Saving	Enable
Set-Up	Power Save Time	5 Min
Parallel I/F	I-Prime	Buffer Print
Parallel I/F	Pin 18	+5v
Parallel I/F	Bi-Direction	Enable
Serial I/F	Parity	None
Serial I/F	Serial Data 7/8 Bits	8 Bits
Serial I/F	Protocol	X-On/X-Off
Serial I/F	Diagnostic Test	No
Serial I/F	Busy Line	SSD-
Serial I/F	Baud Rate	9600 BPS
Serial I/F	DSR Signal	Invalid
Serial I/F	DTR Signal	Ready on Pwr up
Serial I/F	Busy Time	200 ms


4.5. TM-U295 Ticket Printer

Transmission	RS232
Baud Rate	9600
Data Bits	8
Stop Bit	1
OUTPUT	"BUTTON" for Print Key

Set the dip switches to the following.

- 1 and 3 are **ON**.
- The rest are **OFF**.

NOTE: Always restart the printer after making any switch changes.




4.6. TM-U590 Ticket Printer


Transmission	RS232
Baud Rate	9600
Data Bits	8
Stop Bit	1
OUTPUT	"BUTTON" for Print Key

Set the dip switches to the following.

- DSW 1
- DSW 2
- 1, 3 and 7 are **ON** only.
- All are **OFF**.



4.7. Remote Display



Using the **20 mA Serial Current Loop Output** will allow transmission distances up to **1000 cable feet**.

- **Interface Cable (20903)** is recommended.


	Port 2
Protocol	C-Loop
Baud Rate	9600
Data Bits	8
Parity	None
Stop Bit	1
Output Type	rDisp

The 218 Series remote display must be wired for **20 mA Active**, and programmed to match the TS255.

- Wiring to the TS255: **TB4 (C)** to the **Remote Display** (see section 4.6).

1	Tx + Passive 20 mA Output
2	Tx – Passive 20 mA Output

Wire the 218/217 Series **Remote Display** to the TS255 as shown in this diagram.





4.8. 4-20mA Analog Output Setup

Access to this feature is conditional, and depends upon whether it is enabled in the **FB2255 Internal Programming**.

The 4-20mA analog output is passive, so therefore it requires the receiving element to supply the loop with a dedicated, isolated power source from 7-24V DC. The output is linear throughout the range from 4mA to 20mA, and can be programmed to increase (upweigh) or decrease (downweigh) as weight is increased.

Connections are as follows:

Pin 1	+ 4-20mA
Pin 2	- 4-20mA



1. Press and hold the **UNITS** key for three (3) seconds

NOTE: *If 4-20mA Analog Output has been installed and programmed, setting 4-20 to **NO** in the APPS Menu will prevent access to it from the front panel while the analog output continues to operate.*

2. Select **GROSS** or **NET**.
 - The **4-20 mA Analog Output** will continue to track the selection regardless of the currently selected Weigh Mode.
3. Press **MENU**.
4. Press the **right arrow** key to toggle the available settings.
5. Press **ENTER** to select an option.

Available selections include the following.

- **Gross**
- **Net**

4.8.1. PROGRAMMING THE 4mA WEIGHT VALUE

4.20 Lo displays, followed by the current setting.

1. Key in the desired **Weight Value** with the **0-9** keys.
2. Press **ENTER**.

*This weight value will result in a **4mA Output**.*

3. When complete, the program will advance to the 20mA menu.

4.8.2. PROGRAMMING THE 20mA WEIGHT VALUE

4.20 Hi displays, followed by the current setting.

1. Key in the desired **Weight Value** with the **0-9** keys.
2. Press **ENTER**.

*This weight value will result in a **20mA Output***

3. When complete, the TS255 will return to weigh mode.

Section 5: Fieldbus/Bluetooth

5.1. Fieldbus Installation

Fieldbus is a general term that describes an all-digital two-way communications system that interconnects measurement and control equipment such as sensors, actuators and controllers.

- Fieldbus traces its beginnings in the automotive industry, where efforts to simplify and reduce wiring resulted in a multiplexed **Controller Area Network (CAN)** system of modules installed at various points of a car

For example, many cars have multiple controls on the door, such as power-window, power-mirror, power-lock and power-seat controls.

- To eliminate the thick bundle of wires of the older method, a driver's-door module monitors all of the switches.
- If the driver presses the window switch, the door module closes a relay that provides power to the window motor.
- If the driver presses the switch to adjust the passenger-side mirror, the driver's door module sends a packet of data onto the communication bus of the car.
- This packet tells a different module to energize one of the power-mirror motors. In this way, most of the signals that leave the driver's door are consolidated onto the two wires that form the communication bus.

As time has progressed, many different Fieldbus types have been developed, each with different characteristics and specifications.

- Very simply, they serve as a **Local Area Network (LAN)** for instrumentation used in automatic process control and manufacturing applications.
- The LAN is a digital, bi-directional, multi-drop, serial-bus communications network used to link field devices (often referred to as “Nodes”), such as controllers, transducers, actuators and sensors.

There are a number of different manufacturers that produce Fieldbus devices.

- Each produces different hardware interfaces, wiring and connector types, speed, and the amount of bytes of data that can be exchanged on the network, among other things.

Additionally, the current Fieldbus communications network is replacing the older 4-20mA Analog Signal.

- The older 4-20 mA analog signal requires each device to have its own set of wires and its own connection points.
- A Fieldbus eliminates this need as, generally, twisted pair wiring is used.
- All devices on the network are now connected together.

Thurman Scales currently offers five different Fieldbus Devices: **DeviceNet™**, **ControlNet™**, **PROFIBUS®-DP**, **Modbus®** and **Ethernet/IP**.


For more information and EDS files, see <http://www.hms.se/default.shtml>.

5.2. Fieldbus Connections

The term **FIELDBUS** usually describes an all-digital two-way communications system that interconnects measurement and control equipment such as sensors, actuators and controllers.

The **Fieldbus** assembly connects to the 32-pin header on the **TS255** main PCB Assembly.

It is provided with **two (2) standoffs** which support the right side of the card.



5.2.1. OVERVIEW OF TERMS

There are currently **four (4) different of Fieldbus Interfaces** listed as standard accessories for the **TS255** Instrument.

- **DEVICENET™ (29578)**
 - A network system to interconnect control devices for data exchange.
 - It uses a differential serial bus, called **Controller Area Network (CAN)**, as the backbone technology and defines an application layer to cover a range of device profiles.
- **CONTROLNET™ (31979)**
 - An open control network in real-time, for high-throughput applications.


5.2.1. OVERVIEW OF TERMS, CONTINUED

- **PROFIBUS®-DP (29576)**
 - Non-powered two-wire (RS485) network, with **up to 126 nodes**, transferring a maximum of 244 data bytes per node per cycle.
- **MODBUS®-TCP (34032)**
 - Serial network communications in a master/slave (request/response) type relationship using either ASCII or RTU (Remote Terminal Unit) modes.
 - Non-powered two-wire (RS485) network, with **up to 126 nodes**, transferring a maximum of 244 data bytes per node per cycle.
- **ETHERNET/IP (29873)**
 - **Dynamic Host Configuration Protocol (DHCP)** is used for address requests.
 - The data is transmitted continuously from this module.
 - The IP address may be made static by downloading the **IP Configuration Tool Software**.

ETHERNET/IP can be easily confused as a simple combination of EtherNet and the Internet Protocol. Instead, it is an **Industrial Application Layer Protocol** used for communication between industrial control systems and their components.

- Such components include Programmable Automation Controller, Logic Controller, or an I/O System.

The “IP” in EtherNet/IP is not an abbreviation for “Internet Protocol”, but instead, it stands for “**Industrial Protocol**”.



5.2.2. DEVICENET™(29578)

DEVICENET is a low-cost communications link that connects industrial devices to a network, eliminating expensive hardwiring.

- It is based on a broadcast-oriented, communications protocol the **CAN**.
- The **CAN Protocol** was originally developed by BOSCH for the European automotive market for replacing expensive wire harnesses with low-cost network cable.
- The **CAN Protocol** has fast response and high reliability for applications like anti-lock brakes and air bags.

DEVICENET™ also provides power to the network. This allows devices with limited power requirements to be powered directly from the network.

- This reduces connection points and physical size.
- The maximum network size is **up to 64 Nodes**, with message data packets **up to 8 bytes**.

Wire	SIGNAL	DESCRIPTION
1	V	Negative bus supply voltage
2	CAN_L	CAN low bus line
3	SHIELD	Cable shield
4	CAN_H	CAN high bus line
5	V+	Positive bus supply voltage




Additional information available for DeviceNet™ information and EDS files:
<http://www.anybus.com/support/support.asp?PID=324&ProductType=Anybus-CompactCom>

5.2.2. DEVICENET™ (29578), CONTINUED

NETWORK STATUS LED

STATE	INDICATION
OFF	Not online/ No power
GREEN	Online, one or more connection established
FLASHING GREEN (1 Hz)	Online, no corrections established
Red	Critical link failure
Flashing Red (1 Hz)	One or more connections timed out
Alternating Red/Green	Self-test



MODULE STATUS LED

STATE	INDICATION
OFF	No power
GREEN	Operating in normal condition
FLASHING GREEN (1 Hz)	Missing/Incomplete configuration/ Device needs commissioning
Red	Unrecoverable fault(s)
Flashing Red (1 Hz)	Recoverable fault(s)
Alternating Red/Green	Self-test

5.2.3. CONTROLNET™ (31979)

CONTROLNET™ is an open control network running in “real-time”, for high-throughput applications.

- It uses a **Control and Information Protocol (CIP)**, combining the functionality of an I/O Network and a Peer-to-Peer Network.
- **CONTROLNET** is based on the **Producer/Consumer Model**, permitting all nodes on the network to simultaneously access the same data from a single source.
- Maximum of **99 nodes**, with no minimum distance between nodes
- The Control net card uses BNC connectors.




SPECIAL NOTES

For **signal redundancy**, both connectors should be used.

- If not, use either **Connector A** or **B**.

Network Status LED A and **Module Status LED** correspond to **LED 1** and **LED 2** in the instance attributes of the **Anybus Object**.

- They are available in the application interface, but the LED placement on the front does not conform to the standard **Anybus CompactCom** placement of **LED 1** and **LED 2**.



Additional information available for ControlNet Information and EDS files:

<http://www.anybus.com/support/support.asp?PID=427&ProductType=Anybus-CompactCom>

5.2.3. CONTROLNET™ (31979), CONTINUED


NETWORK STATUS

LED	STATE	INDICATION
A and B	OFF	Not online / No power
	Flashing Red (1 Hz)	Incorrect node configuration, duplicate MAC ID etc.
	Alternating Red/Green	Self test of bus controller
	Red	Fatal event or faulty unit
A or B	OFF	Channel is disabled
	Alternating Red/Green	Invalid link configuration
	Flashing Green (1 Hz)	Temporary errors (node self-corrects) or node is not configured to go online.
	Green	Normal operation
	Flashing Red (1 Hz)	Media fault or no other nodes on the Network

MODULE STATUS

STATE	INDICATION
OFF	No power
GREEN	Operating in normal condition, controlled by a Scanner in RUN state.
FLASHING GREEN (1 Hz)	The module has not been configured or the Scanner is in the Idle state.
Red	Unrecoverable fault(s), EXCEPTION,
Flashing Red (1 Hz)	Media fault or no other nodes on the Network

No.	DESCRIPTION
1	Network Status LED A
2	Module Status LED
3	Network Status LED B
4	ControlNet™ Connector A
5	ControlNet™ Connector B



5.2.4. PROFIBUS®-DP (29576)


PROFIBUS®-DP is one of the best-known industrial fieldBus protocols from Europe.

- It is an established standard, used in a wide range of applications as a multi-application communications link for industrial devices.
- The ProfiBus protocol was originally developed by a committee founded by the German government.



PROFIBUS®-DP utilizes a **non-powered two-wire (RS-485) Network**.

- A ProfiBus Network may have **up to 126 nodes**, transferring a maximum of **244 bytes data per node/ per cycle**.
- Baud (Communication) Rates are selectable, and overall end-to-end network distance varies with speed.
- The maximum standard Baud Rate is **12Mbps**, with a maximum distance of **100M (328ft)**, and **1200M (3936 ft.)** at **93.75Kbps** without repeaters.
- **PROFIBUS®-DP** connects to a wide variety of field devices including the following:
 - Discrete and analog I/O Drives.
 - Robots.
 - HMI/MMI products.
 - Pneumatic valves.
 - Barcode readers.
 - Weigh scales.
 - Transducers.
 - Flow measuring equipment.



PIN	SIGNAL	DESCRIPTION
3	B-Line	Positive RxD/TxD, Rs485 level
4	RTS	Request to Send
5	GND	Ground (Isolated)
6	+5 Bus Output	+5V termination power (Isolated, short circuit protected)
8	A-Line	Negative RxD/TxD, RS485 level


5.2.4. PROFIBUS®-DP (29576), CONTINUED

OPERATION MODE LED

LED STATE	DESCRIPTION
OFF	Not online or No power
Green	Online/ Data Exchange
Flashing Green	Online, clear
Flashing Red (1 flash)	Parameterization error
Flashing Red (2 flashes)	Profibus configuration error

MODULAR STATUS LED

LED STATE	DESCRIPTION	COMMENTS
OFF	No power - OR – not initialized	Module state = “ SETUP ” OR NW-INIT ”
Green	Initialized	Module has left the NW_INIT state
Flashing Green	Initialized, diagnostic events(s) present	Extended diagnostic bit is set
Red	Exception error	Module state = EXCEPTION




NO.	DESCRIPTION
1	Communication LED
2	Device Status LED
3	Profibus® Interface

Additional information available for PROFIBUS®-DP Information and GSD files:
<http://www.anybus.com/support/support.asp?PID=321&ProductType=Anybus-CompactCom>

5.2.5 MODBUS TCP (34032)

MODBUS (34032) TCP was originally developed in 1978 to exchange information between devices on the factory floor.

- It developed into the standard for exchanging data and communication **MODULE STATUS** information between PLC systems.
- Modbus-TCP devices communicate over a **Serial Network** in a **master/slave** (request/response) type relationship.
- Uses either the **ASCII** (American Standard Code for Information Interchange) **mode** or the **RTU** (Remote Terminal Unit) **mode**.
- In the **ASCII MODE**, two eight-bit bytes of data are sent as two ASCII characters.
- The primary advantage of ASCII mode is the flexibility of the timing sequence.
- Up to a one second interval can occur between character transmissions without causing communication errors.
- In the **RTU MODE**, data is sent as two four-bit, hexadecimal characters, providing for higher throughput than in ASCII mode for the same baud rate.
- Modbus Plus communicates using a single twisted pair of wires in one shielded cable (**#18AWG**).
- Modbus Plus **does NOT** provide power on the network.
- Maximum of up to **32 Nodes**, and up to **64** with a Repeater.



NO.	DESCRIPTION
1	Communication LED
2	Device Status LED
3	Modbus Interface

COMMUNICATION LED

LED STATE	DESCRIPTION
OFF	No power - OR – no traffic
YELLOW	Frame reception or transmission
RED	A fatal error has occurred

5.2.5. MODBUS TCP (34032), CONTINUED



DEVICE STATUS LED

LED STATE	INDICATION
OFF	Initializine – OR – no power
GREEN	Module initialized, no error
RED	Internal error – OR –major unrecoverable fault
RED, SINGLE FLASH	Communication fault or configuration error Case 1: Invalid setttings in Network Configuration error Case 2: Settings in Network Configuration Object has been changed during runtime (i.e. the settings do not match the currently used configuration).
RED, DOUBLE FLASH	Application diagnostics available.

MODBUS-TCP INTERFACE

PIN	DIRECTION	SIGNAL	COMMENT
Housing	—	PE	Protective Earth
1	—	GND	Bus polarization, ground (isolated)
2	Output ³	5V	Bus polarizatio power +5V DC (isolated)
3	Input	PMC	Connect to pin #2 for RS-232 operation
4			
5	Bidirectional	B-LINE	RS-485 B-Line
6			
7	Input	RX	RS-232 Data Receive
8	Output	TX	RS-232 Data Transmit
9	Bidirectional	A-Line	RS-485 A-Line


Additional information available for Modbus®-TCP Information and GSD files:
<http://www.anybus.com/support/support.asp?PID=458&ProductType=Anybus-CompactCom>

5.2.6. ETHERNET/IP DIAGNOSTIC LEDS

The Ethernet/IP module uses Dynamic Addressing.

- **Dynamic Host Configuration Protocol (DHCP)** is used for address requests.
- The data is transmitted continuously from this module.
- The IP address may be made static by downloading the **IP Configuration Tool Software** from the following site:

<http://www.hms.se/support/support.asp?PID=368&ProductType=Anybus-CompactCom>.



- Using this download, it is possible to change the IP, Sub Net and Gateway addresses of an Ethernet/IP Module.
- To change an address, double click on the IP address field and enter the changes.

*Shown below is the **Network Status LED Chart***

STATE	DESCRIPTION
Off	Not online / No power
Green	Online, one or more connections established.
Flashing	Online, no connections established
Red	Duplicate IP address, FATAL error
Flashing Red	One or more connections timed out

*Shown below is the **Module Status LED Chart***

STATE	DESCRIPTION
Off	No power
Green	Controlled by a scanner in Run state
Flashing Green	Not configures, or Scanner in idle state
Red	Major fault (EXCEPTION-state, FATAL error, etc.)
Flashing Red	Recoverable fault(s)

*Shown below is the **Link / Activity LED Chart***

STATE	DESCRIPTION
Off	No link, no activity
Green	Link established
Flickering Green	Activity

Additional information available for Ethernet IP information and EDS files:

<http://www.anybus.com/support/support.asp?PID=368&ProductType=Anybus-CompactCom>


5.3. Bluetooth® Technology Device

The Bluetooth® Option replaces direct wiring between two devices.

- The Bluetooth® Interface uses either **Port 1** or **Port 2 Serial Output**.
- RS232 Serial Interface to Bluetooth® Interface with a range of **100 meters (328 feet)**.

The Bluetooth® Option operates either as a Client or Server, depending on its connecting device.

If connected to a printer, the **TS255** will be a **Server**. If connected to a PC, it is a **Client**.



Shown below are some Bluetooth® products with their features.

MODEL NO.	MODEL NAME	DESCRIPTION
29515	Bluetooth® Accessory, Class I , for non- TS255 device	• Power source required for non- TS255 side of the connection. • 5 - 12 VDC, USB power cable provided. • PC interfacing software provided.
29639	AC Power adapter for Bluetooth® Accessory 29215	• For use if USB power cable not applicable.
29516	Bluetooth® Accessory, Class I , TS255	• TS255 provides power • RoHS compliant • Includes cable 29402

The **Bluetooth®** device is supplied with a **DB-9 female connector**.

*Shown below is the wiring code / color code to connect the **TS255** and the **Bluetooth®** Device.*

TS255 TB4A OR TB4B	BLUETOOTH® DEVICE	TS SUPPLIED CABLE
Pin 1	Pin 2	Red
Pin 2	Pin 3	White
Pin 4	Pin 5	Black
Pin 3 ON TB4C	Pin 9	Green

5.3. Bluetooth® Technology Device, Continued


Set the **4-position Dip Switch** on each device as shown below.

1,2,3	ON
4	OFF

Baud Rate	9600
Data Bits	8
Parity	None
Stop Bit	1

Follow these steps to installing the **Bluetooth® Devices**.

1. Turn on both Bluetooth® Devices with the **SLIDE SWITCH** on their sides.
 2. Press the **RESET BUTTON** on each one.
 3. Press the **PAIRING BUTTON** of **Device #1** for two (2) seconds
 - The **Standby LED** turns **OFF**.
 - The **Connect LED** blinks three (3) times every two (2) seconds.
 - Keep the power **ON**.
 4. Press the **PAIRING BUTTON** of **Device #2** for two (2) seconds.
 - The **Standby LED** turns **OFF**.
 - The **Connect LED** blinks three (3) times every two (2) seconds.
 5. Press the **Pairing Button** again for two (2) seconds until the **Connect LED** blinks every half (½) second.
- Wait for **Devices #1** and **#2** to connect to each other.
 - The **Connect LEDs** of both will be solid green.
 - This connection process takes about ten (10) seconds.
 - If any other Bluetooth® devices are nearby, it may take longer.




5.3. Bluetooth® Technology Device, Continued

6. Turn **Device #1 OFF**, and then back **ON**.
 - The **Connect LED** light blinks green twice every three (3) seconds.
7. Turn **Device #2 OFF**, and then back **ON**.
8. The **Connect LED** light blinks green once every second.

Configuration is now complete. Both devices are configured to make automatic connection to each other whenever they are powered on.

Section 6: PC25X Utility Software



6.1. Introduction

- The PC25X utility software program can be used to set up and configure the TS255.
- It is required in order to program certain features, such as custom units and custom ticket vector programming.
- The **TS255** uses **Port 2** to communicate to the computer.

6.2. Communication Settings



1. Configure the **TS255** Port 2 as noted in Table 1 below:
 - a. Press and hold the Internal Program Switch until **SetUP** displays.
 - b. Use the Right Arrow key to scroll through each menu item until **Port 2** displays
 - c. See Sections 2.3.9 through 2.3.14 for configuration instructions.
 - d. Exit to weigh mode.

Baud Rate	9600
Data Bits	8
Parity	None
Stop Bit	1
Mode	Continuous

Table 1


2. On the PC Launch the **PC25X** Utility.
 - An image of the **TS255** will display on the computer monitor.

6.2. Communication Settings, Continued



3. Access the **COM Port Settings** of the computer by pressing **F2**.
4. Configure the Com Port connected to the **TS255** via the pop-up menu to match the settings in Table 1 above.
5. Close the pop-up menu when complete.
6. To the left side of the weight display, the legend "**CONNECTED**" with a rotating baton will be displayed.
 - The weight display will duplicate what is shown on the **TS255**.
7. Left-clicking the mouse on any key will transmit that command to the **TS255**.
 - This excludes the **PRINT** key.
 - The legend "**COMMAND SENT!**" will display at the right.
 - Mouse-clicking the **ON/OFF** key will terminate the PC25X software program.



6.3. Communication Files



The default folder for all saved/uploaded parameter files is **PC25X\SAVED**.

6.4. Menu Bar

The PC25X menu bar is located at the bottom of the display.



BUTTON	FUNCTION
NEW	Loads the Parameters Menu with TS255 default settings.
OPEN	Opens the SAVED folder to select a file.
SAVE	Saves the currently named file.
SAVE AS	Saves the current file and prompts for a file name.
UPLOAD	Uploads the current TS255 settings to the PC25X.
DOWNLOAD	Downloads the current PC25X settings to the TS255.
EXIT	Exits the program.

1. Press the **UPLOAD** button to retrieve the current TS255 settings to the PC25X.


– The **TS255** displays “PC”.

2. Press the **INTERNAL PROGRAMMING SWITCH**.




6.4. Menu Bar, Continued

3. When the process is complete, click **OK**.



4. Click the **DOWNLOAD** button to retrieve the current PC25X settings to the TS255.




The TS255 displays "PC".

5. Press the **INTERNAL PROGRAMMING SWITCH**.



6. When complete, click **OK**.

7. Press **EXIT** to close the **Parameter Editor**.



6.5. Configuration

1. Press **F4** to enter the **Parameters Editor**.

Use one of the following methods that apply to programming the features.

- Click on the data item to highlight it, then type in the replacement data.
- Click the drop down arrow and selecting an available item.
- Click on the checkmark to select the option(s).
- Input the custom unit factor to set the conversion factor of the current primary weight data.

CUSTOM UNIT PROGRAMMING EXAMPLE


To convert pounds to dry barrel units, enter the conversion factor, resolution and custom legend. The current **primary weight** will be multiplied by the **conversion factor**, rounded off to the **custom resolution** and printed with a custom legend.

6.6. Calibration

Settings from this window include the following options.

- Scale capacity
- Primary Units
- Auto Zero Tracking (AZT)
- Motion Band (BAL)
- Division Size
- Digital Filter
- Auto Tare settings

*Actual test weight calibration is performed with the **TS255** front panel keys.*




6.7 First time connection using PC25X PC Utility and TS25X Ethernet TCP/IP option.

1. With the TS255 connected to the ethernet network, launch the PC25X PC Utility from the PC on the same network as the TS255.

2. Change the interface from RS232 to TCP/IP by clicking on the button.


3. Select the PC Utility type based on the instrument you will be connecting to. Choose PC25X.

NOTE: If the ethernet card has been previously configured, skip to step 23.



4. Click F4 to open the Configuration window.


5. Select the **IP CONNECTION** Tab.



6. Click the **TCP CONFIGURATION UTILITY** button.



7. The NETEON Utility will open.



8. The default IP (10.10.50.100 or 10.0.50.100) of the ethernet device should show.

9. Highlight the IP address shown by clicking on it.

10. Select the **CONFIG** button.
A new dialog box will open.

Dialog

MAC addr.	00:60:E9:13:8F:7B	
IP address	10.10.50.100	☐ Auto IP
GateWay	10.0.0.254	
Mask	255.255.0.0	Config Now
User ID	admin	Cancel
Password		
Host Name	name	

11. Obtain network setting details from the customer's IT personnel and enter the information in the dialog box.

a. **NOTE:** AUTO IP sets the card to DHCP

12. Set the USER ID and PASSWORD

a. Default = admin with no password

13. Highlight the IP address shown by clicking on it.

14. Click the **CONFIG NOW** button to write the change to the ethernet card.

Dialog


MAC addr.	00:60:E9:13:8F:7B	
IP address	206.220.166.249	☐ Auto IP
GateWay	206.220.166.1	
Mask	255.255.255.0	Config Now
User ID	admin	Cancel
Password		
Host Name	2255_ABS	

15. Click the **BROWSER** button.




16. You will be prompted for the USER ID and PASSWORD previously entered.


17. The **OVERVIEW** window will open showing the current addresses and settings for the ethernet card.



18. If additional network configuration is required, click the **NETWORKING** link.




19. To change the PASSWORD, click the **SECURITY** link.




20. Do NOT make any changes under the COM1 link.

21. Close the browser window when you are done.


22. Click the **EXIT** button to close the configuration utility.




23. Return to the PC25X Utility and select the **IP CONNECTION** tab.
24. If the **SELECT** button is available, proceed to the next step, if it is not click on the **EDIT** button then proceed to the next step.
25. In the **CONFIGURATION** field, enter a human readable name to identify the TS255 instrument to connect to.



26. In the **HOST ADDRESS** field, enter the IP address for the TS255 being connected.
27. Default PORT NUMBER is 4660.




28. Once complete, select **UPDATE GRID**.
29. Save the PC25X Configuration file using the **SAVE AS** button.
30. Press **EXIT** to close the Configuration tool.
31. Weight should now display on the PC25X Utility.
32. The Utility will display the current IP Connect selected next to the TCP/IP button.
33. You can make Configuration changes, Upload and Download files from the PC25X Utility and the TS255 instrument.



6.8. Fieldbus

The **Anybus Module** is set up using the **PC25X Program** and configures the following parameters listed below. The TS255 will automatically detect the Anybus module installed. No additional programming is required except the following parameters if necessary. The remainder of the fieldbus configuration and programming is performed on the fieldbus network side by the customer's network personnel.



PORT 20

As part of the Ethernet IP specification, the fieldbus device uses Port 20. This port cannot be changed. This is to ensure other devices on the network are able to communicate with each other.

NODE ADDRESS

- Enter the **Node Address** of the Module.
- This is typically furnished by the customer.

BAUD RATE

- Most Anybus Modules can automatically detect the network speed by using the **Auto Baud** feature.
- Typical configurations for DeviceNet™ uses 125K bps, 250K bps or 500K bps baud rates

6.8. Fieldbus, Continued

DATA TYPE


Data can be setup to output a **32 bit Integer word** or a **32 bit floating point value**.

ENDIAN

The **Endianness** of a module is determined by the network type, but can be changed from Little Endian to Big Endian, or vice versa by using the **"CHANGE ORDER"** setting.

LITTLE ENDIAN FORMAT OR INTEL ORDER

In **Little Endian Format**, the **least significant byte** is stored first, followed by the next three more significant bytes.



For example, a **32bit value** of **0x12345678** would be stored in memory in **LITTLE ENDIAN** as shown below.

- Address + 0 0x78
- Address + 1 0x56
- Address + 2 0x34
- Address + 3 0x12

BIG ENDIAN FORMAT OR MOTOROLA ORDER

In **Big Endian Format**, the **most significant byte** is stored first, followed by the next three least significant bytes.

For example, a **32bit value** of **0x12345678** would be stored in memory in **BIG ENDIAN** as shown below.

- Address + 0 0x12
- Address + 1 0x34
- Address + 2 0x56
- Address + 3 0x78

6.8. Fieldbus, Continued

OUTPUT

Data from the **TS255** comprises of three (3) 32-bit words.

- **Gross Weight**
- **Tare Weight**
- **A 32bit Status Word**

- Gross and Tare weights can be selected as either a **32-bit Integer** or a **32-bit Floating Point Word**.
- The **Most significant Byte** indicates the Weigh Mode **"G"** for **Gross**, and **"N"** for **Net**.
- The **Next Order Byte** indicates **"O"** Overcapacity, **"M"** Motion of the last command received. (See INPUT Commands)

The next order byte indicates the weight units.

- **"l"** pounds
- **"k"** kilograms
- **"o"** ounces
- **"g"** grams.

The **Least Significant Byte** indicates the number of decimal places, if the weight output is selected to be a 32-bit Integer word.

- If a Floating point word is selected, this byte will be **"0"**.

INPUT

Single Byte Commands can be sent from the network.

- Although the input is read as a 32-bit word, only the **Least Significant Byte** is used in this process.
- When the command is sent and recognized, it is entered into the 32 -bit status byte in the **Least Significant Command Byte** location.
- New commands can be transmitted after transmitting a **NULL** command.

6.8. Fieldbus, Continued

RECOGNIZED COMMANDS


COMMAND	DESCRIPTION
Print Steam	See Custom Format PC25X.
Print Format Stream	CR, SPACE, STX, ENQ or Defined Poll Character
Tare	"A"
Print Ticket	"p" or "P"
Zero	"Z"
Change Gross Net Weight Mode	"G"
Change Units	"U"

DEBUG

- Data in the Anybus Module can be examined by clicking the **START DEBUG** button.
- It is stopped by clicking the **STOP DEBUG** button.
- The Start Debug and Stop Debug provides a verification of the TS255 communicating with the fieldbus module by sending hexadecimal values which may be observed upon pressing start and stop debug.
- The **WRITE BUFFER** contains three 32-bit words.
 - Gross Weight, Tare Weight** and the **Status Word** is the data sent to the Network.
- The Contents of the **READ BUFFER**, which is the data received from the network, is displayed as a 32-bit word.

6.9. 4-20 mA

A point-to-point or multi-drop circuit mainly used in the process automation field to transmit signals from instruments in the field to a controller. It sends an analog signal from 4 to 20 mA that represents 0 to 100% of the weight displayed at the instrument. As a current loop signal, the TS255 4-20 ma output is a passive device which requires an isolated and dedicated power supply provided by others.




6.9. 4-20 mA, Continued

Enable 4-20mA – From the drop down menu, select YES to enable the output.

Low Weight – Enter the weight value which represents the 4mA output signal.

High Weight – Enter the weight value which represents the 20mA output signal.

Mode – From the drop down menu, select weight mode which the 4-20mA will track, Gross or Net.



6.10. Custom Output – Settings

CHECKSUM


- This setting determines whether a **Checksum Character** is enabled or not.
- **Checksum** is an error detection method that checks the integrity of the entire string of data that is transmitted.

DELIMITED

This setting determines if a comma is added to the output string to separate data fields contained within the output string.

HARDWARE HAND SHAKING

No current function. Set up for future use.



6.11. Custom Output – Load


A variety of pre-packaged **Output Strings** is available.

1. Click the **radio button** that applies.

✓ **Default = Thurman**

2. Click OK to download the settings, or **Cancel**.

– See **Appendix 1: Data Output Formats**.




NOTE:

Customized Outputs use **Port 1 only**.

The power **MUST** be cycled to the TS255 Instrument whenever custom outputs are programmed in order for them to take effect.


6.12. Custom Output – Build

1. Customize the **Data Output String** to suit the application requirements.
 - The current structure of the output string is displayed at the bottom of the **Custom Output page**, in order of transmission from left-to-right.





6.12. Custom Output – Build, continued

2. Right-click in the selected **DATA TYPE** field to change data items.
 - This opens a selection window containing many different data items.



6.13. Custom Output – Tokens




1. Select from a wide variety of different characters for the polling character.
 - Start
 - Block
 - Secondary Units
 - Motion
 - Stop
 - Primary Units
 - Weighing Mode
 - Capacity Characters
2. When entering a character that is not listed, select USER DEFINED.



6.13. Custom Output – Tokens, continued

This will produce an additional data entry box as shown.


1. **Right-click** in the selected **DATA ENTRY BOX** to change data items.
2. Make a selection, such as <SOH>, for example.
 - This inserts a **Start of Header** character... otherwise known as a **CTRL/A**, or **0x01 HEX**.
3. When entering a character not listed, select **ENTRY**.
4. Select **Entry** to insert a character using the keyboard, such as an A or a 1.



6.14. Custom Output – Weights

A variety of settings are available for the **Weight Digits** window. These choices include the following.

- Weight Digits
- Leading Zeroes
- Justification
- Decimal Point
- Fixed Decimal Places
- Include Polarity (checkbox)
- Positive Token
- Negative Token



6.15. Formatting Tickets


- Formatting tickets is easily performed with this drag and drop interface.
- The blue-dashes indicate the printable area of the ticket based on the ticket size and margins entered (by the user or by default).

1. Click on the drop down arrow to select the desired ticket **Printer**.
2. Click on the drop down arrow for **INHIBIT** to select either NONE, HIGH, or LOW.
3. Enter the **Ticket Size** and **Margins** in inches.
4. Items can be removed or added from view and printing by right clicking the **VISIBLE** box under the parameter, and then selecting **NO** or **YES**.

- a. Count1 options include:
 - i. NO – not visible
 - ii. PIECE – number of pieces
 - iii. CNT GR. – Gross accumulated count
- b. Count2 options include:
 - i. NO – not visible
 - ii. PIECE – Total accumulated number of pieces
 - iii. CNT NT – NET accumulated count

Field	Time
Visible	YES
Top	6
Left	10

5. Click-and-hold on a data item in the ticket window to move it to a different location or manually change the numeric values for **TOP** and **LEFT**.



NOTE:

- Although the **Lines/inch** and **Char Width** settings are sent to the printer and stored, they are not being used at this time (possible future use).
- Legends such as **GROSS** cannot be disabled, and are **always included**.

6.16. Printed Examples

ACCUMULATION

Field		Count1	Count2	Peak Wt	GR Acc	NT Acc
Visible		CNT GR	CNT NT	NO	YES	YES
Top		14	16	0	20	22
Left		2	2	0	2	2

* See Section [2.9: Weight Accumulation](#) (in User Operations)

```

4 Items GR
 8333.4 lb GR Total

0 Items NT
 0.0 lb NT Total
  
```

Here you see a sample ticket with 4 gross accumulations stored.

```

0 Items GR
 0.0 lb GR Total

5 Items NT
 8333.5 lb NT Total
  
```

Here you see a sample ticket with 5 NET accumulations stored. Note that the Tare weight is not shown.

```

2 Items GR
 4166.7 lb GR Total

6 Items NT
 9166.8 lb NT Total
  
```

Gross weight and NET weight can be accumulated simultaneously in the FB2255. Each Gross weight stored will be in its own register and each NET weight stored will be in its own register, completely independent from each other.

PIECE COUNT

Field	Time	Date	Gross	Tare	Net	Count1	Count2
Visible	YES	YES	YES	YES	YES	Piece	Piece
Top	2	2	6	8	10	14	16
Left	2	13	7	7	7	7	7

See Section [2.12. Piece Counting](#) (in User Operation)

Container weighs 5.0 lb.

5 pieces weigh 1.0 lb

Pieces cannot be accumulated.

When **PRINT** key was pressed, 5 pieces were still on the scale.

02:04PM 02-18-14
6.0 lb GR
5.0 lb TA
1.0 lb NT

5 Pieces
0 Total Pieces

PIECE COUNT & TOTAL

Field	Time	Date	Gross	Tare	Net	Count1	Count2
Visible	YES	YES	YES	YES	YES	Piece	Piece
Top	2	2	6	8	10	14	16
Left	2	13	7	7	7	7	7

* See Section [2.13. Piece Count and Total](#) (in User Operation)

Container weighs 5.0 lb.

5 pieces weigh 1.0 lb

13 pieces have been accumulated previously before step 10 has been completed.

After step 10 was completed and when **PRINT** key was pressed, 5 pieces were still on the scale.

02:04PM 02-18-14
6.0 lb GR
5.0 lb TA
1.0 lb NT

5 Pieces
18 Total Pieces

PEAK WEIGHT

Field	Time	Date	Gross	Tare	Net	Count1	Count2	Peak Wt
Visible	YES	YES	YES	YES	YES	NO	NO	YES
Top	2	2	6	8	10	0	0	14
Left	2	13	7	7	7	0	0	2

* See Section [2.14. Peak Weight](#) (in User Operation)

Container weighs 5.0 lb

Item(s) in container weighs 11.0lb

The peak weight applied to the scale to date was 18.0lb

Gross weight and occurred on 02-17-14 @ 01:04PM

02:04PM 02-18-14

16.0 lb GR

5.0 lb TA

11.0 lb NT

18.0 lb Peak Weight 02-
17-14 01:04PM

Section 7: Service and Maintenance

7.1. Troubleshooting the Instrument

DISPLAY	SYMPTOM	RESOLUTION
ERROR	- Possible bad battery or power loss - Program error	- Replace the PCB. - Replace Battery
No Display	No Power	- Check AC Input - Check battery voltage
Drifting/Unstable	- Display changes at a rapid pace. - Loss of Excitation voltage.	- Check for damaged load cell, load cell cables, or bad main PC. - Measure the Excitation Voltage (5VDC) - Use a Simulator to troubleshoot.


7.2. Battery Installation

STAINLESS STEEL INSTRUMENT

1. Unscrew the black plastic end caps.
2. Insert five (5) alkaline “D” cell batteries.

ABS INSTRUMENT

2. Unscrew the two large knurled screws on the back of the Instrument
3. Remove the battery cover.
4. Insert five (5) alkaline “D” cell batteries.
 - Industrial ‘D’ size Energizer EN95 battery or equivalent is recommended for maximum operating time.
 - Stainless Steel models should have special formed key washers installed for grounding.
 - Four (4) screws fasten the back cover plate at the corners.



Appendix I: Data Output Formats

A. General Notes

<CR>	= means carriage return character
<LF>	= line feed character
<SP>	= space character
<EOT>	= end of transmission character
<...>	= used to indicate individual characters for clarity only (not present in data stream)

B. Thurman/ Toledo Continuous Output

<STX><A><C><WWWWW><TTTTTT><CR>

A	= Status Word A
B	= Status Word B
C	= Status Word C
W	= Displayed Weight
T	= Tare Weight

- Leading zeroes are not suppressed.
- The Continuous Computer Output is an uninitiated, unrequested output that is transmitted at a fixed time interval.

B. Thurman/ Toledo Continuous Output, Continued

Character String	Description
STX	Start of Text character : (02 Hex)
A	Status Word A
B	Status Word B
C	Status Word C
xxxxxx	Displayed Weight : x = Weight (6 characters if grad size does not have a decimal point.) (5 characters if the grad size does have a decimal point. The decimal point is not sent as part of the character string.
xxxxxx	Tare Value : x = Tare (6 characters if the grad size does not have a decimal point.) (5 characters if the grad size does have a decimal point. The decimal point is not sent as part of the character string
CR	Carriage Return Character : (0D hex)
CS	Checksum Character : If enabled, this character consists of the last eight bits of the binary sum of all characters transmitted up to this checksum character.

Status Word A

Bit #	Decimal Point or Zero Location							
	x00	x0	x	x.X	x.XX	x.XXX	x.XXXX	x.XXXXX
0	0	1	0	1	0	1	0	1
1	0	0	1	1	0	0	1	1
2	0	0	0	0	1	1	1	1
Increment Size								
Count by 1				Count by 2		Count by 5		
3	1			0		1		
4	0			1		1		
5			Always Logic 1					
6			Always Logic 0					
7			Parity Bit					

B. Thurman/ Toledo Continuous Output, Continued

Status Word B

Bit #	Description	
0	Gross = 0	Net = 1
1	Positive = 0	Negative = 1
2	In Range = 0	Overcapacity = 1
3	No Motion = 0	Motion = 1
4	lb = 0	kg = 1
5	Always Logic 1	
6	Normal = 0	Power Up = 1
7	Parity Bit	

Status Word C

Bit #	Description	
0	Always Logic 0	
1	Always Logic 0	
2	Always Logic 0	
3	Normal = 0	Print Switch Pushed = 1
4	Always Logic 0	
5	Always Logic 1	
6	Normal = 0	Keyboard Tare = 1
7	Parity Bit	

C. Cardinal 738 Continuous Scoreboard Output

<CR><P><WWWWW><m><SP><U><SP><g><SPSP><ETX>

W = Displayed weight

P = Polarity + = Positive weight

- = Negative weight

U = Units

lb = pounds

kg = kilograms

m = Motion or o = Overload

g = Gross; n = Net

SP = Space

Leading zeroes are not suppressed

D. Weightronics WI-120 Continuous Output

<G><P><WWWWW><SP><U><CR><LF>

G = Gross; N = Net

P = Polarity + = positive weight

- = negative weight

U = Units

lb = pounds

kg = kilograms

SP = Space

Leading zeroes are not suppressed

E. Condec Continuous Output

<STX><P><WWWWWW><U><G><M><CR>

P = Polarity space = positive weight

- = negative weight

W = Displayed weight

U = Units

L = pounds

K = kilograms

G = Gross; N = Net

M = Motion

Leading zeroes are suppressed

F. Demand Output - DEFAULT

Activated by the receipt of a <CR>.

Gross Weight – No Motion – decimal points included

<SP> <W> <W> <W> <W> <W> <W> <SP> <|> <SP> <SP> <G>
<R> <SP> <SP> <CR> <LF> <EOT>

Gross Weight – Motion – decimal points included

<SP> <W> <W> <W> <W> <W> <W> <SP> <|> <SP> <SP> <g>
<r> <SP> <SP> <CR> <LF> <EOT>

Net Weight – No Motion – decimal points included

<SP> <W> <W> <W> <W> <W> <W> <SP> <|> <SP> <SP> <N>
<T> <SP> <SP> <CR> <LF> <EOT>

G. Continuous Output - DEFAULT

- Outputs once every display update rate cycle.
- Continuous Output formatted output. Same for Poll and Auto
- Gross Weight – No Motion – decimal points included.

```
<SP> <W> <W> <W> <W> <W> <W> <SP> <|> <b> <SP> <SP> <G>
<R> <SP> <SP> <CR> <LF> <EOT>
```

Gross Weight – Motion – decimal points included

```
<SP> <W> <W> <W> <W> <W> <W> <SP> <|> <b> <SP> <SP> <g>
<r> <SP> <SP> <CR> <LF> <EOT>
```

Net Weight – No Motion – decimal points included

```
<SP> <W> <W> <W> <W> <W> <W> <SP> <|> <b> <SP> <SP> <N>
<T> <SP> <SP> <CR> <LF> <EOT>
```

Net Weight – Motion – decimal points included

```
<SP> <W> <W> <W> <W> <W> <W> <SP> <|> <b> <SP> <SP> <n>
<t> <SP> <SP> <CR> <LF> <EOT>
```

H. PLC (DO NOT USE)

The PLC selection is no longer functional within the PC25X software and should not be used or selected.

GENERAL INFORMATION

The information below is automatically configured by the TS255 and is provided as supplemental information only.

Baud Rate	19,200
Data Bits	8
Parity	None
Stop Bit	1
Mode	Continuous

- Continuous Output, transmitting data on every other A/D update.
 - Approximately 32 transmissions per second.

The output string is **12 characters**, seen as “**wwwuuu<eot>**” where,

<wwwwww> = Weight including decimal point and negative sign.

Negative sign precedes most significant digit and may be preceded by space characters.

<uu> = units “lb”, “kg”, “oz”, or “g”. “oz” may indicate ounces, or lb/ounces.

<mm> = mode “GR” or “NT” for stable weight, or “gr” or “nt” for motion.

<eot> = end of text.

Example 1: **Gross – lbs. – Weight Stable**

<wwwwww> <l> <g> <r> <EOT>

Example 2: **Gross – lbs. – Weight in Motion**

<wwwwww> <l> <g> <r> <EOT>

Example 3: **Net – kgs. – Weight Stable**

<wwwwww> <k> <g> <n> <t> <EOT>

Example 4: **Net – kgs. – Weight in Motion**

<wwwwww> <k> <g> <n> <t> <EOT>

NOTE: Once **FIELD BUS CONFIGURATION** has been programmed, the installing technician’s setup is complete.

Specialized tools available from www.anybus.com.

Interface of the **HMS COMMUNICATIONS** device, power supply to same device, and programming of the PLC is strictly the responsibility of the customer.

I. UPS

- **Serial Data Output Format** for **UPS** Worldship Software.

The instrument will transmit the following string of data.

Character Number **1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18**

String 1

Gross Weight: X X X X . X X SP l/k b/g SP G/g R/r SP SP CR LF EOT

NOTES:

- Characters denoted by “**X**” are characters **0-9**.
 - Leading zeroes are replaced with spaces (**SP**).
 - **Character 5** is a decimal point (**HEX 2E**).
 - Lower case “**l**” and “**b**” for **Avoirdupois Units**, or “**k**” and “**g**” for **Metrics Units**.
 - The first weight character will be a **minus (–)**, **HEX 2D**, If weight is negative.
 - Characters separated with a “**/**” denoted one of the characters will be transmitted.
 - Lower case **gr** in **characters 12 and 13** indicates scale motion.
 - Upper case indicates stable weight.
 - **EOT, HEX 04** is transmitted in “**HiCAP**” condition.
 - Transmission will occur when a **CR (Hex 0D)** carriage return is received.
-

J. P Ship

- Serial Data Output Format for P Ship, used to interface to FedEx Shipping Programs.
- All computer commands and scale responses are **ASCII Character Strings**, where:

<CR> is an ASCII carriage return (hexadecimal 0D)

<LF> is an ASCII line feed (hexadecimal 0A)

<ETX> is an ASCII End-Of-Text (hexadecimal 03)

(STATUS) is a two ASCII number representation of the scale status (in the form of hexadecimal 3x3x, where the bit pattern of the low nibbles, indicated by an "x", determine the actual status conditions)

COMPUTER RESPONSE	SCALE RESPONSE	COMMAND RESULT
W<CR>	<LF><SP>XXX.XXUU<CR>(STATUS)<ETX>	Returns the weight and scale status in two ASCII digits.
S<CR>	<LF>S(STATUS)<CR><ETX>	Returns the scale Status in two ASCII digits (defined in the following section)
Z<CR>	No response	Zeroes the scale
All Else	<LF>?<CR>	Unrecognizable command

Notes: In the scale response to "W<CR>":

- XXX.XX** = A five digit number with two digits to the right of the decimal point which is the displayed scale weight.
- SP** = An ASCII space (hexadecimal 20). In the event of a negative weight, an ASCII, "-" (hexadecimal 2D) is returned in this location.

J. P Ship, Continued

3. **UU** = A two character weight identifier. If the scale is configured to weigh kilograms, a "KG" (uppercase letters) will be returned, if configured for pounds, "LB" (uppercase letters) will be returned.

4. The decimal point is returned by the scale as part of the ASCII string.

5. Interpretation of scale status digits

The high order nibble of each status byte has a value of 3 (0011 B). The low order nibble of the first and second bytes are defined as follows:

1st Byte: Bit 0 - High = scale is in motion
Low = scale is stable
Bit 1 - High = scale at zero
Low = scale not at zero
Bit 2 - Low = not used
Bit 3 - Low = not used

2nd Byte: Bit 0 - High = scale is below zero
Low = scale is not below zero
Bit 1 - High = scale is over capacity
Low = scale is not over capacity
Bit 2 - High = scale ROM program failure
Low = scale ROM okay
Bit 3 - High = faulty calibration data*
Low = scale calibration okay

*This is the result of an incorrect checksum

An example of the scale response to an "S" command would be:

<LF>S20<CR><ETX>

The following status conditions are in effect for this response:

- scale at zero
- scale is not below zero
- scale is not over capacity
- scale ROM okay
- scale calibration okay

Appendix II: Remote PC Commands

Transmitting certain ASCII characters to the TS255 will duplicate a key-press from a remote location via the RS 232 serial connection to Port 1. The baud rate, parity, and stop bits must match. The data bit length is 8 bits.

ASCII CHARACTER	FUNCTION PERFORMED / COMMENTS
Z (upper case)	Zero. Active in the Polled or Button Modes
A (upper case)	Tare (Auto Tare). Active in the Polled or Button Modes
U (upper case)	Change Units. Active in the Polled or Button Modes
g (lower case)	Toggle Gross / Net. Active in the Polled or Button Modes
P or p (either case)	'P' or 'p'. Active in the Polled or Button Modes The output will be the same as if the instrument front panel switch is operated. This output is formatted via the PC25X program, using the 'Format Ticket' tab and can include any of the field items and in the order prescribed.
CR (upper case)	Carriage Return. Active in the Polled Mode Output will be the displayed weight, either Net or Gross. If Motion then "GR" and "NT" are transmitted as "gr" and "nt". Both strings are terminated with; Carriage Return, Line Feed, End Of Transmission, <CR><LF><EOT>

EXAMPLE

"12345 lb GR<CR><LF><EOT>" or "12345 lb nt<CR><LF><EOT>".

c (lower case)

Active in the Polled or Continuous Modes If the instrument is in the Polled Mode the output will be the same as if a Carriage Return was received. The output will be transmitted when the display is refreshed. If the instrument is in the Continuous Mode the output will be transmitted immediately regardless of display update timing.

NOTE: *The programmed parameters in the TS255 apply equally to both a key press and a remote PC command.*

*For example, in order to change the **Units option** for more than one unit, it must be **Enabled**.*

Appendix III: TS255 Remote Display Wiring

RS232 INTERFACE WIRING (Master)				TS250/255 REMOTE DISPLAY		
MODEL	COM	CONNECT		COM	CONNECT	
FAIRBANKS 2200 (ABS)	1	3	TX	1	TB4(A)-1	RX
	1	5	GND	1	TB4(A)-4	GND
FAIRBANKS 2200 (SS)	1	3	TX	1	TB4(A)-1	RX
	1	5	GND	1	TB4(A)-4	GND
TS255 or TS250	1	TB4(A)-2	TX	1	TB4(A)-1	RX
	1	TB4(A)-1	RX	1	TB4(A)-2	TX
	1	TB4(A)-4	GND	1	TB4(A)-4	GND
	2	TB4(B)-2	TX	1	TB4(A)-1	RX
	2	TB4(B)-1	RX	1	TB4(A)-2	TX
	2	TB4(B)-4	GND	1	TB4(A)-4	GND
IT-2000	1	TB4-1	TX	1	TB4(A)-1	RX
	1	TB4-2	GND	1	TB4(A)-4	GND
IS-3000	2, 3, 4 or 5	3	TX	1	TB4(A)-1	RX
		5	GND	1	TB4(A)-4	GND
IS-3000 (SS)	2, 3, 4 or 5	4	TX	1	TB4(A)-1	RX
		8	GND	1	TB4(A)-4	GND
FAIRBANKS 2800	A	TB3-2	TX	1	TB4(A)-1	RX
		TB3-4	GND	1	TB4(A)-4	GND
	B	TB2-2	TX	1	TB4(A)-1	RX
		TB2-4	GND	1	TB4(A)-4	GND
FAIRBANKS 5200A	1 or 2	4	TX	1	TB4(A)-1	RX
		5	RX	1	TB4(A)-2	TX
		8	GND	1	TB4(A)-4	GND

Appendix IV: TS255 Remote Display Active Keys

MODEL	ZERO	UNIT	GROSS/NET	AUTO TARE	PRINT
FAIRBANKS 2200	***	***	***	***	***
TS250	Y	Y	Y	Y	Y
TS255	Y	Y	Y	Y	Y
IT-2000	***	***	***	***	***
IS-3000	***	***	***	***	***
FAIRBANKS 2800	***	***	***	***	***
FAIRBANKS 5200A	***	Y	Y	***	***



Thurman Scales Inc.
4025 Lakeview Crossing
Groveport, OH 43125

<http://www.thurmanscale.com/>

TS255 Series Instrument

**TS255/ PC25X
Document 51369**