




# TS600 Series Instrumentation

**TS601 In/Out/ GTN Analog Desktop Instrument**

**TS602 In/Out/ GTN Analog NEMA 4X Wall Mount Instrument**

**TS603 In/Out/GTN Analog Panel Mount Instrument**

**TS603 Analog Driver Assist Terminal**





## **Disclaimer**

Every effort has been made to provide complete and accurate information in this manual. However, although this manual may include a specifically identified warranty notice for the product, Thurman Scale makes no representations or warranties with respect to the contents of this manual, and reserves the right to make changes to this manual without notice when and as improvements are made.

Thurman Scale shall not be liable for any loss, damage, cost of repairs, incidental or consequential damages of any kind, whether or not based on express or implied warranty, contract, negligence, or strict liability arising in connection with the design, development, installation, or use of the scale.

**© Copyright 2020**

This document contains proprietary information protected by copyright. All rights are reserved; no part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without prior written permission of the manufacturer

# Public License Statement

Copyright © 2020, Thurman Scale, Inc.  
All Rights Reserved

THE THURMAN SCALE COMPANY DEVELOPED SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The software included in this [Thurman Scale, Inc.](#) product includes one or more open source software components. This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org>). This product also includes software licensed under the Apache License and you may not use any of these files except in compliance with the Apache License. A copy of the Apache License may be obtained at <http://www.apache.org/licenses>. This product may also include the applications governed by the Zlib license, LibPNG license, and the MIT license. For a listing of the open source software applications included in the product that are governed by any one of the above identified licenses, please contact Thurman Scale, Inc. at the address provided below.

To the extent applicable, Thurman Scale, Inc. will comply with the required disclosure conditions set forth in each of the open source software licenses identified below.

## GNU PUBLIC LICENSE:

This Thurman Scale, Inc. product includes open source software components governed by the GNU Public License. To the extent applicable, the person in possession of this product may request a copy of the source code of the software included in the product that is covered by the GNU Public License. The possessor of this product may request such a copy by contacting [Thurman Scale, Inc.](#) at the address set forth below. A copy of the GNU Public License may be found at <http://www.gnu.org/licenses/gpl.html>.

## GNU LESSER GENERAL PUBLIC LICENSE (LGPL):

This Thurman Scale, Inc. product includes open source software libraries governed by the LGPL. The use of the open source libraries is governed by the LGPL and copies of the source code of these libraries may be obtained by contacting [Thurman Scale, Inc.](#) at the address set forth below. A copy of the LGPL license may be found at <http://www.gnu.org/copyleft/lesser.html> and a copy of the GNU Public License incorporated into the LGPL is found at the link provided above.

## BSD LICENSE:

This Thurman Scale, Inc. product includes open source software governed by the BSD open source license. Your own redistribution and use in source and binary forms of these Applications, with or without modification, are permitted provided that the following conditions set forth in the BSD license are met, including:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

A copy of the BSD license may be found at <http://opensource.org/licenses/BSD-2-Clause> or <http://opensource.org/licenses/BSD-3-Clause>.

## ARTISTIC LICENSE:

This Thurman Scale, Inc. product includes open source software governed by the Artistic License. To the extent applicable, the person in possession of this product may request a copy of the source code of the portions of the product software that are covered by the Artistic License or you may find copies of these open source code applications at [[www.cpan.org](http://www.cpan.org)][Thurman to verify location at which user can download source code]. To request a list of the applications and copy of the source code by contacting Thurman Scale, Inc. at the address set forth below. A copy of the Artistic License can be found at <http://opensource.org/licenses/artistic-license-2.0>.

Any Open Source Software inquiries to Thurman Scale, Inc. shall be sent to: [Thurman to provide contact (either person or the title) and the mailing address.] Any request for copies of the source code will only be provided as required by the license under which the open source component was used. For any copies of source code provided, a small processing fee of \$15.00 may apply to cover the cost of the storage medium and the time required for reproduction.

# Amendment Record

## TS600 Series Instrumentation

- TS601** IN/OUT/ GTN Analog Desktop Instrument (**31675**)
- TS602** IN/OUT/ GTN Analog NEMA 4X Wall Mount Instrument (**32575**)
- TS603** IN/OUT/GTN Analog Panel Mount Instrument (**32675**)
- TS603** Analog Driver Assist Terminal (**37768**)

## Operator Manual Document 51421

Manufactured by

**Thurman Scale**  
4025 Lakeview Crossing  
Groveport, Ohio 43215

<b>Revision #</b>	<b>Created</b>	<b>Update</b>
Revision 1	12/2017	Released Manual
Revision 2	08/2019	Updated Operator Menu; Configuration, Added Appendix III
Revision 3	06/2020	Updated User Operations

---

# TABLE OF CONTENTS

---

<b>SECTION 1: GENERAL INFORMATION .....</b>	<b>8</b>
<b>1.1. Instrument Description .....</b>	<b>8</b>
1.1.1. <i>Standard Features .....</i>	<i>8</i>
1.1.2. <i>Accessories .....</i>	<i>8</i>
<b>1.2. Technical Specifications.....</b>	<b>9</b>
<b>1.3. Levels of Security .....</b>	<b>10</b>
<b>1.4. Users' Responsibility.....</b>	<b>11</b>
<b>SECTION 2: USER OPERATIONS.....</b>	<b>12</b>
<b>2.1. Front Panel Key Functions .....</b>	<b>12</b>
<b>2.2. Startup Procedure .....</b>	<b>13</b>
<b>2.3. Gross Weighing.....</b>	<b>13</b>
<b>2.4. Basic Weighing .....</b>	<b>13</b>
<b>2.5. Gross-Tare-Net Weighing .....</b>	<b>14</b>
<b>2.6. Inbound/Outbound Weighing .....</b>	<b>15</b>
<b>SECTION 3: PROGRAMMING OVERVIEW.....</b>	<b>17</b>
<b>3.1. Login .....</b>	<b>17</b>
<b>3.2. Defining the Programming Menus .....</b>	<b>17</b>
<b>3.3. Short-cut Method for Menu Navigations.....</b>	<b>18</b>
<b>SECTION 4: WEB INTERFACE .....</b>	<b>19</b>
<b>4.1. How to Connect Remotely to the TS6XX Series: .....</b>	<b>19</b>
4.1.1. <i>To obtain the current IP address of the TS6XX: .....</i>	<i>19</i>
<b>4.2. Logging n to the Web Interface .....</b>	<b>20</b>
<b>4.3. Navigating the Web Interface .....</b>	<b>21</b>
4.3.1. <i>Audit Trail.....</i>	<i>21</i>
4.3.2. <i>Operator Menu.....</i>	<i>22</i>
4.3.3. <i>Configuration Menu.....</i>	<i>23</i>
4.3.4. <i>Scale Diagnostics .....</i>	<i>25</i>
<b>SECTION 5: AUDIT TRAIL.....</b>	<b>26</b>
<b>5.1. Display .....</b>	<b>26</b>
<b>5.2. Print.....</b>	<b>26</b>
<b>5.3. NJ Jumper State.....</b>	<b>27</b>
<b>5.4. SW Revision .....</b>	<b>27</b>
<b>SECTION 6: OPERATOR MENU .....</b>	<b>28</b>
<b>6.1. New Tare .....</b>	<b>28</b>
<b>6.2. New Keyboard Tare.....</b>	<b>29</b>
<b>6.3. Tare Delete.....</b>	<b>30</b>
<b>6.4. Tare Report.....</b>	<b>30</b>
<b>6.5. Time &amp; Date .....</b>	<b>31</b>
6.5.1. <i>Format Time &amp; Date.....</i>	<i>31</i>
6.5.2. <i>Set Time &amp; Date.....</i>	<i>32</i>
6.5.3. <i>To Display Time &amp; Date .....</i>	<i>32</i>
<b>6.6. Ticket Number .....</b>	<b>33</b>
<b>6.7. Load Cell Diagnostics.....</b>	<b>33</b>



- 6.8. Utility ..... 34
  - 6.8.1. Set Display Intensity ..... 34
  - 6.8.2. Key Pad Beep, Set Volume, Mute ..... 35
- 6.9. Options (Operator) ..... 35
- SECTION 7: CONFIGURATION MENU ..... 36**
  - 7.1. Change Customer PW ..... 36
  - 7.2. Prompts – Programmable ..... 36
  - 7.3. Legends – Programmable ..... 37
  - 7.4. Ticket Formats ..... 37
  - 7.5. COM Ports ..... 37
  - 7.6. Threshold Weights ..... 37
  - 7.7. Traffic Light Control ..... 39
  - 7.8. Reports ..... 39
  - 7.9. Network IP Settings ..... 40
  - 7.10. Transaction Files ..... 41
  - 7.11. Remote Switches ..... 42
  - 7.12. Instrument ID ..... 42
  - 7.13. Serial Input Codes ..... 42
- SECTION 8: SERIAL INPUT / OUTPUT ..... 43**
  - 8.1. Printers ..... 43**
    - 8.1.1. Printer Switch Settings ..... 43
    - 8.1.2. Printer Cabling ..... 43
    - 8.1.3. iDP3550 Tape Printer Settings ..... 44
    - 8.1.4. TM-U590 Ticket Printer Settings ..... 44
    - 8.1.5. TM-U295 Ticket Printer Settings ..... 45
    - 8.1.6. TM-U220 Tape Printer ..... 46
    - 8.1.7. SP298 Printer Settings ..... 48
    - 8.1.8. SP700 Printer Settings ..... 50
    - 8.1.9. SP2000 Printer Settings ..... 52
    - 8.1.10. SP2200 Printer Settings ..... 52
    - 8.1.11. TM-U230 Printer Settings ..... 53
  - 8.2. COM Ports ..... 54**
    - 8.2.1. Programming COM PORTS ..... 55
    - 8.2.2. Configuring the Remote Display Output ..... 55
    - 8.2.3. Selecting the Printer ..... 56
    - 8.2.4. PC Data String Output ..... 56
    - 8.2.5. Configuring Network Output ..... 57
    - 8.2.6. DemandPC ..... 58
  - 8.3. 4-20mA Analog Card (30919) ..... 59**
  - 8.4. Traffic Light Control ..... 60**
    - 8.4.1. Control (Traffic Light) ..... 60
    - 8.4.2. Event to Signal ..... 60
  - 8.5. Programming the Remote Display ..... 61**
    - 8.5.1. Display Mode ..... 61
    - 8.5.2. Type (Output) ..... 61
    - 8.5.3. Enable 218T ..... 62
  - 8.6. Basic Troubleshooting ..... 63**
- SECTION 9: FORMATTING TICKETS ..... 64**
  - 9.1. Standard Ticket Formatting Steps ..... 64**



**9.2. Printer and Ticket Differences..... 65**

**9.3. Ticket Formatting ..... 66**

    9.3.1. *Write Commands* ..... 66

    9.3.2. *Quick Formatting Buttons*..... 67

    9.3.3. *Ticket Format Commands*..... 68

    9.3.4. *Ticket Formats* ..... 69

    9.3.5. *G/T/N Ticket Formatting*..... 70

    9.3.6. *Inbound Ticket Formatting* ..... 71

    9.3.7. *Outbound Ticket Formatting*..... 72

    9.3.8. *Completed Transaction Ticket Example* ..... 73

    9.3.9. *BasicIn and BasicOut Ticket Formatting* ..... 74

    9.3.10. *Deleting a Ticket Format* ..... 75

**APPENDIX I: DATA STRING OUTPUTS ..... 76**

**A. Remote Display Output ..... 76**

**B. Configure Output..... 76**

**APPENDIX II: REMOTE SERIAL COMMANDS ..... 80**

**APPENDIX III: CONNECTING TO THE TS60X VIA ETHERNET ..... 81**

---

# SECTION 1: GENERAL INFORMATION

---

## 1.1. Instrument Description

The **TS601/602/603 Instrument** has four Operating Modes a Basic, Inbound, Outbound, and GTN instrument.

- The Instrument may be enhanced by adding either a 4-20mA or a Relay Module to the unit.
- Only one (1) module may be added to provide either a 4-20mA output or a Relay Module interface to control traffic lights.

The **TS601/602/603 Instrument** is designed for a wide variety of truck, floor, hopper, and tank scale applications.

- The load cells interface with the Instrument through the **Scale Interface Card (SIC)**.
- An RS-232 interface allows for the transfer of data from the Instrument to a computer and vice versa.

Noted below are the four TS600 Series instrument models.

- **Desktop – TS601 (36165)**
- **NEMA 4X Wall Mount – TS602 (36180)**
- **Panel Mount – TS603 (36181)**
- **Driver Assist Terminal – TS603 (37768)**

### 1.1.1. Standard Features

- 0.8" LED alphanumeric display
- One (1) Ethernet Port
- Three (3) USB Ports
- Choice of either One (1) 4-20mA port or one (1) Analog Relay Board.
- External Display COM Port 4
- Three (3) RS232 serial ports
- Capable of formatting tickets
- Keypad Buttons, including the following:
  - 0-9 keys, Enter, Red (stop), Green (go), Tare, In, Out, Units, B/G/Net, Zero and Print.

### 1.1.2. Accessories

PART NO.	DESCRIPTION
30919	4-20mA Analog Kit *
30920	Relay PCB Assy Kit *
25498	Mini USB Keyboard (87 key)
31036	Standard USB Keyboard (104 key)
15892	SVP/ Uninterruptable Power Supply

\* Only one or the other of these accessories may be used in the TS601/02/03 series instrument.



## 1.2. Technical Specifications

PARAMETER	SPECIFICATION
<b>Model</b>	Desktop TS601; NEMA 4X Wall Mount TS602; Panel Mount TS603
<b>Load Cell Interface</b>	Up to 16 ~ 1000Ω load cells max, Or up to 8 ~ 350Ω load cells max
<b>Cell Capacity</b>	1 thru 999,999
<b>Cell Units</b>	lbs, kgs, tons, tonne
<b>No. of Scales</b>	One (1) only
<b>Resolution</b>	10000d commercial 20000d non-commercial
<b>Scale Capacity</b>	100-999,999
<b>Division Size</b>	0.0001 thru 50
<b>Units</b>	lbs, kgs, tons, tonne
<b>Serial Input/ Output</b>	Three (3) RS232 COM Ports, one (1) Console Port, three (3) USB Ports
<b>Storage</b>	Up to 100,000 transactions
<b>Auto Zero Tracking</b>	Selectable – Off, 0.5d, 1.0d, 3.0d
<b>Motion Band</b>	Selectable – Off, 0.5d, 1.0d, 3.0d
<b>Zero Range</b>	Selectable – 2%, 100%

ENVIRONMENTAL	SPECIFICATION
<b>Enclosure</b>	NEMA 12 desk mount and Panel mount; NEMA 4X wall mount
<b>Operating Temperature</b>	14°F to 104°F, (-10°C to 40°C).
<b>Operating Humidity</b>	NEMA 12 non-condensing, not suitable for wash-down conditions.

POWER REQUIREMENTS	SPECIFICATION
<b>Incoming Voltage Requirement</b>	Instrument has an Auto-switching power supply. 100 VAC to 130 VAC, 50Hz\ 60Hz 200 VAC to 260 VAC, 50Hz\ 60Hz It is recommended to install a separate circuit from the circuit panel to the outlet used. There must not be more than 0.2VAC between AC neutral and ground
<b>Ground Requirements</b>	For proper performance, the ground should have no more than 3.0 Ω resistance to true earth ground.
<b>Power Consumption</b>	Less than (<) 40 watts
<b>ETL Listed</b>	Conforms to UL STD 60950-1. CAN/CSA C 22.2 NO.60950-1-03.
<b>Approvals</b>	CC# 12-099 MC# AM-5878



## 1.3. Levels of Security

There are three security levels for accessing the TS601/2/3 programs.

- **Security Levels One thru Three (1 – 3)** configures the hierarchy of the management functions, and limits privilege accesses from unauthorized employees.
- When making the employee hierarchy, employee duties should determine their security level.
- Each access level includes all of the rights of any access level(s) below it.

### FIRST LEVEL: OPERATOR ACCESS

- Accesses the Operator Menu and the Audit Trail Menu.
- **No Password** is necessary for this level of instrument access.

### SECOND LEVEL: SUPERVISOR ACCESS

- All of the Operator Access privileges.
- **Supervisor Password** is required.
- The *default first time use* password for the **Supervisor Access** is **“1”**.
  - *It is strongly recommended to change this password.*
- Second Level Users can also access the **Configuration Menu**.

### THIRD LEVEL: SERVICE TECHNICIAN ACCESS

- Service Technician privileges to install and program the Instrument.

## 1.4. Users' Responsibility

- ✓ All electronic and mechanical calibrations and/or adjustments required for making this equipment perform to accuracy and operational specifications should be performed by trained service personnel.
- ✓ Absolutely no physical, electrical or program modifications other than selection of standard options and accessories are to be made to this equipment.
- ✓ Electrical connections other than those specified may not be performed, and physical alterations (holes, etc.) are not allowed.




*Please call your local*  
**THURMAN SCALE REPRESENTATIVE**  
*For any question, problems, or comments.*

# SECTION 2: USER OPERATIONS

## 2.1. Front Panel Key Functions

KEYS	FUNCTION
<b>RED &amp; GREEN LIGHT BUTTONS</b>	<ul style="list-style-type: none"> <li>Activates the <b>Traffic Light</b> function, if one is installed.</li> <li>When in the <b>Programming Mode</b>, pressing the <b>RED</b> button returns to the <b>Weight Display</b> (except when modifying an entry).</li> <li>The <b>GREEN</b> button deletes the <b>Ticket Format</b>, when in the Ticket Format menu.</li> </ul>
<b>TARE</b>	Performs an <b>AutoTare</b> function.
<b>IN &amp; OUT BUTTONS</b>	<ul style="list-style-type: none"> <li>Manually selects the <b>INBOUND</b> or <b>OUTBOUND</b> mode.</li> <li>The <b>OUT</b> button prints the current Ticket Format, when in the Ticket Format menu.</li> </ul>
<b>UP &amp; DOWN Arrows</b>	Navigates through the menu selections.
<b>MENU</b>	<ul style="list-style-type: none"> <li>The basic <b>HOME</b> button.</li> <li>Initiates the programming process into the different menus.</li> <li>Backs up one level on the Menu Tree.</li> <li>If the actions are not saved, pressing the <b>MENU</b> button voids this input.</li> </ul>
<b>NUMERIC Keys</b>	<ul style="list-style-type: none"> <li>Enters values for passwords, weight amounts, and configuration inputs.</li> <li>These keys can shortcut to desired entries in a selection item</li> <li>See <b>3.4. Short-cut Method for Menu Navigations</b>.</li> </ul>
<b>ENTER</b>	Activates and saves data input.
<b>UNITS</b>	<ul style="list-style-type: none"> <li>Toggles and sets the unit types for the weight displayed.</li> <li>When programming, it inserts data if additional items are needed.</li> <li>Data-insert function happens before the item that is currently being viewed, while in the Format Menu.</li> </ul>
<b>B/G/NET</b>	<ul style="list-style-type: none"> <li>Toggles active display between <b>GROSS</b> and <b>TARE</b>, in the <b>GTN</b> mode.</li> <li>Deletes one character in text/number.</li> </ul>
<b>ZERO</b>	<ul style="list-style-type: none"> <li><b>ZERO</b>s the scale.</li> <li>When editing numbers or text, this clears the data.</li> </ul>
<b>PRINT</b>	<ul style="list-style-type: none"> <li>Initiates a <b>PRINT</b> cycle.</li> <li>Toggles between editing and showing the name of the current menu choice.</li> <li>Prints a sample ticket while in the <b>Layout Menu</b>.</li> </ul>





## 2.2. Startup Procedure

1. Plug the unit in. The following sequence should occur:
  - a. **T5600** will scroll across the display, followed by the display driver and revision number.
  - b. **BOOT \*** will appear
  - c. **LOAD \*** will appear
  - d. **START \*** will appear
  - e. The current weight on the scale will display.

## 2.3. Gross Weighing


*The truck drives on the scale and the operator prints the result.*

1. Press the **ZERO** key.
2. Drive the vehicle to be weighed on the platform.
3. Once the display stabilizes, press the **PRINT** key.
  - A **GTN** ticket prints with the **Gross Weight**.

## 2.4. Basic Weighing

**BASIC MODE** weighs the vehicle, then prints a ticket displaying the **Time, Date** and **Weight Amount** (either **Tare** or **Gross**). *This is its only function.*

- This mode **does not** have In/Out or Tare functions, (including storing Tares).
  - This mode requires specialized **keypad overlay stickers**.
1. With a **loaded vehicle** on the scale, press the **GROSS / PRINT** key
    - This is the **IN key**, before the template sticker was added.
  2. With an **empty vehicle** on the scale, press the **TARE / PRINT** key.
    - This is the **Out key**, before the template sticker was added.



*This TS600 Front Panel has the **BASIC Mode** stickers applied.*



## 2.5. Gross-Tare-Net Weighing


### Option 1

- 1a. Press the **ZERO** key.
- b. Drive the empty vehicle to be weighed on the platform.
- c. Press the **TARE** button.
  - The weight is the captured **Tare Weight**.
- d. Exit the scale and load the vehicle with product.
- e. Drive back onto the scale.
- f. Once the display stabilizes, press the **PRINT** key and a Gross-Tare-Net Ticket will be printed.

**OR...**

### Option 2


- 1a. With the scale unloaded, press the **ZERO** key.
- b. Drive the loaded vehicle to be weighed on the platform.
- c. When the display stabilizes, press the **PRINT** key.
- d. When **KEY IN TARE AND PRESS ENTER** displays, enter a known **TARE amount** from an earlier weighment using the numeric keypad, then press **ENTER**.
  - A **GTN Ticket** will be printed.



---

**NOTE:** For printing only **Gross Weight**, enter **ZERO (0)** when prompted to enter a Tare amount.

---





## 2.6. Inbound/Outbound Weighing

Noted below are a few tips for the Inbound/Outbound Weighing Mode.

- The **Loop ID** input varies depending on the installed software:  
**Revision 2.2.0** software and lower, Loop ID is **limited to 3 numeric characters**.  
**Revision 2.4.2** software and higher, **supports up to 15 alphanumeric characters**
- The **Loop ID** is replaced by saving a new tare, or a saving a new keyboard tare ID.


There are 4 options when performing Inbound/Outbound Weighing.

### Option 1

- 1a. Press the **ZERO** key.
- b. Drive the vehicle onto the platform, whether it is either full or empty.
- c. Once the display stabilizes, press the **IN** (Inbound) key.
- d. When the **Loop ID** legend text displays, enter the **Loop ID number** using the QWERTY keyboard or keypad, then press **ENTER**.

### Option 2

- 1a. Press **ENTER** to have the TS601 auto-assign a **Loop ID number**.
- b. Drive off the scale and process the trailer, by either filling or emptying it.
- c. The same vehicle returns to the scale, either full or empty.
- d. Once the display stabilizes, press the **OUT** (Outbound) key.
- e. When the **Loop ID legend text** displays, enter the **LOOP ID Number** from an Inbound Transaction or saved TARE ID number, then press **ENTER**.





## 2.5. Inbound/Outbound Weighing, Continued

### Option 3

- 1a. With the scale unloaded, press the **ZERO** key.
- b. Drive the loaded vehicle to be weighed on the platform.
- c. When the display stabilizes, press the **PRINT** key.
- d. When **KEY IN TARE AND PRESS ENTER** display, using the enter a known **TARE amount** from an earlier weighment, then press **ENTER**.
  - A **GTN Ticket** will print.

---

**NOTE:** For **Gross Weight** only to be printed, enter **ZERO (0)** when prompted to enter a *Tare amount*.

---

### Option 4


- 1a. With the scale unloaded, press the **ZERO** key.
- b. Drive the loaded vehicle to be weighed on the platform.
- c. When the display stabilizes, press the **IN** or **OUT** key.
- d. When the **Loop ID legend text** displays, enter a **Tare ID number** from a stored **NEW TARE** or stored **NEW KEYBOARD TARE**, then press **ENTER**.

***The transaction is processed and an Outbound ticket prints***

# SECTION 3: PROGRAMMING OVERVIEW

## 3.1. Login

1. Press the **MENU** button to toggle between **Weight Display** and **Menu System**.



2. To enter the **MENU System**, when **LOGIN** displays, press the **ENTER** button.

– The display will be blank.

3. Input the **Service Password**, then press **ENTER**.

✓ **Supervisor Password = 1**

**OK** displays first, then **AUDIT TRAIL** follows.

4. Press the **DOWN ARROW** to navigate through the following main menus.

- **Audit Trail**
- **Operator Menu**
- **Configuration Menu**

5. Press **ENTER** to accept the option.

## 3.2. Defining the Programming Menus

*The six (6) programming menus are briefly defined below.*

<b>AUDIT TRAIL</b>	Identifies how many times and when changes have been made to the scale's Calibration or Configuration settings. <b>NO Password required</b>
<b>OPERATOR MENU</b>	Programs the Time/Date, Ticket Number, Load Cell Diagnostics, Tare Functions, Display Intensity and Keypad Sounds. <b>NO Password required</b>
<b>CONFIGURATION MENU</b>	Programs Customer Passwords, Communications Programming and Functions, Ticket Formats, Programmable Prompts and Legends, Device Input/Outputs, Weight Threshold, Report Configuration, Network Configuration, and Transaction Files Operations. <b>Default Password = 1</b>



### 3.3. Short-cut Method for Menu Navigations

Navigate through the different menu levels by entering a **Hot-key Number** and immediately access functions of the next higher level.

- The **Hot-key Number** displays in the flow charts to the **left** of the function.

*Follow these steps to navigate using the HOT-KEY NUMBERS.*

6. Press a **HOT-KEY NUMBER** to advance to the functions of the next menu level.
7. Continue pressing the next **HOT-KEY NUMBER**, moving forward in the menu tree, until the needed function is accessed.
8. Press **MENU** to move backward to the previous level.

---

# SECTION 4: WEB INTERFACE

---

The configuration of all TS6XX series scales with **software version 2.0.1** or higher can now be performed through the instrument **OR** through the *Web Interface*.

---

**NOTE:** *At this time, scale calibration can **ONLY** be performed through the TS6XX instrument and **NOT** the **Web Interface**.*

---

The Web Interface can be accessed through most browsers (Internet Explorer, Firefox, Google Chrome) that is connected to a TCP/IP network **OR** by using an Ethernet crossover cable connected to a PC or tablet.

The first step in connecting remotely is to determine the connection address (IP address) of the instrument.

## 4.1. How to Connect Remotely to the TS6XX Series:

*There are two (2) connection types used with the TS6XX.*

- **DHCP (Dynamic Host Configuration Protocol)** – Automatically addresses each node the first time it connects to the company's Intranet. A **DHCP** connection may change every few weeks so if you are not able to connect, re-verify the IP address on the instrument (see **To obtain the current IP address of the TS6XX**)
- **STATIC** – Dedicated addresses assigned by the IT Department that are specific to each node, and do not change.

### 4.1.1. To obtain the current IP address of the TS6XX:

1. Login to the TS6XX
2. **Scroll down to CONFIGURATION**, press **ENTER**
3. Scroll up to **NETWORK**, press **ENTER**
4. **Scroll down to DHCP OPTIONS**, press **ENTER**
5. **MY IP** is displayed, press **ENTER**
6. **The TS60X IP address is displayed (XXX .XXX .XXX .XXX)**  
Write down the IP address
7. Press the RED Traffic light button twice to return to the weigh screen.

*Follow these steps to display, or to enter the **Static addresses** in the **NETWORK option**.*

## 4.2. Logging in to the Web Interface

1. Locate the **IP Address** of the TS6XX Series Instrument  
(See also To obtain the current IP address of the TS6XX )


---

**NOTE:** *In order to login to the Web Interface, you **MUST** logout of the TS6XX instrument. If you are **NOT** logged out, you will receive the message “**Front Panel in Use**” until you log out.*

---

2. Input the correct **IP Address** of the TS6XX into the Address Bar of the web browser, then press **ENTER** on the remote computer.

3. Click on the **LOGIN** link.




Input the Default **Operator Password**, then press the **LOG IN** button.

**Operator Password = 1.**

The **Web Interface Home** screen appears.

After you are logged in successfully, the message “**Remote Config in Process**” will appear on the screen of the instrument.



## 4.3. Navigating the Web Interface

After successfully logging into the TS6XX Web Interface, the additional options of **Configuration Menu**, **Service Menu** and **Expansion Cards** will appear in the left-hand navigation. Additional options also will appear under **Operator Menu** and **Power Supply**.


---

**NOTE:** As stated previously, the Scale calibration can **NOT** be performed through the Web Interface but only through the instrument. All other settings are identical between the Web Interface and the instrument.

---

### 4.3.1. Audit Trail

The following options will appear in the Web Interface under **Audit Trail**:



**Display:** Displays all configuration changes made to each scale with drop-down menus for **Audit Report**, **number of items per page** and an available **Search**.


**Print:** Print the records from the Audit Report with options for number of items to print and a drop-down menu of available printers.

**NJ Jumper State:** Lets you know if this feature is active or inactive. See section [5.3. NJ Jumper](#) for more information about this option.

**SW Revisions:** Provides **Image**, **Model**, **Main**, **Drivers**, **Interpreter**, **Webconfig** information.



### 4.3.2. Operator Menu



**New Tare:** Add a new tare from the scale.

**New Keyboard Tare:** Manually enter a new tare.

**Tare Delete:** Provides the same options of **New Tare**, **New Keyboard Tare** and deleting a tare. A drop-down menu of all the existing tares and a **Search** is available.

**Tare Report:** Provides the same options as **Tare Delete** and a **Print** option with a drop-down list of available printers.

**Time And Date:** Provides the options of **Format Time and Date** and **Set Time and Date**.

**Tickets:** Set the starting value of tickets under **Number**, print the last created ticket under **Print Last Ticket** or add the ticket number of a ticket you wish to re-print under **Print Duplicate Ticket**.

**Load Cell Diagnostics:** Provides a live count of the **Cell Outputs** and **Errors**.


**Utility:** Provides drop-down menus for **Display Intensity**, **Keypad Beep**, scale **Volume** ranging from 10% (lowest volume) to 100% (highest volume) and **Mute**.

**Options (Operator):** When processing Inbound Loops, **Outbound Auto Suggest** displays the next available. When processing Inbound Loops, **Auto Increment Inbound ID** automatically uses the next available (without displaying it). **Show Looping ID Text** displays *all* the stated information about the Loop, including the ID number, truck description, or any related text.



### 4.3.3. Configuration Menu

The following options will appear in the Web Interface under **Configuration Menu**:



**Customer Password (Configuration Menu Password)**: Change the login password of the instrument. This is highly recommended.

**Prompts**: Messages to the Operator that ask a question, offer a choice, or relay an instruction. The **Name** field is a text entry field for naming a prompt. "Prompt 1" is the name used by the system to identify the prompt. **GTN, Inbound, Outbound, Basic In,** and **Basic Out** are all drop-down menu items that may be enabled or disabled.

**Legends**: The **Loop ID** field is a text entry field if you wish add a custom name.

**Ticket Formats**: The connected printer displays in the **Printer** field. The **Mode** drop-down menu lets tickets print in **GTN, Inbound, Outbound, BasicIn,** or **Basic Out** formats.

---

**NOTE:** *If a printer does not display in the **Printer** field, no printer has been added to a COM port. See [8.2. COM Ports](#) to connect to an available printer.*

---

**Remote Display**: Provides a drop-down menu to adjust **Display Mode** to continuous or print, **Type (Output)** to display by ticket number, Active Gross or Net Wt. **Enable 218T** set to Yes or No.

**Com Ports**: Provides options for configuring the three input com ports and the single outgoing port. See section [8.2. COM Ports](#) for further details.



**Threshold Weights:** **Initial Weight** option provides up and down arrows to set the minimum amount the truck must weigh to initiate a weighment.

- **Initial Weight** is the minimum weight value to initial a transaction, trigger automatic traffic light control, initiate the Blind Counter functions.
- **Maximum Weight** is the maximum allowable weight for processing transactions.
- **Allow Over Weight Transactions** can be set to YES to warn of an overweight condition or NO to prevent overweight transactions.

**Traffic Light Control:** **Control (Traffic Light)** either Automatic or Manual. The **Event to Signal** option lets the operator add a time to delay between 1-10 seconds to the signal. "Scale ID 1" is the name used by the system to identify the setting.

**Reports:** Provides options for displaying a report. **Type** provides an option for choosing Completed or Incomplete transactions. **Media** only shows "Jump Drive" in the drop-down menu. Reports must be generated to an inserted jump drive. **Sort By** provides the option of the report being sorted by Loop ID or Date/Time. **Delimiter** provides the option of generating a report in CSV or Tab format. See section [7.9. Reports](#) for more details.

**Network:** **DHCP Options** shows the network connectivity details of the instrument, **IP**, **Netmask**, **Gateway** and **DNS**. The **Network Output** provides an option for the **Type** output, of either Off or PC Continuous. The **Format** provides a choice of scale company output data. See also [Appendix 1: Data String Outputs](#) The **Local Port** provides up and down arrows to choose the correct port number on the outgoing PC.

Network section under the **CONFIGURATION MENU** controls all network settings.

Options include **DHCP** or **STATIC IP**

**DHCP OPTIONS** or\* **STATIC IP** : Reports the IP address, Netmask, Gateway, Primary DNS

\*Displayed value dependent on selected option of DHCP or STATIC.

Network Output: If configured will send **NETWORK** continuous **SCALE** output.

- **Type** is either OFF or PC Continuous
- **Format:** Select from 5 factory **DEFINED** formats:  
Thurman, Toledo, Cardinal, Weigh-Tronix, Condec
- **Local Port:** default 5001, change only if requested by site.

The screenshot shows the 'Network Output' configuration interface. It includes a 'Type' dropdown menu set to 'PC Continuous', a 'Format' dropdown menu set to 'Thurman', and a 'Local Port' spinner box set to '5001'. A 'Submit' button is located below these fields. To the right, a 'Speed' dropdown menu is open, showing options: 'AUTO', '10/HALF', '10/FULL', '100/HALF', and '100/FULL'. The 'AUTO' option is currently selected.



Speed: This controls the speed and if full or half duplex is used on the network device. Default is AUTO and in most cases is enough.

**Transaction Files:** This option allows for file deletion by five different options: **All Transactions, By Ticket Number, By Date Range, By Ticket Range** and **Incompletes**.


**Remote Switches:** **Initial Weight** option Used to configure/select the four (4) available remote Switch inputs.

**Instrument ID:** used to set the Instrument ID (1 – 255)

**Serial Input Codes:** **Initial Weight** option allows for entry of specific HEX codes to simulate a remote serial command.

### 4.3.4. Scale Diagnostics

**Scale Diagnostics** displays real-time data by **Weights** or **Cell Counts**. Click either Weights or Cell Counts to switch between options. The **Gross Weight** appears as well.



**Weights:** Displays **Weights** and **Zero Counts**.

**Cell Counts:** Displays **Current Counts** and **Zero Counts**.

---

# SECTION 5: AUDIT TRAIL

---

The **AUDIT TRAIL** report displays all the configuration and calibration activities that were changed within the Instrument.

- Provided for **Weights and Measures Officials**.

## 5.1. Display

Filters the **Audit Trail Events** displayed, based on the selected option, after the **ENTER** button is pressed.

- This option is limited to **view only access**.

*The example below defines the **Audit Trail** report message.*



The screenshot shows an LCD display with the following text:

```
MODE INBOUND / OUTBOUND      MODE -- INSTRUMENT
28      08/06/13      11 : 28
```

- The unit is in the **INBOUND/OUTBOUND MODE** (Inbound/Outbound, GTN or Basic Mode).
- The UNIT is currently in the **INSTRUMENT MODE** (Instrument, Scale or Complete).
- There have been **28** “log-able” events performed on this instrument.
- The **DATE** and **TIME** of the last recorded event (#28, in this case).

## 5.2. Print

Sets up the print output for the **Audit Report**, then prints all Configuration and Calibration activities that were changed within the Instrument.

- Offers a choice of the available printers configured to a COM Port.
- Prints some or all of the records.
- The **PRINT OUT** function activates the printer according to the settings.



Follow these steps to print an **AUDIT TRAIL** report.

1. Prepare the printer.
2. Open the **AUDIT TRAIL** menu, then select the correct printer.

- TM-U295
- IDP-2550
- DemandPC
- TM-U230
- TM-U590
- TM-U220
- SP-700
- SP-298
- SP-2000
- SP-2200

---

**NOTE:** *The printer must be correctly configured before completing this option.*

---

3. Select the **NUMBER OR RECORDS** to include on the report.

- Last (record)
- 10
- 50
- All (records)

4. Select **PRINT OUT**, then press **ENTER**.

### 5.3. NJ Jumper State

*This feature prevents unauthorized users from accessing certain programming menus.*

1. In the **AUDIT TRAIL** menu, select the **NJ JUMPER STATE**.
2. Select either **NO JUMPER** or **JUMPER ON**.

### 5.4. SW Revision

*This option displays all the current revision information, used for troubleshooting.*

1. In the **AUDIT TRAIL** menu, select the **SW REVISION**.
2. Open any of the following options to view the revision number.
  - **IMAGE** – Displays the Software Image revision number and software part number.
  - **MODEL** – Displays which model is selected during the last software installation.
    - Either **TS601** or **TS601**.
  - **MAIN** – Displays the current revision level of the Main Software Program..
  - **DRIVERS** – Displays the current revision level of the software driver program.
  - **INTERPRETER** – Displays the current revision level of the software interpreter.
  - **WEBCONFIG** – Displays the current revision level of the **Web Configuration** software.

---

# SECTION 6: OPERATOR MENU


---

## 6.1. New Tare

Follow these steps to store a **New Tare**, using the scale platform, then recalled later as a saved **Tare Weight**.

1. In the **Operator Menu**, press the **DOWN arrow** until **NEW TARE** displays, then press **ENTER**.
2. When **ID (TARE)** displays, Press **ENTER**.
3. When the last stored Tare ID number displays, input the new tare number, then press **ENTER**.
4. When **WEIGHT (TARE)** displays, press **ENTER**.
5. The current weight on the platform is displayed with annunciator on front panel lit to identify active units; press **ENTER** to capture the weight.
  - If there is motion on the platform at that time; **MOTION \_ PLEASE WAIT** displays until the scale settles, and then the weight can be captured.
6. When **VEHICLE DESCRIPTION** displays, press **ENTER**.
7. When the current **Vehicle Description** displays. input the new **Vehicle Description** , then press **ENTER**.
  - This can be the truck drivers' plate number, the vendor ID, or another designated identifying number.

**GROSS WEIGHT – TARE WEIGHT = NET WEIGHT**



8. When **SAVE** displays, press **ENTER**.
9. Using the **DOWN ARROW**, select either **YES** or **NO**, then press **ENTER**.
  - **YES** saves the captured TARE Weight Value, ID, and Vehicle Description.
  - **NO** does not save the **Tare Data**.

---

**NOTE:** If the Tare ID entered in **Step 3** is a duplicate of an existing Stored Tare, then **OVERWRITER, - NO** will display.

---



## 6.1. New Tare, Continued

10. To abort saving the tare, press **ENTER**.
11. To overwrite the existing tare data with the new tare data, press the **DOWN** arrow until **OVERWRITE? - YES** displays, then press **ENTER**
  - **NEW TARE** displays.

## 6.2. New Keyboard Tare

*Follow these steps to store a New Tare, using the keyboard, to be recalled later as a saved tare weight.*

1. In the **Operator Menu**, press the **DOWN** arrow until **NEW KEYBOARD TARE** displays, then press **ENTER**.
2. When **ID (TARE)** displays, press **ENTER**.
3. The last stored Tare ID number is displayed, input the new tare number, then press **ENTER**.
4. When **WEIGHT (TARE)** displays, press **ENTER**.
5. The last tare entry weight is displayed; enter a new tare value via the keyboard, then press **ENTER**.
6. When **UNITS** displays, press **ENTER**.
7. When the current **Units** setting displays, use the **UP/DOWN** arrows to select the correct one, then press **ENTER**.
  - **LB, KG, TON, or TONNE**.
8. When **VEHICLE DESCRIPTION** displays, press **ENTER**.
9. When the current **Vehicle Description** displays; input the new **Vehicle Description**, then press **ENTER**.
  - This can be the truck drivers' plate number, the vendor ID, or another designated identifying number.
10. When **SAVE** displays, press **ENTER**.
11. Using the **DOWN** arrow, select either **YES** or **NO**, then press **ENTER**.
  - Selecting **YES** saves the **Tare**.
  - Selecting **NO** does not save the **Tare**.

---

**NOTE:** *If the Tare ID entered in Step 3 is a duplicate of an existing Stored Tare, then **OVERWRITE? - NO** will display.*

---

12. To abort saving the tare, press **ENTER**.



13. To overwrite the existing tare, press the **DOWN ARROW** until **OVERWRITE?** displays, then press **ENTER** when **YES** displays.

### 6.3. Tare Delete

This option displays a list of all the stored **New Tare** and **New Keyboard Tare** entries.

*Follow these steps to delete a stored Tare.*

1. While in the **OPERATOR MENU**, press the **DOWN arrow** and select the **TARE DELETE**, then press **ENTER**.
2. Press the **DOWN/UP arrows** to scroll through the stored tares.
3. To delete a tare, press the **ZERO** key.

### 6.4. Tare Report

This option displays the stored New Tares and New Keyboard Tares, then prints a Report as selected by the operator.

*Follow these steps to set the Tare Report.*

1. While in the **OPERATOR MENU**, press the **DOWN arrow** and select the **TARE REPORT**, then press **ENTER**.
- 2a. When **DISPLAY** appears, press **ENTER**.
  - This shows the **Stored Tares**, listing the **Tare ID Number**, **Weight**, **Date**, and the **Tare Description**.
- b. Use the **UP/DOWN arrows** to scroll through the list.
- c. Press **MENU** to return to the **Tare Menu**.

**OR...**

- 2a. Use the **DOWN arrows** to select **PRINT**, then press **ENTER**.
- b. Press **ENTER** when **PRINTER** displays.
- c. Select an available **PRINTER**.
- d. Press **ENTER** when **PRINT OUT** displays for the **Tare Report**.
- e. Press **MENU** when **PRINTING COMPLETE --- MENU TO CONTINUE** displays.



## 6.5. Time & Date

### 6.5.1. Format Time & Date

Use the **UP/DOWN** Arrows, **Numeric** keys, **MENU** and **ENTER** buttons to format the Time and Date.

3. While in the OPERATOR MENU, select the **TIME AND DATE** option, then press **ENTER**.
4. **TIME FORMAT** displays, press **ENTER**.

Options are:

**H\_M**

**H\_M\_S**

5. Using the **UP/DOWN** arrows, select the desired format, then press **ENTER**.
6. When **AM/PM** displays, press **ENTER**.
7. When **DATE FORMAT** displays, Press **ENTER**.

Options are:

**MDYY**

**MDYY** (this is for a 4 digit year date)

**DMYY**

**DMYY** (this is for a 4 digit year date)

**YYMD**

**YYMD** (this is for a 4 digit year date)

**MMDDYY**

**MMDDYY** (this is for a 4 digit year date)

**DDMMYY**

**DDMMYY** (this is for a 4 digit year date)

**YYMMDD**

**YYMMDD** (this is for a 4 digit year date)

8. Using the **UP/DOWN** arrows, select the desired format, then press **ENTER**.
9. When **DATE SEPERATOR** displays, press **ENTER**.

Options are:

**/**

**--**

**(SPACE)**



10. After the selection is made, the display returns to **FORMAT TIME AND DATE**

### 6.5.2. Set Time & Date

Use the **Arrow**, **Numeric** and **ENTER** Keys to set the time and date.

1. With the TS60X displaying **FORMAT TIME AND DATE** use the DOWN arrow to display **SET TIME AND DATE** option, then press **ENTER**.
2. **YEAR** will display. Press **ENTER**, key in the year, then press **ENTER**.
3. **MONTH** will display. Press **ENTER**, key in the month, then press **ENTER**.
4. **DAY** will display. Press **ENTER**, key in the day, then press **ENTER**.
5. **HOURL** will display. Press **ENTER**, key in the hour, then press **ENTER**.
6. **MINUTE** will display. Press **ENTER**, key in the minute, then press **ENTER**.
7. **SAVE TIME AND DATE** will display. Press **ENTER** to save the new Time & Date.
8. **TIME SET - PRESS KEY TO CONTINUE** will display.
9. The Time & Date currently configured in the TS60X will now scroll across the display. Press **ENTER**.
10. Display will now show **SET TIME AND DATE**

---

**NOTE:** To set a PM time in the 12 hour format, enter it using the 24 hour format.

- i.e. 8 am is entered as 08. 2 pm entered as 14.
- 

### 6.5.3. To Display Time & Date

1. With the TS60X displaying **FORMAT TIME AND DATE** use the DOWN arrow to display **SET TIME AND DATE** option, then press **ENTER**.
2. **YEAR** will display. Use the UP arrow key to display **SHOW TIME AND DATE**
3. Press **ENTER** and the current configured Time & Date will scroll across the display.
4. Press **ENTER** to return to **SET TIME AND DATE**
5. Press the Red Traffic Light button to return to the weigh screen.



## 6.6. Ticket Number

Follow these steps to access a specific ticket by entering the Ticket Number.

1. While in the **OPERATOR MENU**, select the **TICKET NUMBER** option, then press **ENTER**.
- 2a. When **NUMBER** displays press **ENTER**.
  - b. Using the numeric keypad, in the **Ticket Number**, press **ENTER**.
    - Allows a maximum entry of **six (6) digits**.
    - This sets the value for the **Ticket Number** to be used in the next printing transaction.
  - c. Press the **DOWN arrow** until the **LAST TICKET - PRINT** option displays, then press **ENTER**.
    - This prints a duplicate of the last ticket transaction.

**OR...**

- 2a. Press the **DOWN arrow** until the **DUPLICATE -- PRINT** option displays, then press **ENTER**.
- b. When **ENTER TICKET NUMBER** appears, enter the desired ticket number, then press **ENTER**.
  - This option prints a duplicate ticket for the number as input by the operator.)

## 6.7. Load Cell Diagnostics

**Load Cell Diagnostics** gives a quick snapshot of how each load cell is performing, used for easier troubleshooting capabilities.

1. While in the **OPERATOR MENU**, select the **LOAD CELL DIAGNOSTICS** option, then press **ENTER**.
2. When **ID** displays, press **ENTER**.
3. When **CELL OUTPUTS** displays, press **ENTER**.

### **Step 4 (Option 1)**

- 4a. When **DISPLAY** appears, press **ENTER**.
- b. When **COUNTS** displays, press **ENTER**.
- c. Using the **DOWN/UP arrows**, select the desired load cell (**CELL1** thru **CELL 16**), then press **ENTER**.
  - The counts for the selected load cell will be displayed.



- d. Press **ENTER** to return to **Cell Selection**.
- e. Press **MENU** to return to **DISPLAY MENU**.
- f. Press **DOWN** arrow until **ERRORS** displays, then press **ENTER**.
  - If **NONE** appears, then there are no errors to display.
- e. If errors do occur, use the **DOWN** arrow to select one of the listed Cell numbers that have recorded an error, then press **ENTER**.
  - The **ERROR TYPE**, **DATE**, and **GHOST STATUS** for the recorded error will be displayed.
  - Press **ENTER** three times to return to **Cell Outputs Menu**.

#### **STEP 4 (Option 2)**

- 4a. Press the **DOWN** arrow until **PRINT** displays, then press **ENTER**.
- b. When **PRINTER** displays, press **ENTER**.
- c. Press the **DOWN** arrow to select a printer if multiple printers are configured, then press **ENTER**.
- d. When **COUNTS** displays, press **ENTER** to print the **Cell Counts**.

*The following categories are noted on the **COUNTS** print-out.*

**CELL NUM** – Identifies the load cell in the scale platform.

**CAL COUNTS** – the zero load cell count stored at calibration.

**CURRENT** – the current load cell counts.

**WEIGHT** – the current weight value.

## **6.8. Utility**

### **6.8.1. Set Display Intensity**

- 1. While in the **OPERATOR MENU**, press the **DOWN** arrow and select the **UTILITY** option, then press **ENTER**.
- 2. Press **ENTER** when **SET DISPLAY INTENSITY** appears.
- 3. Select **LOW**, **MEDIUM** or **HIGH**, then press **ENTER**.



### 6.8.2. Key Pad Beep, Set Volume, Mute

#### KEY PAD BEEP

1. In the **UTILITY MENU**, press the **DOWN arrow** and select the **KEY PAD BEEP** option, then press **ENTER**.
2. Select **ON** or **OFF**, then press **ENTER**.

#### SET VOLUME

3. In the **UTILITY MENU**, press the **DOWN arrow** and select the **SET VOLUME** option, then press **ENTER**.
4. Adjust the **BEEP volume** to the desired level.

#### MUTE

5. In the **UTILITY MENU**, press the **DOWN arrow** and select the **MUTE** option, then press **ENTER**.
  - This silences the **Key Pad Beep** until it is reversed.

### 6.9. Options (Operator)

1. While in the **OPERATOR MENU**, press the **DOWN arrow** and select **OPTIONS (OPERATOR)**, then press **ENTER**.
2. Press the **DOWN arrow** and press **ENTER** to select one of these options.
  - **OUTBOUND AUTO SUGGEST** – When processing Inbound Loops, this selection displays the next available one.
  - **AUTO INCREMENT INBOUND ID** – If enabled, the instrument will suggest a Loop ID one value higher than the last Inbound ID used. Otherwise, it will use the lowest available ID.
  - **SHOW LOOPING ID TEXT** – This selection displays *all* the stated information about the Loop, including the ID number, truck description, or any related text.
  - **VIEW BLIND COUNT** – Track number of blind count events.
  - **WEB TIMEOUT** – Select web timeout value.

---

# SECTION 7: CONFIGURATION MENU

---

## 7.1. Change Customer PW

1. In the Configuration Menu, press **ENTER**.
2. When **CHANGE CUSTOMER PASSWORD** displays, press **ENTER**.
3. When **ENTER PASSWORD** displays, **ENTER**.
4. Present **Customer Password** displays.
5. Input the new **Customer Password**, then press **ENTER**.
6. When **CONFIRM PW** displays, press **ENTER** again.
  - If the password is entered incorrectly, **ERROR** displays, then the instrument returns to the previous step.

## 7.2. Prompts – Programmable

**PROMPTS** are messages to the Operator that ask a question, offer a choice, or relay an instruction.

1. In the Configuration Menu, press the **DOWN** arrow until **PROMPTS PROGRAMMABLE** displays.
2. Press **ENTER** when **PROMPT 1** displays.
3. When **NAME** displays, press **ENTER** to prompt the required text.
4. Enter the desired **Entry Prompt 1** text heading.
  - The operator can enter alphanumeric text by either using the **UP** and **DOWN** arrows of the **keypad**, or using the **external keyboard**.
  - When **ENABLED**, this feature displays a **Programmable Prompt** text box.
  - Some examples for this field include “**Truck type**”, “**Driver’s last name**”, “**Special Notes**”, etc.
5. Press **ENTER** to save the **Prompt 1** text, which then can be printed on the ticket.
  - This print command is activated with **<write (Prompt 1 Text)>**.



## 7.2. Prompts – Programmable, Continued

6. Press the DOWN arrow and choose **GTN, INBOUND, OUTBOUND, BASICIN** or **BASICOUT**, then press **ENTER**.
7. Press the **DOWN** arrow to select either **DISABLED** or **ENABLED**, then press **ENTER** to confirm this selection.
  - Selecting **ENABLED** initiates the prompt during the weighment transaction when that operating mode is used.

## 7.3. Legends – Programmable

*Activating this option displays a **LOOP ID** for the operator to enter.*

1. In the Configuration Menu, press the DOWN arrow until **LEGENDS - PROGRAMMABLE** displays.
2. Press **ENTER** when **LOOP ID** displays to edit this **LEGENDS** text.
3. Enter the desired **LOOP ID text**, then press **ENTER** to save it.
  - The Operator can enter alphanumeric text using the up/down arrows on the keypad, or using an external Keyboard..
  - This print command is activated with **<write (Loop ID Text)>**.

## 7.4. Ticket Formats

*For complete descriptions and procedures, see [SECTION 9: FORMATTING TICKETS](#).*

---

**IMPORTANT NOTE:** *Always configure the **COM Ports** first before formatting tickets*

---

## 7.5. COM Ports

*For complete descriptions and procedures, see [8.2. COM PORTS](#).*

## 7.6. Threshold Weights

**THRESHOLD WEIGHT** sets the minimum amount the truck must weigh to initiate a weighment.

- This feature is not used when the **Traffic Light Control** is set to **MANUAL**.



- ✓ **Valid values = 0 to 99,999**
- ✓ **Default setting = 1000**

Follow these steps to set the **THRESHOLD WEIGHT**.


1. In the CONFIGURATION MENU, press the DOWN arrow until **THRESHOLD WEIGHTS** displays.
2. Press **ENTER**.
3. When **INITIAL WEIGHT** displays, press **ENTER**.
4. Enter the desired Threshold Weights value, then press **ENTER**.
5. When **MAXIMUM WEIGHT** displays, press **ENTER**.
6. When **THRESHOLD** displays, press **ENTER**.
7. Enter the desired Maximum Threshold Weight value, then press **ENTER**.
8. **ALLOW OVERWEIGHT TRANSACTION** displays, press **ENTER**.
9. Select **YES** or **NO**
  - **NO** = The TS60X will NOT allow the transaction to continue.
    - The TS60X will display **WEIGHT EXCEEDS MAX THRESHOLD--UNABLE TO CONTINUE**

---

**NOTE – THERE IS NO MEANS TO OVERRIDE THIS SETTING AT THE WEIGH SCREEN. The load on the overweight vehicle must be adjusted before a weighment can be completed.**

---

- **YES** = The TS60X will prompt the Operator with options.
  - The TS60X will display **WEIGHT EXCEEDS MAX THRESHOLD - MENU TO ABORT / ENTER TO CONTINUE**
- The TS60X will continue to display this message until the Operator makes a choice.



## 7.7. Traffic Light Control

---


**NOTE:** See [SECTION 8.4. TRAFFIC LIGHT CONTROL](#) for complete instructions on programming the traffic light.

---

## 7.8. Reports

Follow these steps to setup and generate the **TRANSACTION REPORTS**.

1. In the **CONFIGURATION MENU**, press the **DOWN arrow** until **REPORTS** displays, then press **ENTER**.
2. When **TYPE** displays, press **ENTER**.
3. Using the **DOWN arrow**, select either **COMPLETED TRANSACTIONS** or **INCOMPLETE TRANSACTIONS**, then press **ENTER**.
4. When **MEDIA TYPE** displays, press **ENTER**.
5. When **JUMP DRIVE** displays, press **ENTER**.
  - A **Jump Drive** must be inserted into a **USB port** for a report to be generated.
  - The **Jump Drive** must then be inserted into a printer or PC to print the document or process it further.
6. When **SORT BY** displays, use the **UP/DOWN arrows** to select the **LOOP ID**, **DATE/TIME** or the **TICKET#** for the desired method of sorting the data, then press **ENTER**.
7. When **DELIMITER** displays, using the **DOWN arrow**, select one of these options, then press **ENTER**.
  - **CSV (Comma Separated Value)** – Commas separate data items in the Transaction Report.
  - **TAB** – Tabs are used to separate data items in the Transaction Report.
8. When **GENERATE** displays, press **ENTER** to store the **Report** to the **Jump Drive**.
  - **SUCCESS TYPE\_YYYY-M-DDTHM.XSV SAVED - MENU TO EXIT** displays with the data file name information when the report is stored.
    - Where **TYPE** is either **Completed** or **Incomplete**.
    - **YYYY** is the **year**; **M** is the **month**; **H** is the **hour**; **M** is the **minute**; and **X** is either **C** for **CSV** or **T** for **TAB**.
  - **NO USB DRIVE FOUND - MENU TO EXIT** will display if the USB drive is not installed.
9. Press **MENU** to exit.



## 7.9. Network IP Settings

The **NETWORK option** displays and provides access to configures the ethernet TCP/IP network connection addresses.

**There are two (2) connection options available with the TS60X.**

**DHCP (Dynamic Host Configuration Protocol)** – The customers DHCP network automatically assigns the IP address for the TS60X attached to the network. When using DHCP, the IP address of the TS60X **can change** each time the customers network reissues the leases for the IP addresses on the network. This is why this type of network is known as **Dynamic**.

**STATIC** – Dedicated, specific IP address. This IP address will be provided by the **customers** IT Department. To use a Static IP address the customers IT staff must provide you the following information:

- IP address
- Netmask
- Gateway
- Primary DNS

To enter a **Static address**:

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **NETWORK** displays, then press **ENTER**.
2. When **USE DHCP?** displays, press **ENTER**.
3. When **DHCP** displays, press the **DOWN arrow** until **STATIC** displays, press **ENTER**.
4. **USE DHCP?** will display again. Press the **DOWN arrow** until **STATIC IP** displays. Press **ENTER**.
5. **IP ADDRESS** displays. Key in the IP Address and press **ENTER**.
6. **NETMASK** displays. Key in the Netmask and press **ENTER**.
7. **GATEWAY** displays. Key in the Gateway and press **ENTER**.
8. **PRIMARY DNS** displays. Key in the DNS and press **ENTER**.
9. Press the **DOWN arrow** until **APPLY CHANGES** displays. Press **ENTER**.
10. **NO** displays. Press the **DOWN arrow** until **YES** displays. Press **ENTER**.

---

**NOTE** – If you do not **APPLY** after entering the settings described above, the settings will **NOT** be saved.

---



---

**NOTE** - The instrument **MUST** be connected to a network or you will get an **INTERN** error when you apply changes.

---

- Press the RED traffic light button to return to the weight screen.
- **\*\* Static IP settings are now complete.\*\***

To configure the TS60X for a **DHCP address**:

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **NETWORK** displays, then press **ENTER**.
2. When **USE DHCP?** displays, press **ENTER**.
3. Either **DHCP** or **STATIC** will display, press the **DOWN** arrow until **DHCP** displays, press **ENTER**.
4. **USE DHCP?** will display again. Press the RED traffic light button to return to the weight screen.


Reboot the TS60X.

**\*\* DHCP settings are now complete. \*\***

## 7.10. Transaction Files

Follow these steps to delete **TRANSACTION FILES**.

5. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **TRANSACTION FILES** displays, then press **ENTER**.
6. Press the **DOWN** arrow to select one of the following options, then press **ENTER**.
  - **DELETE ALL TRANSACTIONS** removes all transactions.
  - **DELETE BY TICKET** removes one specific transaction based on the ticket number entered.
  - **DELETE BY DATE RANGE** removes all transactions within the entered date range.
  - **DELETE BY TICKET RANGE** removes all transactions within the entered ticket range.
  - **DELETE INCOMPLETE** removes all the Inbound transactions.



# C A U T I O N

Performing any of these **TRANSACTION FILES** functions will erase some or all the current transaction data records.

## 7.11. Remote Switches

1. In the **CONFIGURATION MENU**, press the **DOWN arrow** until **REMOTE SWITCHES** displays, press **ENTER**.
2. Press the **DOWN arrow** to view switches 1-4 and press **ENTER** on any switch.
3. Press the **UP/DOWN arrows** to view the available options and press **ENTER** to assign one function.
4. **(Optional)** Repeat steps 2-3 to assign up to 3 other remote switches.
5. Use the **RED LIGHT** button to return to the weigh screen.

## 7.12. Instrument ID

Use this setting to assign a numeric ID to the instrument.

## 7.13. Serial Input Codes

1. In the configuration menu, scroll to **SERIAL INPUT CODES** and press **ENTER**. **RED** will appear.
2. Use the arrow keys to scroll through the available inputs and press **ENTER** to select the desired input.
3. Assign the input code a hexadecimal value and press **ENTER**.
4. Repeat steps 3 and 4 for any remaining codes you wish to change.
5. Press the **RED LIGHT** button to return to the weigh screen.

# SECTION 8: SERIAL INPUT / OUTPUT

## 8.1. Printers

### 8.1.1. Printer Switch Settings

ROLL TAPE PRINTER	SW 1 ON	SW 2 ON	SW 3 ON	SWITCH SETTINGS
iDP3550 (28810)	2, 3, 4, 8	1, 2, 3, 5, 6	—	9600 Baud, No Parity, 8 Data and 1 Stop Bit.

TICKET PRINTER	SW 1 ON	SW 2 ON	SW 3 ON	SWITCH SETTINGS
TM-U590 (24740)	1, 3, 7	All OFF	—	9600 Baud, No Parity, 8 Data and 1 Stop Bit.
TM-U295 (24741)	1, 3	All OFF	—	9600 Baud, No Parity, 8 Data and 1 Stop Bit.
SP298	All OFF	3	1, 5	9600 Baud, No Parity, 8 Data and 1 Stop Bit.
SP700	1 thru 7	1 thru 6	1, 5	9600 Baud, No Parity, 8 Data and 1 Stop Bit.
SP2000	All OFF	3	1, 5	2400 Baud, Even Parity, 7 Data and 2 Stop Bit.
SP2200	2, 3, 8	All OFF	All OFF	2400 Baud, No Parity, 7 Data and 2 Stop Bit.
TM-U230 (30954)	All OFF	2, 5, 8	—	9600 Baud, No Parity, 8 Data and 1 Stop Bit.

— No switch bank present inside the printer.

**NOTE:** The Thurman Scale standard default COM Port settings for all the printers is **9600 Baud, No Parity, 8 Bits, and 1 Stop Bit.**

### 8.1.2. Printer Cabling

The chart below shows the connections for the two cable types used with the printers.

#### 14807 CABLE KIT


WIRE	DB-9 INSTRUMENT	COLOR	DB-25 PRINTER	DESC.
1	P1-2	R	P2-2	RX
2	P1-3	W	P2-3	TX
3	P1-5	G	P2-7	GROUND
4	P1-7	O	P2-8	JUMPERED

#### 14809 CABLE KIT

✓ Used only with the **3550 Printer.**

WIRE	DB-9 INSTRUMENT	COLOR	DB-25 PRINTER	DESC.
1	P1-3	R	P2-3	TX to PRINTER
2	P1-8	W	P2-20	BUSY
3	P1-5	G	P2-7	GROUND

### 8.1.3. iDP3550 Tape Printer Settings



DS2	ON	OFF	DS1	ON	OFF
1	X		1		X
2	X		2	X	
3	X		3	X	
4		X	4	X	
5	X		5		X
6	X		6		X
7		X	7		X
8		X	8	X	
			9		X
			10		X

BAUD	<b>9600</b>
PARITY	<b>No</b>
DATA BITS	<b>8</b>
STOP BIT	<b>1</b>

### 8.1.4. TM-U590 Ticket Printer Settings


- For TS601/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.

BAUD	<b>9600</b>
PARITY	<b>No</b>
DATA BITS	<b>8</b>
STOP BIT	<b>1</b>

Set the printer **dip switches** as listed below.

**DSW 1:** 1, 3, and 7 = **ON** only.

**DSW 2:** All Switches = **OFF**






### 8.1.5. TM-U295 Ticket Printer Settings

- For TS601/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.

Set the printer **dip switches** as listed below.

**SW1:** 1 and 3 = **ON**

**Remainder** = **OFF**




BAUD	<b>9600</b>
PARITY	<b>No</b>
DATA BITS	<b>8</b>
STOP BIT	<b>1</b>

### 8.1.6. TM-U220 Tape Printer

- Uses **SERIAL** communication.
- Use cable **25932**.

BAUD	<b>9600</b>
PARITY	<b>No</b>
DATA BITS	<b>8</b>
STOP BIT	<b>1</b>



## WIRING

### Cable **25932** Wiring for COM 1-3

DB-9 INSTRUMENT	DESCRIPTION	WIRE COLOR	DB-25 PRINTER	DESCRIPTION
2	RxD	BR	2	TxD
3	TxD	R	3	RxD
4	DRT	O	6	DSR
5	SG	Y	7	SG
6	DSR	G	20	DTR
7	RTS	BL	5	CTS
8	CTS	BK	4	RTS

### Cable **25932** Wiring for Serial Expansion Module\*

RS232 PORT 1: COM7 XX	DESCRIPTION	WIRE COLOR	DB-25 PRINTER	DESCRIPTION
TB1a-2	RxD	BR	2	TxD
TB1a-3	TxD	R	3	RxD
TB1a-4	DRT	O	6	DSR
TB1a-5	SG	Y	7	SG
TB1b-6	DSR	G	20	DTR
TB1b-7	RTS	BL	5	CTS
TB1b-8	CTS	BK	4	RTS

\* *Must remove the 9-pin connector.*

### 8.1.6. TM-U220 Tape Printer, Continued

#### DIP SWITCH 1 (Serial Interface)

SWITCH	FUNCTION	ON	OFF
1	Data receive error	Ignored	<b>Prints “?”</b>
2	Receive buffer capacity	40 bytes	<b>4KB</b>
3	Handshaking	XON/XOFF	<b>DTR/DSR</b>
4	Work length	7 bits	<b>8 bits</b>
5	Parity check	Yes	<b>No</b>
6	Parity selection	Even	<b>Odd</b>
7	Transmission speed	4800 bps	<b>9600 bps</b>
8	BUSY condition	Receive buffer full	<b>Receive buffer full or Offline</b>

*Default settings are in bold.*


#### DIP SWITCH 2 (Serial Interface)

SWITCH	FUNCTION	ON	OFF
1	Print Column	42/35	<b>40/33</b>
* 2	For internal use only (auto-cutter) (do not change)	<b>Enabled</b>	<b>Disabled</b>
3	Pin 6 reset signal	Used	<b>Not used</b>
4	Pin 25 reset signal	Used	<b>Not used</b>
5	Undefined	--	--
6	Internal use only (flash memory rewriting) (Do not change)	Enabled	<b>Disabled</b>
7	Undefined	--	--
8	Serial Interface section	Memory Switch	<b>Dip Switch</b>

*Default settings are in bold.*

*\* The TM-U220 Tape Printer DAT (dk gray case, w/cutter) will have DSW2 switch #2 set to ON. TM-U220 Tape Printer (white case, no cutter) will have DSW2 switch #2 set to OFF. All other switch settings are identical between printers.*

Access the **Dip Switches** by unfastening the screw and removing the cover plate, found on the bottom of the printer.






### 8.1.7. SP298 Printer Settings


- For TS601/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.

BAUD	<b>9600</b>
PARITY	<b>No</b>
DATA BITS	<b>8</b>
STOP BIT	<b>1</b>

#### ACCESSING THE DIP SWITCHES

- Remove all power from the printer, as well as all Network cables from between the printer and the Instrument.
- Remove the **Printer Cover**.
- Press down with a screwdriver at **Location “A”** marked in the illustration below, and carefully slide the **Document Table** in the direction indicated by the arrow until it is out of the way.
  - It is not necessary to remove the document table completely. Just move it enough to access the DIP Switches inside.
- Set the **DIP Switches** into their correct positions.
- Slide the Document Table back into place while pressing down at **Location “A”**.
- Replace the **Print Cover**.





### 8.1.7. SP298 Printer Settings, Continued

#### DIP Switch Settings (SERIAL INTERFACE)

SWITCH	FUNCTION	ON	OFF
1	Baud Rate	See table below.	
2			
3	Data Length	8 bits	7 bits
4	Parity Check	Disabled	Enabled
5	Parity	Odd	Even
6	Handshake	DTR/DSR	XON/XOFF
7	Command Emulation	See table below	
8			
9	Pin #6 (DSR) reset signal	Enabled	Disabled
10	Pin #25 (INIT) reset signal	Enabled	Disabled

#### Baud Rate Settings Table

BAUD RATE	SWITCH 1	SWITCH 2-2
4800 bps	OFF	ON
9600 bps	ON	ON
1920 bps	ON	OFF
3840 bps	OFF	OFF

#### Command Emulation Table

COMMAND EMULATION	SWITCH 7	SWITCH 8
Star Mode	ON	ON
ESC/POS (TM-295)	ON	OFF
ESC/POS (TM-290)	OFF	OFF
Not used (*)	OFF	ON

\* Never set **Switch 7** to **OFF** at the same time that **Switch 8** is set to **ON**.


### 8.1.8. SP700 Printer Settings

- For TS601/2/3 Instrument Desktop and NEMA 4X SERIAL communications, use cable **14807**.

BAUD	<b>9600</b>
PARITY	<b>No</b>
DATA BITS	<b>8</b>
STOP BIT	<b>1</b>

There are **two (2) dip switch** locations on the Star SP700 Printer.

- Underneath the printer, behind a protective cover is **DIP Switch 1**.
- DIP Switch 2** is on the Serial Interface Board.



SWITCH	FUNCTION	ON	OFF
1-1	Always ON	<b>Should be set ON</b>	
1-2	Auto Cutter *	<b>Invalid</b>	Valid
1-3	Always ON	<b>Should be set ON</b>	
1-4	Command Emulation	<b>Star</b>	ESC/POS
1-5	USB mode **	<b>Printer Class</b>	Vendor Class
1-6	2 Colors Printing	<b>Valid</b>	Invalid
1-7	Reserved		
1-8	Print head model ***	18-pin wire	<b>9-pin wire</b>

\* The factory settings for enabling/disabling the Auto Cutter are as listed below.

- Models without Auto Cutter: Invalid (**Switch 1-2 = ON**).
- Models with Auto Cutter: Valid (**Switch 1-2 = OFF**).

**NOTE:** Only program the **Auto Cutter** function with models that have the **Auto Cutter Accessory** installed.

- This is models with a tear bar.
- A mechanical error will occur.

\*\* **USB Interface** model only.

\*\*\* Do not change the default setting (**Switch 1-8 = OFF**).



### 8.1.8. SP700 Printer Settings, Continued

#### DIP Switch 2

SWITCH	FUNCTION	ON	OFF
2-1	Baud Rate	See table below.	
2-2			
2-3	Data Length	8 bits	7 bits
2-4	Parity Check	Disabled	Enabled
2-5	Parity	Odd	Even
2-6	Handshake	DTR/DSR	XON/XOFF
2-7	Pin #6 (DSR) reset signal	Valid	Invalid
2-8	Pin #25 (INIT) reset signal	Valid	Invalid

#### Baud Rate Settings Table

BAUD RATE	SWITCH 2-1	SWITCH 2-2
4800 bps	OFF	ON
9600 bps	ON	ON
1920 bps	ON	OFF
3840 bps	OFF	OFF

### 8.1.9. SP2000 Printer Settings


The SP2000 is a Dot Matrix ticket printer. The following switch settings and cable requirements will work with the default format.

- For TS601/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.

BAUD	<b>2400</b>
PARITY	<b>EVEN</b>
DATA BITS	<b>7</b>
STOP BIT	<b>1</b>

Set the printer's **dip switches** according to the following:

- **DSW 1:** All **OFF**.
- **DSW 2:** **Three (3) ON** only.
- **DSW 3:** **One (1) and five (5) ON** only.



### 8.1.10. SP2200 Printer Settings

The SP2200 is a Dot Matrix ticket printer. The following switch settings and cable requirements will work with the default format.

- **TS601/2/3 Desktop** and **NEMA 4X** use cable **14807**.

BAUD	<b>2400</b>
PARITY	<b>NO</b>
DATA BITS	<b>7</b>
STOP BIT	<b>2</b>


Set the printer's **dip switches** according to the following:

- **DSW 1:** **Two (2), three (3), and eight (8) ON** only.
- **DSW 2 and 3:** All **OFF**.



### 8.1.11. TM-U230 Printer Settings

- For TS601/2/3 Instrument **Desktop** and **NEMA 4X SERIAL** communications, use cable **14807**.



BAUD	<b>9600</b>
PARITY	<b>No</b>
DATA BITS	<b>8</b>
STOP BIT	<b>1</b>

### DIP Switch 1 Settings (SERIAL INTERFACE)

SWITCH	FUNCTION	ON	OFF
1	Data receive error	Ignored	<b>Prints “?”</b>
2	Receive buffer capacity	1KB	<b>16KB</b>
3	Handshaking	XON/XOFF	<b>DTR/DSR</b>
4	Work length	7 bits	<b>8 bits</b>
5	Parity check	Yes	<b>No</b>
6	Parity selection	Even	<b>Odd</b>
7	Transmission speed	4800 bps	<b>9600 bps</b>
8	BUSY condition	Receive buffer full	<b>Receive buffer full or Offline</b>


### DIP Switch 2 Settings (SERIAL INTERFACE)

SWITCH	FUNCTION	ON	OFF
1	Sections number of characters per line (cpl) 7 x 9 font/ 9 x 9 font	42/35	<b>40/33</b>
2	For internal use only (Auto-cutter) (do not change)	<b>Enabled</b>	Disabled
3	Pin 6 reset signal	Used	Not used
4	Pin 25 reset signal	Used	Not used
5	PAPER OUT LED flashing pattern	<b>Flashes</b>	Lights on
6	For internal use only (flash memory rewriting) (Do not change)	Enabled	<b>Disabled</b>
7	For internal use only (Internal synchronization) (Do not change)	Asynchronous	<b>Synchronous with clock</b>
8	Internal buzzer	<b>Disabled</b>	Enabled

## 8.2. COM Ports

The TS601/2/3 Instrument has numerous ports and outlets allowing different Input/ Output devices to be utilized.

- The back of the Instrument has a 120V outlet, but the unit also supports 220V Scale Input.
- The TS601/2/3 instrument has three (3) standard **Serial Output COM Ports**.
  - These are configured for **RS-232** communications.
  - Serial Outputs can be customized to provide specific configured data string protocols, configuration parameters, using output modes such as **PC Polled, PC Continuous, Demand PC, Off, Remote Display**, and **all printers**.
- The **Console Port** is a RS232 Connection.
- There are three (3) **USB Ports** used for different external components, such as a keyboard, USB Flash Drive, etc.
- The three (3) **ACC holes** are used when wiring external component accessories, such as a remote display, traffic lights, etc.
- The **Ethernet Port** is used **only** for Web Ticket Formatting.





### 8.2.1. Programming COM PORTS

---

**NOTE:** Always configure the Printer before formatting the tickets.

---

Follow these steps to program the **FOUR (4) COM PORTS**.

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **COM PORTS** displays.
2. Press **ENTER**.
3. Using the **DOWN** arrow, select the desired **COM PORT** to configure, then press **ENTER**.
  - **COM Ports** one thru three (1-3) are standard **Serial ports**.
  - COM Port four (4) is dedicated to **20 mA Output**, currently used only for the Remote Display.

### 8.2.2. Configuring the Remote Display Output

Follow these steps to program the **REMOTE DISPLAY**

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **COM PORTS** displays, press **ENTER**.
2. Using the **UP/DOWN** arrows, select **COM 4 (20 MA)**, then press **ENTER**.
3. **DEVICE ATTACHED** is displayed. Press **ENTER**.
4. Use the **UP/DOWN** arrows to display **REMOTE DISPLAY**, then press **ENTER**.
5. **LOAD DEFAULT SETTINGS?** Is displayed, press **ENTER**.
6. Use the **UP/DOWN** arrow to display **YES**, the press **ENTER**.
  - This will load the default settings for Thurman 218 remote displays.
    - **SETTINGS** is displayed. If using a non-Thurman remote display or if the settings otherwise require changes, press **ENTER** to enter the settings menu.
    - The available settings include **BAUD RATE**, **PARITY**, **STOP BITS**, **DATA BITS**, and **CHECKSUM**.
7. Using the **DOWN/UP** arrow, select the proper communication settings for your remote display, then press **ENTER**.
8. Select the correct setting for your remote display, then press **ENTER**.
9. After **CHECKSUM** is displayed, **SETTINGS** is displayed again. Press the **RED** traffic light button once to return to the weigh screen.



**NOTE:** Reference section 10.4 PROGRAMMING THE REMOTE DISPLAY for additional information.

### 8.2.3. Selecting the Printer

1. When **DEVICE ATTACHED** displays, press **ENTER**.
2. Using the **DOWN/UP arrows**, select the desired printer, then press **ENTER**.

OFF *	TM-U230	SP-2000
TM-U295	TM-U590	SP-22000
IDP-3550	SP-700	SP-298
TM-U220	TM-L90	EU-T432
OKI-420	GC-420J	

\* Does not transmit weight amount.

3. When **LOAD DEFAULTS** display, press **ENTER**.
4. Using the **UP/DOWN arrows**, select **YES** or **NO**, then press **ENTER**.
5. When **SETTINGS** displays, press **ENTER**.
6. Using the **DOWN/UP arrow**, select the proper RS-232 Communication settings, then press **ENTER**.
  - The settings include **BAUD RATE**, **PARITY**, **STOP BITS**, **DATA BITS**, and **CHECKSUM**.
7. Input the correct setting, then press **ENTER**.

**NOTE:** The Thurman Scale standard default COM Port settings for all the printers is **9600 Baud, No Parity, 8 Bits, and 1 Stop Bit**.

- The **FORMAT option** does not appear when programming the printers.

### 8.2.4. PC Data String Output

1. When **DEVICE ATTACHED** displays, press **ENTER**.
2. Pressing the **DOWN arrow**, select **PC CONTINUOUS** or **PC POLLED**, then press **ENTER**.
  - **PC CONTINUOUS** – Sends displayed weight continuously.



- **PC POLLED** – The external device sends out a polling request (i.e. CR, “W”, etc.), and the instrument responds with return data.
  - *Data sent is configured in the **GTN** format as the **DEMAND OUTPUT**..*
- 3. Press **ENTER** when **FORMAT** displays.
- 4. Press the **DOWN-arrow** to select the correct standardized data string format.
  - **THURMAN .**
  - **WEIGHTRONIX**
  - **TOLEDO**
  - **CONDEC**
  - **CARDINAL**
- 5. Press **ENTER** to confirm this selection.
- 6. When **LOAD DEFAULTS** displays, press **ENTER**.
- 7. Using the **DOWN/UP arrow**, select **YES** or **NO**, then press **ENTER**.
- 8. When **SETTINGS** displays, press **ENTER**.
- 9. Using the **DOWN/UP** arrow, select the proper RS-232 communication settings, then press **ENTER**.
  - The settings include **BAUD, RATE, PARITY, STOP, BITS, DATA BITS**, and **CHECKSUM**.
- 10. When the current setting is displayed, either press **ENTER**,  
**OR**  
Using the **Numeric Keypad** or **DOWN arrow** input the desired setting, then press **ENTER**.

### 8.2.5. Configuring Network Output

1. Press **MENU** and **LOGIN** will show on screen. Press **ENTER** , (Login in with appropriate login) **OK** appears. Press **ENTER** and **AUDIT TRAIL** appears.
2. Press **DOWN/UP** arrows until **CONFIGURATION** appears. Press **ENTER** and **CHANGE CUSTOMER PASSWORD** appears.
3. Press **DOWN/UP** arrows until **COM PORTS** appears. Press **ENTER**. **UCOM= 1** appears.
4. Press **DOWN/UP** arrows to select the appropriate COM= 1,2,3 or 4. Press **ENTER**. The selected comport, 1,2,3 or 4, is dedicated to the ethernet output only. COM with the comport number you are using. (RS232) will show on the screen. Press **ENTER**.
5. Press **DOWN/UP** arrows until **DEVICE ATTACHED**. appears. Press **ENTER**. **OFF** appears.
6. Press **DOWN/UP** arrows until **NETWORK** appears. Press **ENTER**, **LOCAL PORT** appears. Add the correct port number as determined by the customer. 5001 is the default. Press **ENTER**, **OK** appears and then **CONFIGURE** .



7. Press **ENTER**, **LOAD** appears. Press **ENTER**, **FAIRBANKS** appears. Press **UP/DOWN** arrows on keypad to view a list of formats. Choose the one the customer's IT department wants the TS601 to stream to the PC. Press **ENTER**, **OK** appears and then **LOAD**.

### 8.2.6. DemandPC

This option transmits the weight data in the **GTN format** whenever a carriage return is received.

- All data strings which have a **NON-ZERO VALUE** in the coordinates will be transmitted.
- The order the data strings appear in the data transmission follows the order in which the data is listed in the ticket format.

---

**NOTE:** DemandPC has a separate ticket format that must be enabled in the [Ticket Formats](#) menu.

---

*Follow these steps to format the **DemandPC** option.*

1. When **DEVICE ATTACHED** displays, press **ENTER**.
2. Pressing the **DOWN** arrow, select the **DEMANDPC OUTPUT** then press **ENTER**.
3. When **LOAD DEFAULTS** displays, press **ENTER**.
4. Using the **DOWN/UP** arrow, select **YES** or **NO**, then press **ENTER**.
5. When **SETTINGS** displays, press **ENTER**.
6. Using the **DOWN/UP** arrow, select the proper RS-232 communication settings, then press **ENTER**.
  - These settings include **BAUD**, **RATE**, **PARITY**, **STOP**, **BITS**, **DATA BITS**, and **CHECKSUM**.
7. When the current setting is displayed, either press **ENTER**.

**OR...**

Using the **numeric keypad** or **DOWN** arrow input the desired setting, then press **ENTER**.

### 8.3. 4-20mA Analog Card (30919)

The **4-20 mA ANALOG CARD (30920)** is an **Passive Current Loop Device** with **16 Bit High Resolution Output**.

<b>4-20mA Specifications</b>	– 16 bit resolution +/- .01 integral linearity
<b>Current Loop Voltage Compliance</b>	<ul style="list-style-type: none"> <li>• The 4-20 Analog Card is a <b>PASSIVE DEVICE</b>, and <i>does</i> supply any current loop voltage.</li> <li>• Customer's external source must furnish 7 to 40 VDC power (typical voltage 24 VDC).</li> <li>• The negative (-) power of the supply <b>MUST</b> be isolated from chassis ground</li> <li>• See important <b>CAUTION</b> box below.</li> <li>• A separate Power Supply must be furnished for each output.</li> </ul>
<b>Full Scale Setting Time</b>	<ul style="list-style-type: none"> <li>• 8msecs.</li> </ul>
<b>Output Impedance</b>	<ul style="list-style-type: none"> <li>• 25 Meg Ohms.</li> </ul>
<b>Alarm Current</b>	<ul style="list-style-type: none"> <li>• 3.5 to 24mA (underload/overload conditions), Offset at 25°C; +/- .1% of full scale. Offset drift; +/- 25 ppm of full scale per degree Celsius.</li> </ul>
<b>Total Output Error</b>	<ul style="list-style-type: none"> <li>• (20mA) at 25°C: +/- .2% of full scale max.</li> </ul>
<b>Total Output Drift</b>	<ul style="list-style-type: none"> <li>• +/- 50 ppm of full scale per degree Celsius max.</li> </ul>

C A U T I O N

Failure to use an **ISOLATED POWER SUPPLY**

WILL CAUSE

CATASTROPHIC DAMAGE!



## 8.4. Traffic Light Control

The **Traffic Light Control** sets the operational modes of the traffic light. It is typically controlled automatically by the instrument weightment cycle.

- Each **I/O RELAY CARD** supports **two (2)** sets of lights operated in parallel.

### 8.4.1. Control (Traffic Light)

*Follow these steps to setup the **TRAFFIC LIGHT CONTROL**.*

1. In the CONFIGURATION MENU, press the DOWN arrow until **TRAFFIC LIGHT CONTROL** displays. Press **ENTER**.
2. When **SCALE ID 1** displays, press **ENTER**.
3. When **CONTROL TRAFFIC LIGHT** displays, press **ENTER**.
4. When **AUTOMATIC** displays, either press **ENTER** to select it,

**Or...**

Press the **DOWN arrow** to enter the **MANUAL** option, then press **ENTER**.

### 8.4.2. Event to Signal

*Follow these steps to setup the **EVENT TO SIGNAL OPTION**.*

1. In the **Configuration Menu**, press the **DOWN** arrow until **TRAFFIC LIGHT CONTROL** displays. Press **ENTER**
2. When **SCALE ID 1** displays, press **ENTER**.
3. Press the **DOWN arrow** until **CONTROL TRAFFIC LIGHT** displays, then press **ENTER**.
4. Press the **DOWN arrow** until **EVENT TO SIGNAL** displays, then press **ENTER**.
5. When **X SECOND TIME DELAY** displays, where "X" is the delay setting, input a value from **2** to **10** (seconds), then press **ENTER**.

✓ **Default = 6 Seconds**



## 8.5. Programming the Remote Display

### 8.5.1. Display Mode

Follow these steps to setup the **DISPLAY MODE**.

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **REMOTE DISPLAY** appears. Press **ENTER**.
2. When **DISPLAY MODE** appears, press **ENTER**.
3. When **CONTINUOUS** displays, either press **ENTER** to select it, or press the **DOWN** arrow to enter **ON PRINT**.
4. Press **ENTER**.

### 8.5.2. Type (Output)

This option formats what will appear on the **REMOTE DISPLAY**.

1. In the **REMOTE DISPLAY** menu, press the **DOWN** arrow until **TYPE OUTPUT** displays, then press **ENTER**
2. Press the **DOWN** arrow to select **Gross Wt**, **Net Wt**, **Ticket Number**, **Active Gross** or **Net Wt**.
3. Press **ENTER**.

### IMPORTANT PROGRAMMING CONSIDERATIONS

- When **Display mode** is set to **CONTINUOUS**, and the **Active Gross** or **NetWt** is also set, the remote display follows what appears on the instrument display.
  - The operator can toggle between **Gross Wt** and **Net Wt** by pressing the **B/G NET** button.
  - If the output type is set to **Gross Wt**, the instrument will only display the Gross Weight, regardless of what appears on the instrument.
  - This is the same for **Net Wt**. The remote display indicates the Net Weight.
- When display **Type (Output)** is set to **TICKET NUMBER**, the next **Ticket Number** displays until a print occurs and the printed vehicle leaves the scale.
  - The weight drops below a threshold, either the **Initial Weight** threshold entry or **25 divisions of zero**, whichever is higher.
  - At that point, the next new ticket number displays.
- If display **Type (Output)** is set to **TICKET NUMBER**; the 218/218T Remote Display must be configured first.
  - Set the Annunciator (**ANNUN**) to **SCALE 1**.
  - Set the Annunciator to **NO**.



### 8.5.3. Enable 218T

**I M P O R T A N T**

✓ **Failure to complete these steps correctly constitutes a **NTEP violation**.**

*Follow these steps to enable the 218T Display Instrument.*

1. In the **CONFIGURATION MENU**, press the **DOWN** arrow until **REMOTE DISPLAY** appears, then press **ENTER**.
2. Press the **DOWN** arrow until **ENABLE TRAFFIC LIGHT** displays, then press **ENTER**.
3. Select **YES** or **NO**, then press **ENTER**.

---

**NOTE:** *For the Traffic Light function on the 218T to work, the Display Mode must be set to **CONTINUOUS**.*

---



### 8.6. Basic Troubleshooting

ERROR CONDITION(S)	SOLUTION(S)
Check that scale is empty. If Scale is empty, Call for Service. Load Cell(s) bad.	<b>A large amount of weight is zeroed.</b> –This is normal. –Press <b>OK</b> and continue weighing. –Possible load cell damage. –Call for Service.
<b>LOAD CELL FAILURE(S)</b> Flashing and displays "-- -- -- --"	<b>Possible load cell damage.</b> –Access the <b>Load Cell Diagnostics Menu</b> to verify the load cell status. –Count stability or change of counts. –Contact the local service for further trouble-shooting. –Call for Service.
<b>5C CELLS FOUND NONE</b>	<b>Possible damaged load cell cable.</b> –Load cell shortened. –Defective Pit Power Supply. –Defective Smart Sectional Controller(s). –Defective SIC Module.
Displays "-- -- -- --" " " LB <b>GROSS</b>	<b>Communication error to load Cells.</b> –Check settings by pressing <b>F10</b> . –Settings should be COM2, Even.
<b>INTERR</b>	<b>System Error.</b> –Restore Backup, if possible to recover. –Otherwise, replace the PCB Assembly Base Board (33143).
<b>POWER SUPPLY ERROR: AC OUTPUT OPEN</b>	<b>Check main interface cable to be cut.</b>
<b>AC OUTPUT SHORTENED</b>	<b>Cable problems, usually repairable.</b>
<b>COMMUNICATION ERROR</b>	<b>Can be caused by numerous transmission problems, including bad Load Cell, faulty cable, conflicting programming, etc.</b>
<b>POWER SUPPLY NEEDS TO BE CONFIGURED: GO TO MENU</b>	<b>First-time opening message to configure the Instrument to the Power Supply.</b>

---

# SECTION 9: FORMATTING TICKETS

---

## 9.1. Standard Ticket Formatting Steps

Listed below are the standard steps for formatting a ticket.

1. Configure the **Service Menu** to the correct **OPERATING MODE**.
  - This setup determines how the ticket prints.
  - The **GTN format** configures only the **GTN tickets**.
  - The **In/Out format** configures In/Out tickets.
  - The **Basic format** configures BasicIn and BasicOut tickets.
  - Each **Operating Mode** formats the weightment data in different positions on the ticket, printing only the needed data for that ticket.
  - The ticket format can also vary due to the printer type that is used.
  - Each ticket format can be adjusted to best suit the customer's needs.

---

**IMPORTANT NOTE:** *Always configure the **COM Ports** before formatting tickets.*

---

2. Set up the **COM Ports** in the **Configuration Menu** to a specific attached device.
3. Install, wire and configure the printer.
4. Access the **TICKET FORMAT** menu.
5. Insert a blank ticket, then press the **PRINT** key for a ticket self-test.
  - This identifies its current margin setup.
6. Press the **OUT** button to print out the complete **Mode of Operation** format structure.
7. Using this self-test ticket, plan where to format the ticket margins and available print spaces.
  - Determine how the current ticket format might differ from the customer's needs.
  - Plan the needed changes according to their **SPACE** (*horizontal*) and **FEED** (*vertical*) coordinates of the ticket.
  - Mark up this ticket with a ruler and pencil as needed, using it as a guide.





### 9.3. Ticket Formatting

Follow these guidelines when programming a **TICKET FORMAT**.

- All commands are written in the specific order to the ticket. They flow downward, starting from the top-left of the printer-assigned margin.
- Each command first describes the action, then in brackets, it defines how many, the type of action, or exactly what text to print.
- To remove a printed item on the ticket, display the command, then press the **ZERO key**.

#### 9.3.1. Write Commands

**WRITE (\_\_\_\_\_)** commands offer a standard list of **System Data Fields** to use when programming.

Follow these steps to alter how a **WRITE** field appears.

1. Use the **UP/DOWN arrows** to navigate thru the **WRITE commands**, then press **ENTER** to open one.
2. Using the **UP/DOWN arrows**, select the option that best suits the programming need, then press **ENTER**.
  - The **WRITE (\_\_\_\_\_)** option selected will display next on the ticket.
  - Certain commands offer two choices, followed by a printed response for one.

#### Example:

**HIDEWRITEONZERO (TARE/TARE)**

This example means the following:

- **Hide** (do not print) the **Tare amount if it equals ZERO (0)**.
- **Write** (print) the **Tare amount if it is greater than ZERO (0)**.

<b>Keypad Formatting Buttons</b>	
<b>UNITS:</b>	Inserts new format line <i>before</i> .
<b>B/G/NET:</b>	Inserts new format line <i>after</i> .
<b>ZERO:</b>	Deletes the current format line.
<b>OUT:</b>	Prints entire Format Script.
<b>MENU:</b>	Saves ticket format.
	– Steps back one level.
<b>ENTER:</b>	Saves all data input..
<b>PRINT:</b>	Prints a sample ticket.
<b>RED Button:</b>	Exits to <b>Weigh Screen</b> .
<b>GREEN Button:</b>	Deletes Format Script.



### 9.3.1. Write Commands, Continued

Listed below are the **WRITE (\_\_\_\_\_)** commands.

- **GROSS**
- **TARE**
- **NET**
- **DATEIN**
- **DATEOUT**
- **TIMEIN**
- **TIMEOUT**
- **UNITSGROSS UNITSTARENET**
- **TICKET NUMBER**
- **LOOPIDTEXT**
- **LOOPIDPROMPT1TEXT**
- **PROMPT 1**
- **INBOUND**
- **MANUAL TARE**
- **DUPLICATE**
- **DUALGROSS**
- **DUALTARE**
- **DUAL NET**
- **DUALINBOUND**
- **DUALUNITSGROSS**
- **DUTANTUNITS**
- **VEHDESC**

**WRITE (TEXT)** commands are programmable text fields, allowing legends or prompts to be altered to suit the application needs.


- These text fields can be any character(s) required to suit the customer’s need.
- All data items are **left justified**, with a maximum of **fifteen (15) characters**.

**NOTE:** When inverting tickets, the **Invert “On”** command should be the first one in the format.

Turn the option **“Off”** as the last command before the ticket release, or the reports will invert when they print.

### 9.3.2. Quick Formatting Buttons

KEYPAD	EXT. KEYBOARD	PROGRAMMING FUNCTION	NORMAL FUNCTION
ZERO	DEL	Deletes current formatting line.	ZERO
UNITS	PgUp	Inserts a new line <i>before</i> the current line.	UNITS
PRINT	INSERT	Prints a sample ticket	PRINTS
B/G NET	END	Inserts a new line <i>after</i> the current line.	B/G NET Select
MENU	HOME	<ul style="list-style-type: none"> <li>• Saves ticket format (YES/NO).</li> <li>• Backs up one menu level.</li> </ul>	MENU
RED LIGHT	F1	Exits without saving.	Red Light ON
GREEN LIGHT	F2	Deletes the entire Ticket Format Script.	Green Light ON
IN	F4	N/A	INBOUND
OUT	F5	Prints the entire Ticket Format Script.	OUTBOUND
TARE	“.”	N/A	Auto Tare



### 9.3.3. Ticket Format Commands

The **TICKET FORMAT** commands are defined below.


SPACE ( )	One (1) movement across (horizontal).
FEED ( )	One (1) movement downward (vertical).
INVERT ON/OFF	Prints the ticket from the bottom-to-the-top, placing data where it belongs according to the programmed coordinates.
WRITE TEXT ("___")	Programmable fields that allow <b>Legends</b> or <b>Prompts</b> to be altered to suit the application needs. Appears exactly as written within the quotation marks. <ul style="list-style-type: none"> <li>When programming <b>(WRITE)</b> fields, a <b>System Data</b> list displays.</li> </ul>
HIDEWRITEONZERO (TARE, NET)	If the Tare is <b>ZERO</b> , this prevents the <b>Net Weight</b> figure from being printed.
HIDEWRITETEXTONZERO (___/"___")	<b>HIDE</b> the message if the amount is <b>ZERO (0)</b> . <b>WRITE</b> the quoted word if there is a different amount. <ul style="list-style-type: none"> <li>Quotation marks within the command display the exact words.</li> </ul>
WRITE (_____)	Without quotation marks, the printer writes out requested data of the command. <ul style="list-style-type: none"> <li>A command is sometimes blended with others together to print all the correct elements. <b>WRITE (UNITSTARENET)</b> is an example.</li> </ul>
WRITE (DUPLICATE)	<b>"Duplicate Copy"</b> appears on the ticket for a <b>TICKET REPRINT</b> . <ul style="list-style-type: none"> <li>This specialized command has one purpose, and cannot be altered.</li> </ul>
ENHANCE ("on")	Enlarges the font characters, and prints them in bold text.
ENHANCE ("off")	Reduces the font size, and prints them in standard text.
WRITE (GROSS)	Prints the <b>Gross Weight</b> .
WRITE (TARE)	Prints the <b>Tare Weight</b> .
WRITE (NET)	Prints the <b>Net Weight</b> .
WRITE (DATE IN)	Prints the <b>date</b> of the <b>first weighment</b> .
WRITE (DATE OUT)	Prints the <b>date</b> of the <b>final weighment</b> .
WRITE (TIME IN)	Prints the <b>time</b> of the <b>first weighment</b> .
WRITE (TIME OUT)	Prints the <b>time</b> of the <b>final weighment</b> .
WRITE (UNITS)	Prints the <b>Unit</b> choice.
WRITE (TICKET NUMBER)	Prints the current <b>ticket number</b> .
WRITE (LOOP ID TEXT)	Prints the legend in the <b>Loop ID</b> field, determined by the technician. <ul style="list-style-type: none"> <li><b>Truck Number, Rail Car Number, etc.</b></li> </ul>
WRITE (LOOP ID)	Prints the <b>Loop ID</b> .
WRITE (PROMPT 1 TEXT)	Prints the <b>Legend</b> that prompts the user to enter an answer or to add data. <ul style="list-style-type: none"> <li><b>BOL Number, License, etc.</b></li> </ul>
WRITE (PROMPT 1)	Prints the data from the <b>Prompt 1 Text</b> field.
INBOUND	Prints the <b>Inbound weight</b> .
WRITE (MANUAL TARE)	Prints an asterisk (*) next to the <b>TARE value</b> when it is a <b>MANUAL TARE</b> ..
RELEASE ( )	End of the ticket, this command <b>releases the ticket</b> from the printer.
CLAMP ( )	Clamps the printer paper.
CUTPAPER ( )	Cuts the printer paper.





### 9.3.5. G/T/N Ticket Formatting

Defined below is the structure and appearance of a **GROSS/TARE/NET** ticket.




**1-Space <8>** moves the ticket text horizontally.

**3-Feed <1>** moves the ticket text vertically.

**"Duplicate Copy"** appears only when a **TICKET REPRINT** is performed.

This image shows the printed areas and other defined elements of a G/T/N Ticket.  
 – All grey markings are for illustration purposes only.



**14-Enhance <"on">** is the command for enlarged and bolded print.

**32-Enhance <"off">** restores print style to standard.


Example of an actual G/T/N Ticket.

GTN	
1-Space <4>	
2-Write <Duplicate >	
3-Feed <1>	
4-WriteText <"TICKET NUMBER" >	
5-Space <6>	
6-Write <TicketNumber >	
7-Feed <14>	
8-Space <4>	
9-Write <DateOut >	
10-Space <10>	
11-Write <TimeOut >	
12-Feed <2>	
13-Enhance <"on" >	
14-Write <GroSS >	
15-Space <1>	
16-Write <UnitSGroSS >	
17-Space <1>	
18-WriteText <"GROSS" >	
19-Feed <1>	
20-Write <Tare >	
21-Space <1>	
22-Write <UnitSTareNet >	
23-Write <ManualTare >	
24-HideWriteTextOnZero <Tare, "TARE" >	
25-Feed <1>	
26-Write <Net >	
27- Space <1>	
28-Write <UnitSTareNet >	
29-Space <1>	
30-HideWriteTextOnZero <Tare, "NET" >	
31-Feed <2>	
32-Enhance <"off" >	
33-Feed <10>	
34-ReleaSe < >	

The flow chart above outlines the coordinates for each element of the G/T/N Ticket.

### 9.3.6. Inbound Ticket Formatting


Defined below is the structure and appearance of an **INBOUND** ticket example.



INBOUND	
1-Space <4>	
2-Write <Duplicate >	
3-Feed <1>	
4-Feed <10>	
5-WriteText <"INBOUND" >	
6-Space <6>	
7-Write <Inbound >	
8-Space <6>	
9-Write <UnitSGross >	
10-Feed <1>	
11-Write <LoopIDText >	
12-Space <6>	
13-Write <LoopID >	
14-Feed <2>	
15-Space <4>	
16-Write <DateIn >	
17-Space <10>	
18-Write <TimeIn >	
19-Feed <16>	
20-ReleaSe < >	

The image above shows the printed areas and other defined elements of the ticket.

- All grey markings are for illustration purposes only, and not printed.




Example of an **Inbound Ticket**.

The flow chart above outlines each element of the Inbound Ticket.




### 9.3.7. Outbound Ticket Formatting

Defined below is the structure and appearance of an **OUTBOUND** ticket example.



OUTBOUND	
1-Space <4>	
2-Write <Duplicate >	
3-Feed <1>	
4-WriteText <"TICKET NUMBER" >	
5-Space <6>	
6-Write <TicketNumber >	
7-Feed <14>	
8-Space <4>	
9-Write <DateOut >	
10-Space <10>	
11-Write <TimeOut >	
12-Feed <2>	
13-Enhance <"on" >	
14-Write <GroSS >	
15-Space <1>	
16-Write <UnitSGroSS >	
17-Space <1>	
18-WriteText <"GROSS" >	
19-Feed <1>	
20-Write <Tare >	
21-Space <1>	
22-Write <UnitSTareNet >	
23-Write <ManualTare>	
24-HideWriteTextOnZero <Tare, "TARE" >	
25-Feed <1>	
26-Write <Net >	
27-Space <1>	
28-Write <UnitsTareNet >	
29-Space <1>	
30-HideWriteTextOnZero <Tare, "NET" >	
31-Feed <2>	
32-Enhance <"off" >	
33-Write <LoopIDText >	
34-Space <6>	
35-Write <LoopID >	
36-Feed <10>	
37-Release <>	

This image shows the printed areas and other defined elements of the **Outbound Ticket**.  
– All grey markings are for illustration purposes only.



Actual image of an **Outbound Ticket** (without any Inbound Ticket information).

This flow chart outlines coordinates for each element of the **Outbound Ticket**.



### 9.3.8. Completed Transaction Ticket Example

Shown below is a ticket example of a completed **INBOUND / OUTBOUND** transaction.

**INBOUND TICKET**  
includes the **LOOP ID, DATE, TIME,** and Initial Weight.

1-800-821-3322

---

TICKET NUMBER 12

CUSTOMER'S NAME \_\_\_\_\_  
 ADDRESS \_\_\_\_\_  
 COMMODITY \_\_\_\_\_  
 CARRIER \_\_\_\_\_

INBOUND	20000	1b	
Loop ID	333		

INBOUND DATE 10/18/12 TIME 02:54 PM  
 OUTBOUND DATE 10/18/12 TIME 04:24 PM

35020	1b	GROSS	
20000	1b	TARE	
15020	1b	NET	

Loop ID 333

DRIVER ON \_\_\_\_\_ OFF \_\_\_\_\_

SHIPPER \_\_\_\_\_  
 WEIGHER \_\_\_\_\_

**OUTBOUND TICKET** includes the **DATE, TIME, GROSS, TARE and NET Weights.** Also includes the **TICKET NUMBER and LOOP ID NUMBER.**

**Keypad Formatting Buttons**

**UNITS:** Inserts new format line *before*.

**B/G/NET:** Inserts new format line *after*.

**ZERO:** Deletes the current format line.

**OUT:** Prints entire Format Script.

**MENU:** Saves ticket format.  
 - Steps back one level.

**ENTER:** Saves all data input..


**PRINT:** Prints a sample ticket.

**RED Button:** Exits to **Weigh Screen**.

**GREEN Button:** Deletes Format Script.



### 9.3.9. BasicIn and BasicOut Ticket Formatting



This image shows the printed areas and other defined elements of the BasicIn and BasicOut Tickets.

BASICIN	
1-Write <TimeIn >	
2-Space <1>	
3-Write <DateIn >	
4-Space <1>	
5-Write <GroSS >	
6-Space <1>	
7-Write <UnitSGroSS >	
8-Space <1>	
9-WriteText <"GROSS" >	
10-Feed <1>	
11-ReleaSe < >	


BASICOUT	
1-Feed <2>	
2-Space <1>	
3-Write <TimeOut >	
4-Space <1>	
5-Write <DateOut >	
6-Space <1>	
7-Write <GroSS >	
8-Space <1>	
9-Write <UnitSGroSS >	
10-Space <1>	
11-WriteText <"TARE" >	
12-Feed <1>	
13-ReleaSe < >	

**NOTE:** Tickets programmed in the **BasicIn** and **BasicOut** formats can be set up as the customer requests, within the boundaries of the ticket size.

- The one displayed above is shown as an **example only**.



### 9.3.10. Deleting a Ticket Format



Follow these steps to **DELETE** a ticket format, and then reset to the **factory default**.

1. In the **CONFIGURATION MENU**, press the **DOWN arrow** until **TICKET FORMATS** displays, then press **ENTER**.
2. When **PRINTER** displays, press **ENTER**.
3. Press the **DOWN arrow** until the desired printer displays, then press **ENTER**.
4. Press the **DOWN arrow** until **SELECT FORMAT** displays, then press **ENTER**.
5. Press the **DOWN arrow** the **Ticket Format** to be deleted displays, then press **ENTER**.
6. When **ENABLED** or **DISABLED** displays, press **ENTER**.
7. Press the **DOWN arrow** until **DELETE** displays, then press **ENTER**.
8. Press the **DOWN arrow** until **YES** displays, then press **ENTER** to delete the current ticket format and replace with the default format.

---

# APPENDIX I: DATA STRING OUTPUTS

---

## A. Remote Display Output

### DATA FORMAT

<STX><A><0><SP/-><XXXXXX><ETX>

---

### NOTES:

1. Characters denoted by X are characters 0-9.
  2. Leading zeroes are suppressed.
  3. Polarity indication for a positive value is a space (SP).
    - Negative values are not transmitted.
  4. Identifier code <4><0> = Gross weight.
    - Transmission is Gross Only.
  5. Transmission for the DEMAND Mode occurs when a carriage return (CR) HEX 0D is received.
  6. See [APPENDIX V](#) for more ID Codes.
- 

## B. Configure Output

The Continuous Computer Output is an uninitiated, unrequested output that gets transmitted at a fixed time interval.

### THURMAN/TOLEDO DATA FORMAT

<STX><A><B><C><GGGGGG><TTTTTT><CR>

---

### Character String Description:

**STX** - Start of Text character (02 Hex)

**A** - Status Word A

**B** - Status Word B

**C** - Status Word C

**G (gross weight data)** - xxxxxx Displayed Weight : x = Weight

- 6 characters if the graduation size does not have a decimal point.

- 5 characters if the graduation size does have a decimal point.

The decimal point is not sent as part of the character string.

**T (tare weight data)** - xxxxxx Tare Value : x = Tare

- (6 characters if the graduation size does not have a decimal point.)

- (5 characters if the graduation size does have a decimal point.

The decimal point is not sent as part of the character string.

**CR** - Carriage Return Character: (0D hex)

**CS** - CheckSum Character: If enabled, this character consists of the last eight bits of the binary sum of all characters transmitted up to this checksum character.

---



## B. Configure Output, Continued

### STATUS CODE (WORD) A

Bit #	X00	X0	X	X.X	X.XX	X.XXX	X.XXXX	X.XXXXX
0	0	1	0	1	0	1	0	1
1	0	0	1	1	0	0	1	1
2	0	0	0	0	1	1	1	1

### THURMAN/TOLEDO DATA FORMAT

#### INCREMENT SIZE

Bit #	Count By 1	Count by 2	Count by 5
3	1	0	1
4	0	1	1
5		Always Logic 1	
6		Always Logic 0	
7		Parity Bit	

### STATUS CODE (WORD) B

Bit #	Description
0	Gross = 0 Net = 1
1	Positive = 0 Negative = 1
2	In Range = 0 Overcapacity = 1
3	No Motion = 0 Motion = 1
4	Lb = 0 Kg = 1
5	Always Logic 1
6	Normal = 0 Power Up = 1
7	Parity Bit



## B. Configure Output, Continued

### STATUS CODE (WORD) C

Bit #	Description		
0	Always Logic = 0		
1	Always Logic = 0		
2	Always Logic = 0		
3	Normal = 0		Print Switch Pushed = 1
4	Always Logic = 0		
5	Always Logic = 0		
6	Normal = 0		Keyboard Tare = 1
7	Parity Bit		

### CARDINAL 738 CONTINUOUS SCOREBOARD DATA FORMAT

<CR><P><WWWWW>Period (.)<m><SP><u><SP><g><SP><SP><ETX>

#### Character String Description:

**CR** – Carriage return

**P** – Polarity (+ = Positive weight, - = Negative weight)

**W** – Displayed weight

- 6 characters if the graduation size does not have a decimal point.

- 5 characters if the graduation size does have a decimal point.

**m** – Motion or o = Overload


**SP** – Space

**U** - Units (lb = pounds, kg = kilograms)

**g** – Gross or **n** = Net

**ETX** - End of text

- Leading zeros are not suppressed
- If division size has no decimal point, set the decimal to "trailing".
- If division size has a decimal point, set the decimal to "floating".



## B. Configure Output, Continued

### WEIGHTRONIX DATA FORMAT

<SP><G><WWWWW><SP><U><U><CR><LF>

---

#### Character String Description:

**SP** – Space

**g** – Gross or **n** = Net

**W** – Displayed weight

- 6 characters if the graduation size does not have a decimal point.
- 5 characters if the graduation size does have a decimal point.

**SP** – Space

**U** – Units (lb = pounds, kg = kilograms)

**M** – Motion

**CR** – Carriage return

**LF** – Line feed

- Leading zeros are not suppressed.
  - There is no motion character.
- 

### CONDEC CONTINUOUS DATA FORMAT

<STX><SP><SP><WWWWW><U><G><M><CR>

---

#### Character String Description:

**STX** – Start of Text character (02 Hex)

**SP** – Space

**SP** – Space

**W** – Displayed weight

- 6 characters if the graduation size does not have a decimal point.
- 5 characters if the graduation size does have a decimal point.

**U** – Units (L = pounds, K = kilograms)

**G** – Gross; **N** = Net

**M** – Motion

**CR** – Carriage return.

- Leading zeros are suppressed.
-

---

# APPENDIX II: REMOTE SERIAL COMMANDS

---

COMMAND	DESCRIPTION
<b>A</b>	Sets the <u>A</u> uto Tare Weight on scale.
<b>G</b>	Turns the traffic light <u>G</u> reen. — Used in Manual Mode only.
<b>LA</b>	Changes Traffic <u>L</u> ight to <b>Automatic Mode</b> .
<b>LM</b>	Changes Traffic <u>L</u> ight to <b>Manual Mode</b> .
<b>R</b>	Turns Traffic Light <u>R</u> ed. — Used in the <b>Manual Mode</b> only.
<b>Txxxxx</b>	Sets <u>T</u> are on scale — Where <b>xxxxx</b> equals the tare weight value required.
<b>U</b>	Toggles <u>U</u> nits on scale.
<b>Z</b>	<u>Z</u> eroes the scale.
<b>P</b>	<u>P</u> rints a ticket for the active scale.
<b>W</b>	<b>Demand Request</b> for a <u>W</u> eight output using <b>PC Polled</b> .

---

# APPENDIX III: CONNECTING TO THE TS60X VIA ETHERNET

---

## *Connecting via the Web Utility using an ethernet crossover cable*

---

**NOTE:** If you are *not* using a keyboard and mouse on your PC or if you are using a Tablet, touch and hold will act as a 'Right Click'.


---

### To access the current IP address of the TS60X:

1. Login to the TS60X
2. Scroll *down* to **CONFIGURATION**.  
Press ENTER
3. Scroll *up* to **NETWORK**  
Press ENTER
4. Use **DHCP?** is displayed.  
Press ENTER  
Depending on how the TS60X has been configured **DHCP** or **STATIC** will display. Follow the instructions below for **DHCP** or **STATIC**:

### *If DHCP is displayed...*

5. Scroll down to **STATIC** and press **ENTER**:
6. Use **DHCP?** is displayed.  
Scroll down to **STATIC IP** and press **ENTER**
7. **IP ADDRESS** is displayed  
Enter the IP ADDRESS as:  
**192.168.100.XXX** and press **ENTER**  
XXX must be **greater** than 001
8. **IP ADDRESS** is displayed and press **ENTER**
9. Scroll *down* to **NETMASK** and press **ENTER**  
Enter the **NETMASK** as:  
**255.255.255.000** and press **ENTER**
10. Scroll *down* to **GATEWAY** and press **ENTER**  
Enter the **GATEWAY** as:  
**192.168.100.001** and press **ENTER**



11. Scroll down to **PRIMARY DNS** and press **ENTER**  
Enter the **PRIMARY DNS** as:  
**008.008.008.008** and press **ENTER**
12. Scroll *down* to **APPLY CHANGES**  
Scroll *down* to **YES** and press **ENTER**
13. Press the **RED** Traffic light button twice to return to the weigh screen

***If STATIC is displayed...(continued from Step 4 on previous page)***

5. Press **ENTER**
6. **IP ADDRESS** is displayed and press **ENTER**
7. The TS60X IP address is displayed  
**XXX.XXX.XXX.XXX**
8. Use the right arrow to scroll to see the whole IP address
9. Write down the IP address


**Procedure:**

1. **FOR TABLET USERS ONLY** - Plug in your USB to ethernet adaptor
  - a. If you are using a PC with **Windows 8**, proceed directly to step 2

2. Right click on the **Start menu** (Windows Logo)




3. Click on **Network Connections**






4. Right click on **Ethernet Connection** for the adapter (it may state **ETHERNET 2**)



5. Click on **Properties**



6. Click on internet protocol **Ver. 4 TCP/IP 4**





7. Then click on **Properties**

8. Click **Use the following IP address:**

Obtain an IP address automatically  
 Use the following IP address:  
IP address: [ ] . [ ] . [ ] . [ ]  
Subnet mask: [ ] . [ ] . [ ] . [ ]  
Default gateway: [ ] . [ ] . [ ] . [ ]

9. Enter the IP address of the instrument here, but make the last number in the IP address **at least 1 number higher** than the instrument.

Use the following IP address:  
IP address: [ 192 . 168 . 100 . 003 ]  
Subnet mask: [ 255 . 255 . 255 . 000 ]  
Default gateway: [ 192 . 168 . 100 . 001 ]

10. Click in the Subnet Mask box and enter 255.255.255.0 as shown.

Use the following IP address:  
IP address: [ 192 . 168 . 100 . 003 ]  
Subnet mask: [ 255 . 255 . 255 . 000 ]  
Default gateway: [ 192 . 168 . 100 . 001 ]

11. Click in the Default Gateway box and enter 192.168.100.001 as shown.

Use the following IP address:  
IP address: [ 192 . 168 . 100 . 003 ]  
Subnet mask: [ 255 . 255 . 255 . 000 ]  
Default gateway: [ 192 . 168 . 100 . 001 ]

12. Click in the Preferred DNS server box and enter 008.008.008.008 as shown.

Use the following DNS server addresses:  
Preferred DNS server: [ 008 . 008 . 008 . 008 ]  
Alternate DNS server: [ . . . ]


13. Click **OK** close this window.

14. Connect your PC or Tablet to the instrument using the ethernet cable.

15. Open your browser (Internet Explorer, Chrome or FireFox)



16. Enter the IP address of the instrument in the browser address bar



*WHEN USING CERTAIN BROWSERS, YOU MAY NEED TO INCLUDE LEADING ZEROS WHEN ENTERING THE IP ADDRESS.*



THURMAN SCALE, INC.  
4025 Lakeview Crossing  
Groveport, Ohio 43215  
[www.thurmanscale.com](http://www.thurmanscale.com)

## **TS600 Series Instrumentation**

**TS601 IN/OUT/GTN Analog Desktop Instrument**

**TS602 IN/OUT/GTN Analog NEMA 4X Wall mount Instrument**

**TS603 In/Out/GTN Analog Panel Mount Instrument**

**TS603 Driver Assist Terminal**

**Operator Manual 51421**